

Document No.: SX-DSV03224

Revision No.: 11.0

Date of Issue: February 1, 2024

Classification: ☐ New ☒ Change

SPECIFICATIONS

Product Name: AC Servo Driver

Product Series Name: MINAS A6N Series for Linear motor/DD motor/VCM

Product Model Number: Basic Type/Multifunction Type

Motion Control Business Unit, Industrial Device Business Division
Panasonic Industry Co., Ltd.
7-1-1 Morofuku, Daito City, Osaka, 574-0044, Japan

If you have any questions, please contact the sales office or distributor of the product.

Panasonic

REVISIONS

Date	Rev.	Page	Description	Signed
Mar. 20, 2019	0.0	—	NEWLY ISSUED	—
Jul. 4, 2019	1.0	—	Changed company name	—
		P6	Corrected table in “3 Product Line-up”	
Jan. 8, 2020	2.0	—	Added parameters	—
		P1, P29 to P34 P44 to P50	Added function “Voice coil motor (VCM) support”	
Apr. 8, 2020	3.0	—	Added 400 V specification	—
		—	Updated other contents according to the latest Japanese version	
		—	Corrected typographical errors	
Sep. 25, 2020	4.0	—	Added information regarding the attached table, corrected typographical errors	—
		—	Changed the title of this specification to “Standard Specifications”	
Nov. 10, 2020	4.1	P39	Corrected typographical errors	—
Mar. 1, 2021	5.0	—	Added Size D 400 V specification, corrected typographical errors	—
Nov. 1, 2021	6.0	—	Changed company name	—
		P78, 79	Updated the description of global standards	
		P92	Updated a note about network security	
		P93	Added a note about reverse engineering	
Apr. 1, 2022	7.0	—	Changed to our updated format and revised to standardize expressions	—
		—	Changed company name	
Oct. 31, 2022	8.0	—	Changed Compliance with the international standards Corrected typographical errors	—
Jul. 12, 2023	9.0	—	Added Size G/H 400 V specification	—
Nov. 1, 2023	10.0	—	Updated default parameters	—
Feb. 1, 2024	11.0	P3, 4	Corrected typo regarding rated current of applicable motor (MDDL45NL, MDDL45NM)	—
		P7 to P17	Changed product number of X7 analog monitor connector	
		P54	Changed the connector and terminal product number of the X7 connector cable	
		P87 to P89	Added Compliance with EN61800-5-1:2007/A11:2021	
		P95	Added text to “Load protection and overheating protection” column	

Date	Rev.	Page	Description	Signed
		P108, 110, 113	Corrected typo regarding maximum output current (MDDL45NL, MDDL45NM, MGDLC3NM, MGDLC4NM)	

Table of Contents

1 Scope of Application	1
2 How to Read Product Numbers	2
3 Product Line-up	3
3.1 Basic Type	3
3.2 Multifunction Type	4
4 Specifications	5
5 Appearance and Part Names	7
5.1 Size A, B 100 V/200 V	7
5.2 Size C, D 100 V/200 V	8
5.3 Size E 200 V	9
5.4 Size F 200 V	10
5.5 Size G 200 V	11
5.6 Size H 200 V	12
5.7 Size D 400 V	13
5.8 Size E 400 V	14
5.9 Size F 400 V	15
5.10 Size G 400 V	16
5.11 Size H 400 V	17
5.12 Example nameplate	18
5.13 Front panel	19
6 Dimensions	20
6.1 Size A 100 V/200 V	20
6.2 Size B 100 V/200 V	22
6.3 Size C 100 V/200 V	24
6.4 Size D 200 V/400 V	26
6.5 Size E 200 V/400 V	28
6.6 Size F 200 V/400 V	30
6.7 Size G 200 V/400 V	32
6.8 Size H 200 V/400 V	34
7 Configuration of Connectors and Terminal Blocks	35
7.1 Power Connectors XA, XB, XC, XD and Terminal Blocks	35
7.1.1 Size A, B 100 V/200 V	35
7.1.2 Size C, D 100 V/200 V	36
7.1.3 Size E 200 V	37
7.1.4 Size F 200 V	38
7.1.5 Size G 200 V	39
7.1.6 Size H 200 V	40
7.1.7 Size D, E 400 V	41
7.1.8 Size F 400 V	42
7.1.9 Size G 400 V	43

7.1.10	Size H 400 V	44
7.2	USB Connector X1	45
7.3	RTEX Connector X2A, X2B	45
7.4	Safety Function Connector X3	46
7.5	Parallel I/O connector X4	47
7.5.1	Input signal	47
7.5.2	Output signal	47
7.5.3	feedback output signal/position compare output signal	48
7.5.4	Other	48
7.6	Feedback scale connector X5	49
7.7	CS Signal Connector X6	50
7.8	Analog Monitor Connector X7	50
7.9	I/O Signal Interface	51
7.9.1	CS Signal Interface	52
8	Wiring and System Configuration	54
8.1	Cables Used and Maximum Cable Lengths	54
8.2	Cable Side Connectors	54
8.3	Precautions for Wiring	55
8.3.1	Wiring to Power Connectors and Terminal Blocks	55
8.3.1.1	Size A, B 100 V/200 V	55
8.3.1.2	Size C, D 100 V/200 V	56
8.3.1.3	Size E 200 V	57
8.3.1.4	Size F 200 V	58
8.3.1.5	Size G 200 V	59
8.3.1.6	Size H 200 V	61
8.3.1.7	Size D, E 400 V	63
8.3.1.8	Size F 400 V	64
8.3.1.9	Size G 400 V	65
8.3.1.10	Size H 400 V	67
8.3.1.11	Precautions	69
8.3.1.12	How to wire to the power connector	71
8.3.2	Wiring to Connector X4	72
8.3.2.1	Control input	72
8.3.2.2	Control output	73
8.3.2.3	Feedback Output Signal/Position Compare Output Signal	74
8.3.3	Wiring to Connector X5, X6	75
8.3.3.1	Wiring example for A/B phase, home position signal differential input type	76
8.3.3.2	Serial communication type wiring example	78
8.3.3.3	Wiring example with an external power supply	80
8.3.4	Wiring to Connectors X2A, X2B	82
8.3.4.1	Connection of X2A	83
8.3.4.2	Connection of X2B	83
8.3.4.3	RJ45 plug pin configuration	83
8.4	Dynamic Brake	84
8.5	Mounting Direction and Spacing	84
9	Compliance with International Standards	86
9.1	List of Compliance Standards for Servo Drivers	86
9.2	EU directives and UK regulations	87
9.2.1	Compliance with the EU EMC directive/UK EMC regulation	87
9.2.2	Compliance with EN 61800-5-1:2007/A11:2021	87
9.3	Configuration of Peripheral Devices	90
9.3.1	Installation Environment	90
9.3.2	Power Supply	92

9.3.3 Molded Case Circuit Breaker (MCCB)	92
9.3.4 Noise Filter	92
9.3.5 Surge Absorber	92
9.3.6 Ferrite Core	92
9.3.7 Grounding	92
9.4 List of Peripheral Devices Applicable to the Servo Driver	93
9.5 Compliance with UL Standards.....	95
9.6 Radio Waves Act (South Korea)	95
9.7 Compliance with the SEMI F47 Standard	96
9.8 Harmonic Suppression Measures.....	96
10 SAFETY PRECAUTIONS	97
11 Life span.....	101
11.1 Expected Life span of Servo Driver.....	101
11.2 Standard Life span	101
12 Warranty.....	102
12.1 Warranty Period	102
12.2 Warranty Coverage.....	102
12.3 Warranty Service	102
13 Network Security	103
14 Additional Precautions	104
15 Model Specifications	106
Appendix List of Default Parameters	

1 Scope of Application

This specification relates to the MINAS A6N Series for Linear motor/DD motor/VCM of AC Servo Drivers manufactured by Motion Control Business Unit, Industrial Device Business Division, Panasonic Industry Co., Ltd.

This product is intended for use as industrial equipment. It must not be used for any other purpose (e.g., for home use).

■ Related Materials

Technical Reference Document - Basic Function Specifications - : SX-DSV03181

Technical Reference Document - Realtime Express (RTEX) Communication Specifications - : SX-DSV03211

* Please refer to the Panasonic website for the above documents.

■ Precautions

- 1 Reproduction of the contents of this document in whole or in part is strictly prohibited.
- 2 Due to product improvements, this document is subject to change without notice.

■ Applicable Motor Types

This series is compatible with DD (direct drive) motors, linear motors, and voice coil motors (VCM).


Motor Type	DD (direct drive) motor	Linear motor Voice coil motor (VCM)
'Classification in This Document	Rotary type	Linear type
'Related Terms	Inertia (unit: kgm ²)	Weight (unit: kg)
	Torque (unit: Nm)	Thrust (unit: N)
	r/min	mm/s
	Rotation	Operation

The terminology used in this document is assuming the use of "rotary type".

If using "linear type", replace the terms as shown in the table above.

2 How to Read Product Numbers

Product numbers are to be read as follows:



3 Product Line-up

3.1 Basic Type

servo amplifier specification					Rated output of applicable motor			
					Rated current (Arms)			Maximum current (Arms)
Power	Product number	Size symbol	IGBT [A]	Regenerative resistor	6 kHz	8 kHz	12 kHz	
Single-phase AC 100-120 V	MADLN01NL	A	15	External	—	—	1.2	3.7
	MADLN11NL	A	15	External	—	—	1.6	5.5
	MBDLN21NL	B	15	External	2.5	2.1	—	7.4
	MCDLN31NL	C	30	Built-in	4.6	4.1	—	14.3
Single-phase or 3-phase AC 200-240 V	MADLN05NL	A	15	External	—	—	1.2	3.8
	MADLN15NL	A	15	External	—	—	1.6	4.8
	MBDLN25NL	B	15	External	2.6	2.1	—	7.3
	MCDLN35NL	C	30	Built-in	4.1	—	—	13.2
	MDDL45NL	D	30	Built-in	5.9	—	—	15.5
	MDDL55NL	D	50	Built-in	9.4	—	—	26.1
3-phase AC 200-240 V	MEDLN83NL	E	75	Built-in	13.4	—	—	37.4
	MEDLN93NL	E	100	Built-in	17	—	—	48
	MFDLNA3NL	F	150	Built-in	18.7	—	—	54.4
	MFDLNB3NL	F	150	Built-in	33	—	—	72.1

* Select and use an applicable motor so that it is below the stated rated current and maximum current.

* The standard type is not compatible with size G and size H 400 V models.

3.2 Multifunction Type

servo amplifier specification					Rated output of applicable motor			
					'Rated current (Arms)			Maximum current (Arms)
Power	Product number	Size symbol	IGBT [A]	Regenerative resistor	Carrier frequency			
					6 kHz	8 kHz	12 kHz	
Single-phase AC 100-120 V	MADLT01NM	A	15	External	—	—	1.2	3.7
	MADLT11NM	A	15	External	—	—	1.6	5.5
	MBDLT21NM	B	15	External	2.5	2.1	—	7.4
	MCDLT31NM	C	30	Built-in	4.6	4.1	—	14.3
Single-phase or 3-phase AC 200-240 V	MADLT05NM	A	15	External	—	—	1.2	3.8
	MADLT15NM	A	15	External	—	—	1.6	4.8
	MBDLT25NM	B	15	External	2.6	2.1	—	7.3
	MCDLT35NM	C	30	Built-in	4.1	—	—	13.2
	MDDLT45NM	D	30	Built-in	5.9	—	—	15.5
	MDDLT55NM	D	50	Built-in	9.4	—	—	26.1
3-phase AC 200-240 V	MEDLT83NM	E	75	Built-in	13.4	—	—	37.4
	MEDLT93NM	E	100	Built-in	17.0	—	—	48.0
	MFDLTA3NM	F	150	Built-in	18.7	—	—	54.4
	MFDLTB3NM	F	150	Built-in	33.0	—	—	72.1
3-phase 200 V	MGDLTC3NM	G	200	External	40.0	—	—	116.6
3-phase 200 V	MHDLTE3NM	H	300	External	—	66.1	—	167.2
	MHDLTF3NM	H	450	External	80.2	—	—	207.9
3-phase 400 V	MDDLT44NM	D	25	Built-in	1.5	1.2	0.8	4.5
	MDDLT54NM	D	25	Built-in	2.9	—	—	8.7
	MDDLT64NM	D	25	Built-in	4.7	—	—	14.1
	MEDLT84NM	E	35	Built-in	6.7	—	—	19.7
	MFDLTA4NM	F	50	Built-in	9.4	—	—	28.2
	MFDLTB4NM	F	75	Built-in	16.5	—	—	42.4
	MGDLTC4NM	G	100	External	20.3	—	—	58.7
	MHDLTE4NM	H	150	External	—	32.3	—	83.7
	MHDLTF4NM	H	200	External	40.1	—	—	103.9

* Select and use an applicable motor so that it is below the stated rated current and maximum current.

4 Specifications

Item				Description
Input power supply	100 V type	Main circuit power supply		Single-phase 100–120 V, -15% to +10%, 50/60 Hz
		Control circuit power supply		Single-phase 100–120 V, -15% to +10%, 50/60 Hz
	200 V type	Main circuit power supply	Sizes A–D	Single-phase/3-phase 200–240 V, -15% to +10%, 50/60 Hz
			Sizes E–H	3-phase 200–240 V, -15% to +10%, 50/60 Hz
		Control circuit power supply	Sizes A–D	Single-phase 200–240 V, -15% to +10%, 50/60 Hz
			Sizes E–H	Single-phase 200–240 V, -15% to +10%, 50/60 Hz
	400 V type	Main circuit power supply		3-phase 380Y/220-480Y/277 V, -15% to +10%, 50/60 Hz TN (ground the neutral point to earth)
		Control circuit power supply		DC 24 V, ±15 %
Ambient operating conditions		Temperature		Operating temperature: 0–55°C (no freezing) Storage temperature: -20°C to 65°C (Max. temperature guarantee: 80°C, 72 hours, no condensation ^(*))
		Humidity		Operating/storage humidity: 20–85% RH or less (no condensation ^(*))
		Elevation		1,000 m or less above sea level
		Vibration		5.88 m/s ² or less, 10–60 Hz
		Pollution degree		Pollution degree 2
Insulation voltage resistance				Withstanding AC 1,500 V between primary and ground for 1 minute
Control method				IGBT PWM method, sinusoidal drive
CS signal feedback				CS signal input (CS1, CS2, CS3); supports TTL-level input
Scale feedback				A/B phase, homing signal differential input type Panasonic supported serial communication type ^(*)
Control signal		Input		8 general inputs Select general input function based on parameters
		Output		3 general outputs Select general output function based on parameters
Analog signal		Output		2 outputs (analog monitor 1, analog monitor 2)
Pulse signal		Output		2 outputs Line driver output for encoder pulses (A/B phase signals)
Communication function		Realtime Express (RTEX)		Real-time operation command transmission, parameter setting, status monitoring, etc.
		USB		Connect to a computer for parameter setting or status monitoring, etc.
Safety terminal ^(*)				Connector for functional safetyConnector for functional safety
Front panel				(1) Rotary switch (2) 2-digit, 7-segment LED and 2 lights for status display (3) Analog monitor connector
Regeneration				Sizes A, B, G, H: No built-in regenerative resistor (external only) Sizes C–F: Built-in regenerative resistor (external also possible)
Dynamic brake				Sizes A–G: Built-in / Size H: External only

Item	Description
Control mode	Position control: Profile position control (PP), cyclic position control (CP) Velocity control: Cyclic velocity control (CV) Torque control: Cyclic torque control (CT) The above PP/CP/CV/CT are switched using RTEX communication commands

- *1 Please note that condensation tends occur when the temperature drops.
- *2 Please refer to the collaboration catalog for the corresponding scale manufacturer and part number.
- *3 Cannot be used with the basic type.


For details of each specification, refer to Technical Reference - Functional Specification -.

Feedback scale input signal specification

The A/B signal at less than or equal to the maximum output frequency 4 Mbps are available.

Please use under the following conditions.


Please note that if the duty ratio of the scale input signal waveform is not 50%, it may not be able to be read normally.



5 Appearance and Part Names

For each size, the figure is of a multifunction type. The basic type does not have X3 (connector for safety functions/safety bypass plug).


5.1 Size A, B 100 V/200 V



X1	USB connector UB-M5BR-S14-4S (LF) (SN) (JST) equivalent		
X2A	RTEX connector (RX) MOD-WRJ88LY1G-TP+ (HTK) equivalent	X2B	RTEX connector (TX) MOD-WRJ88LY1G-TP+ (HTK) equivalent
X3	Safety function connector CIF-HS08SK-071-TB (LF) equivalent	X3'	Safety bypass plug CIF-PB08AK-GF1R (JST)
X4	Parallel I/O connector DF02R026NA2 (JAE) equivalent	X5	Feedback scale connector MUF-RS10SK-GKX-TB (LF) (JST) equivalent
X6	CS signal connector 3E106-2230KV (3M) equivalent	X7	Analog monitor connector 533984005 (Molex) equivalent
XA	Power supply input connector S05B-F32SK-GGXR (JST) equivalent	XA'	Power supply input connector 05JFAT-SAXGGKK-A (JST) equivalent
XB	Motor output connector S06B-F32SK-GGXR (JST) equivalent	XB'	Motor output connector 06JFAT-SAXGGKK-A (JST) equivalent
(1)	Front panel	(2)	Charge lamp
(3)	Earth connection screw	(4)	Main power supply input
(5)	Control power supply input	(6)	Regenerative resistor connection
(7)	Motor output		

* Remove the safety bypass plug when wiring to X3.


5.2 Size C, D 100 V/200 V



X1	USB connector UB-M5BR-S14-4S (LF) (SN) (JST) equivalent		
X2A	RTEX connector (RX) MOD-WRJ88LY1G-TP+ (HTK) equivalent	X2B	RTEX connector (TX) MOD-WRJ88LY1G-TP+ (HTK) equivalent
X3	Safety function connector CIF-HS08SK-071-TB (LF) equivalent	X3'	Safety bypass plug CIF-PB08AK-GF1R (JST)
X4	Parallel I/O connector DF02R026NA2 (JAE) equivalent	X5	Feedback scale connector MUF-RS10SK-GKX-TB (LF) (JST) equivalent
X6	CS signal connector 3E106-2230KV (3M) equivalent	X7	Analog monitor connector 533984005 (Molex) equivalent
XA	Power supply input connector S05B-F32SK-GGXR (JST) equivalent	XA'	Power supply input connector 05JFAT-SAXGGKK-A (JST) equivalent
XB	Motor output connector S06B-F32SK-GGXR (JST) equivalent	XB'	Motor output connector 06JFAT-SAXGGKK-A (JST) equivalent
XC	Manufacturer use (Do not connect anything to this connector)	(1)	Front panel
(2)	Charge lamp	(3)	Earth connection screw
(4)	Main power supply input	(5)	Control power supply input
(6)	Regenerative resistor connection	(7)	Motor output

* Remove the safety bypass plug when wiring to X3.


5.3 Size E 200 V



X1	USB connector UB-M5BR-S14-4S (LF) (SN) (JST) equivalent		
X2A	RTEX connector (RX) MOD-WRJ88LY1G-TP+ (HTK) equivalent	X2B	RTEX connector (TX) MOD-WRJ88LY1G-TP+ (HTK) equivalent
X3	Safety function connector CIF-HS08SK-071-TB (LF) equivalent	X3'	Safety bypass plug CIF-PB08AK-GF1R (JST)
X4	Parallel I/O connector DF02R026NA2 (JAE) equivalent	X5	Feedback scale connector MUF-RS10SK-GKX-TB (LF) (JST) equivalent
X6	CS signal connector 3E106-2230KV (3M) equivalent	X7	Analog monitor connector 533984005 (Molex) equivalent
XA	Power supply input connector S05B-JTSLSK-GSANXR (JST) equivalent	XA'	Power supply input connector 05JFAT-SAXGSA-L (JST) equivalent
XB	Motor output connector S03B-JTSLSK-GSANXR (JST) equivalent	XB'	Motor output connector 03JFAT-SAXGSA-L (JST) equivalent
XC	Regenerative resistor connector S04B-JTSLSK-GSANXR (JST) equivalent	XC'	Regenerative resistor connector 04JFAT-SAXGSA-L (JST) equivalent
(1)	Front panel	(2)	Charge lamp
(3)	Earth connection screw	(4)	Main power supply input
(5)	Control power supply input	(6)	Regenerative resistor connection
(7)	Motor output		

* Remove the safety bypass plug when wiring to X3.


5.4 Size F 200 V



X1	USB connector UB-M5BR-S14-4S (LF) (SN) (JST) equivalent		
X2A	RTEX connector (RX) MOD-WRJ88LY1G-TP+ (HTK) equivalent	X2B	RTEX connector (TX) MOD-WRJ88LY1G-TP+ (HTK) equivalent
X3	Safety function connector CIF-HS08SK-071-TB (LF) equivalent	X3'	Safety bypass plug CIF-PB08AK-GF1R (JST)
X4	Parallel I/O connector DF02R026NA2 (JAE) equivalent	X5	Feedback scale connector MUF-RS10SK-GKX-TB (LF) (JST) equivalent
X6	CS signal connector 3E106-2230KV (3M) equivalent	X7	Analog monitor connector 533984005 (Molex) equivalent
(1)	Front panel	(2)	Charge lamp
(3)	Earth connection screw	(4)	Main power supply input
(5)	Control power supply input	(6)	Regenerative resistor connection (Normal RB-B short circuit)
(7)	Motor output		

* Remove the safety bypass plug when wiring to X3.


5.5 Size G 200 V



X1	USB connector UB-M5BR-S14-4S (LF) (SN) (JST) equivalent	XE	External DB control connector 5569-04A2-210 (MOLEX) equivalent
X2A	RTEX connector (RX) MOD-WRJ88LY1G-TP+ (HTK) equivalent	X2B	RTEX connector (TX) MOD-WRJ88LY-TP+ (HTK) equivalent
X3	Safety function connector CIF-HS08SK-071-TB (LF) equivalent	X3'	Safety bypass plug CIF-PB08AK-GF1R (JST)
X4	Parallel I/O connector DF02R050NA2 (JAE) equivalent	X5	Feedback scale connector MUF-RS10SK-GKX-TB (LF) (JST) equivalent
X6	CS signal connector 3E106-2230KV (3M) equivalent	X7	Analog monitor connector 533984005 (Molex) equivalent
XS	Internal DB switch	(1)	Front panel
(2)	Charge lamp	(3)	Earth connection screw
(4)	Control power supply input	(5)	Main power supply input
(6)	Regenerative resistor connection	(7)	Motor output

* Remove the safety bypass plug when wiring to X3.


5.6 Size H 200 V



X1	USB connector UB-M5BR-S14-4S (LF) (SN) (JST) equivalent		
X2A	RTEX connector (RX) MOD-WRJ88LY1G-TP+ (HTK) equivalent	X2B	RTEX connector (TX) MOD-WRJ88LY1G-TP+ (HTK) equivalent
X3	Safety function connector CIF-HS08SK-071-TB (LF) equivalent	X3'	Safety bypass plug CIF-PB08AK-GF1R (JST)
X4	Parallel I/O connector DF02R050NA2 (JAE) equivalent	X5	Feedback scale connector MUF-RS10SK-GKX-TB (LF) (JST) equivalent
X6	CS signal connector 3E106-2230KV (3M) equivalent	X7	Analog monitor connector 533984005 (Molex) equivalent
(1)	Front panel	(2)	Charge lamp
(3)	Earth connection screw	(4)	Control power supply input
(5)	External DB control connection	(6)	Main power supply input
(7)	Regenerative resistor connection	(8)	Motor output

* Remove the safety bypass plug when wiring to X3.


5.7 Size D 400 V



X1	USB connector UB-M5BR-S14-4S (LF) (SN) (JST) equivalent		
X2A	RTEX connector (RX) MOD-WRJ88LY1G-TP+ (HTK) equivalent	X2B	RTEX connector (TX) MOD-WRJ88LY1G-TP+ (HTK) equivalent
X3	Safety function connector CIF-HS08SK-071-TB (LF) equivalent	X3'	Safety bypass plug CIF-PB08AK-GF1R (JST)
X4	Parallel I/O connector DF02R026NA2 (JAE) equivalent	X5	Feedback scale connector MUF-RS10SK-GKX-TB (LF) (JST) equivalent
X6	CS signal connector 3E106-2230KV (3M) equivalent	X7	Analog monitor connector 533984005 (Molex) equivalent
XA	Power supply input connector S03B-JTSLSS-GSANYR (JST) equivalent	XA'	Power supply input connector 03JFAT-SAYGSA-L (JST) equivalent
XB	Motor output connector S03B-JTSLSK-GSANXR (JST) equivalent	XB'	Motor output connector 03JFAT-SAXGSA-L (JST) equivalent
XC	Regenerative resistor connector S04B-JTSLSK-GSANXR (JST) equivalent	XC'	Regenerative resistor connector 04JFAT-SAXGSA-L (JST) equivalent
XD	Control power supply Input connector S02B-J25SK-GGR (JST) equivalent	XD'	Control power supply Input connector 02MJFAT-SAGF (JST) equivalent
(1)	Front panel	(2)	Charge lamp
(3)	Earth connection screw	(4)	Control power supply input
(5)	Main power supply input	(6)	Regenerative resistor connection
(7)	Motor output		

* Remove the safety bypass plug when wiring to X3.


5.8 Size E 400 V



X1	USB connector UB-M5BR-S14-4S (LF) (SN) (JST) equivalent		
X2A	RTEX connector (RX) MOD-WRJ88LY1G-TP+ (HTK) equivalent	X2B	RTEX connector (TX) MOD-WRJ88LY1G-TP+ (HTK) equivalent
X3	Safety function connector CIF-HS08SK-071-TB (LF) equivalent	X3'	Safety bypass plug CIF-PB08AK-GF1R (JST)
X4	Parallel I/O connector DF02R026NA2 (JAE) equivalent	X5	Feedback scale connector MUF-RS10SK-GKX-TB (LF) (JST) equivalent
X6	CS signal connector 3E106-2230KV (3M) equivalent	X7	Analog monitor connector 533984005 (Molex) equivalent
XA	Power supply input connector S03B-JTSLSS-GSANYR (JST) equivalent	XA'	Power supply input connector 03JFAT-SAYGSA-L (JST) equivalent
XB	Motor output connector S03B-JTSLSK-GSANXR (JST) equivalent	XB'	Motor output connector 03JFAT-SAXGSA-L (JST) equivalent
XC	Regenerative resistor connector S04B-JTSLSK-GSANXR (JST) equivalent	XC'	Regenerative resistor connector 04JFAT-SAXGSA-L (JST) equivalent
XD	Control power supply Input connector S02B-J25SK-GGR (JST) equivalent	XD'	Control power supply Input connector 02MJFAT-SAGF (JST) equivalent
(1)	Front panel	(2)	Charge lamp
(3)	Earth connection screw	(4)	Control power supply input
(5)	Main power supply input	(6)	Regenerative resistor connection
(7)	Motor output		

* Remove the safety bypass plug when wiring to X3.


5.9 Size F 400 V



X1	USB connector UB-M5BR-S14-4S (LF) (SN) (JST) equivalent		
X2A	RTEX connector (RX) MOD-WRJ88LY1G-TP+ (HTK) equivalent	X2B	RTEX connector (TX) MOD-WRJ88LY1G-TP+ (HTK) equivalent
X3	Safety function connector CIF-HS08SK-071-TB (LF) equivalent	X3'	Safety bypass plug CIF-PB08AK-GF1R (JST)
X4	Parallel I/O connector DF02R026NA2 (JAE) equivalent	X5	Feedback scale connector MUF-RS10SK-GKX-TB (LF) (JST) equivalent
X6	CS signal connector 3E106-2230KV (3M) equivalent	X7	Analog monitor connector 533984005 (Molex) equivalent
XD	Control power supply Input connector S02B-J25SK-GGR (JST) equivalent	XD'	Control power supply Input connector 02MJFAT-SAGF (JST) equivalent
(1)	Front panel	(2)	Charge lamp
(3)	Earth connection screw	(4)	Control power supply input
(5)	Main power supply input	(6)	Regenerative resistor connection (Normal RB-B short circuit)
(7)	Motor output		

* Remove the safety bypass plug when wiring to X3.


5.10 Size G 400 V



X1	USB connector UB-M5BR-S14-4S (LF) (SN) (JST) equivalent	XE	External DB control connector 5569-04A2-210 (MOLEX) equivalent
X2A	RTEX connector (RX) MOD-WRJ88LY1G-TP+ (HTK) equivalent	X2B	RTEX connector (TX) MOD-WRJ88LY-TP+ (HTK) equivalent
X3	Safety function connector CIF-HS08SK-071-TB (LF) equivalent	X3'	Safety bypass plug CIF-PB08AK-GF1R (JST)
X4	Parallel I/O connector DF02R050NA2 (JAE) equivalent	X5	Feedback scale connector MUF-RS10SK-GKX-TB (LF) (JST) equivalent
X6	CS signal connector 3E106-2230KV (3M) equivalent	X7	Analog monitor connector 533984005 (Molex) equivalent
XD	Control power supply Input connector SR02B-J25SK-GGR (JST) equivalent	XD'	Control power supply Input connector 02MJFAT-SAGF (JST) equivalent
XS	Internal DB switch	(1)	Front panel
(2)	Charge lamp	(3)	Earth connection screw
(4)	Control power supply input	(5)	Main power supply input
(6)	Regenerative resistor connection	(7)	Motor output

* Remove the safety bypass plug when wiring to X3.


5.11 Size H 400 V



X1	USB connector UB-M5BR-S14-4S (LF) (SN) (JST) equivalent		
X2A	RTEX connector (RX) MOD-WRJ88LY1G-TP+ (HTK) equivalent	X2B	RTEX connector (TX) MOD-WRJ88LY1G-TP+ (HTK) equivalent
X3	Safety function connector CIF-HS08SK-071-TB (LF) equivalent	X3'	Safety bypass plug CIF-PB08AK-GF1R (JST)
X4	Parallel I/O connector DF02R050NA2 (JAE) equivalent	X5	Feedback scale connector MUF-RS10SK-GKX-TB (LF) (JST) equivalent
X6	CS signal connector 3E106-2230KV (3M) equivalent	X7	Analog monitor connector 533984005 (Molex) equivalent
(1)	Front panel	(2)	Charge lamp
(3)	Earth connection screw	(4)	Control power supply input
(5)	External DB control connection	(6)	Main power supply input
(7)	Regenerative resistor connection	(8)	Motor output

* Remove the safety bypass plug when wiring to X3.

5.12 Example nameplate




Although serial numbers range from 1 to 33999, they are shown on the name plate in 4-digit format shown as shown below.

The letters “I” and “O” are not used for the fourth digit.

Value of serial number	Notation on the nameplate
1 – 9999	0001 – 9999
10000 – 10999	A000 – A999
11000 – 11999	B000 – B999
⋮	⋮
17000 – 17999	H000 – H999
18000 – 18999	J000 – J999
⋮	⋮
22000 – 22999	N000 – N999
23000 – 23999	P000 – P999
⋮	⋮
33000 – 33999	Z000 – Z999

5.13 Front panel




6 Dimensions

Each size has the same external dimensions for the basic and multifunction types (figures show the multifunction type).


Some dimensions for the 400 V model are different (see note).

6.1 Size A 100 V/200 V

Base-mounted installation (Standard: Rear-mounted)



*1 Do not use screw holes for which no dimensions are shown.


Rack-mounted installation (Using optional parts: Front-mounted)

*1 Do not use screw holes for which no dimensions are shown.


*2 Mounting brackets are optional parts. They are not included with the product.

6.2 Size B 100 V/200 V

Base-mounted installation (Standard: Rear-mounted)




*1 Do not use screw holes for which no dimensions are shown.

Rack-mounted installation (Using optional parts: Front-mounted)

*1 Do not use screw holes for which no dimensions are shown.

*2 Mounting brackets are optional parts. They are not included with the product.


Rack-mounted installation (Using optional parts: Front-mounted)

*1 Do not use screw holes for which no dimensions are shown.

*2 Mounting brackets are optional parts. They are not included with the product.

6.4 Size D 200 V/400 V


Base-mounted installation (Standard: Rear-mounted)



*1 For the 400 V model, this dimension is 188 mm.

*2 Do not use screw holes for which no dimensions are shown.

Rack-mounted installation (Using optional parts: Front-mounted)




*1 For the 400 V model, this dimension is 37 mm.

*2 Do not use screw holes for which no dimensions are shown.

*3 Mounting brackets are optional parts. They are not included with the product.


6.5 Size E 200 V/400 V

Rack-mounting installation (Standard mounting bracket position: Front-mounted)



*1 Do not use screw holes for which no dimensions are shown.

*2 When installing the servo driver, secure it in the four U-shaped notches on the mounting bracket.


Base-mounted installation (Modified mounting bracket position: Rear-mounted)

*1 Do not use screw holes for which no dimensions are shown.

*2 サ When installing the servo driver, secure it in the four U-shaped notches on the mounting bracket.

6.6 Size F 200 V/400 V

Rack-mounting installation (Standard mounting bracket position: Front-mounted)




*1 Do not use screw holes for which no dimensions are shown.

*2 When installing the servo driver, secure it in the four U-shaped notches on the mounting bracket.


6.7 Size G 200 V/400 V

Rack-mounting installation (Standard mounting bracket position: Front-mounted)



*1 Do not use screw holes for which no dimensions are shown.

*2 When installing the servo driver, secure it in the four U-shaped notches on the mounting bracket.

Base-mounted installation (Modified mounting bracket position: Rear-mounted)


Unit: mm

*1 Do not use screw holes for which no dimensions are shown.

*2 When installing the servo driver, secure it in the four U-shaped notches on the mounting bracket.

6.8 Size H 200 V/400 V

Base-mounted installation (Rear-mounted)





*1 Do not use screw holes for which no dimensions are shown.

7 Configuration of Connectors and Terminal Blocks



7.1 Power Connectors XA, XB, XC, XD and Terminal Blocks

7.1.1 Size A, B 100 V/200 V

	Pin No.	Symbol	Name	Description	
XA	5	L1	Main power supply input terminal	100 V	Single-phase 100–120 V, -15% to +10%, 50/60 Hz Connect to terminals L1 and L3.
	4	L2			
	3	L3		200 V	Single-phase/3-phase 200–240 V, -15% to +10%, 50/60 Hz For single-phase, connect to terminals L1 and L3.
	2	L1C	Control power supply input terminal	100 V	Single-phase 100–120 V, -15% to +10%, 50/60 Hz
	1	L2C		200 V	Single-phase 200–240 V, -15% to +10%, 50/60 Hz
XB	6	P	Regenerative resistor connection terminal	<ul style="list-style-type: none"> When using an external regenerative resistor (customer-supplied), connect the external regenerative resistor between P and B. In addition, parameters must be used for regenerative resistor settings. For details, refer to “Technical Reference - Functional Specification”. Do not connect anything to the N terminal. 	
	5	N			
	4	B			
	3	U	Motor output terminal	<ul style="list-style-type: none"> Connect each phase of the motor winding. U: U phase, V: V phase, W: W phase Connect the following when using the voice coil motor. U: U-phase, W: W-phase Do not connect anything for V-phase. For details, refer to “Technical Reference - Functional Specification”. 	
	2	V			
	1	W			
			Ground terminal	<ul style="list-style-type: none"> Connect with the motor E terminal to ground to earth. 	



* Tighten the M4 grounding screw to a torque of 1.0–1.2 N·m.

7.1.2 Size C, D 100 V/200 V

	Pin No.	Symbol	Name	Description	
XA	5	L1	Main power supply input terminal	100 V	Single-phase 100–120 V, -15% to +10%, 50/60 Hz Connect to terminals L1 and L3.
	4	L2			
	3	L3		200 V	Single-phase/3-phase 200–240 V, -15% to +10%, 50/60 Hz For single-phase, connect to terminals L1 and L3.
	2	L1C	Control power supply input terminal	100 V	Single-phase 100–120 V, -15% to +10%, 50/60 Hz
	1	L2C		200 V	Single-phase 200–240 V, -15% to +10%, 50/60 Hz
XC	4	N	—	● Do not connect anything to this connector.	
	3				
	2	P			
	1				
XB	6	P	Regenerative resistor connection terminal	● Normally, short circuit between RB and B. ● When using an external regenerative resistor (customer-supplied), open between RB and B and connect the external regenerative resistor between P and B. In addition, parameters must be used for regenerative resistor settings. For details, refer to “Technical Reference - Functional Specification”.	
	5	RB			
	4	B			
	3	U	Motor output terminal	● Connect each phase of the motor winding. U: U phase, V: V phase, W: W phase ● Connect the following when using the voice coil motor. U: U-phase, W: W-phase Do not connect anything for V-phase. For details, refer to “Technical Reference - Functional Specification”.	
	2	V			
	1	W			
			Ground terminal	● Connect with the motor E terminal to ground to earth.	

* Tighten the M4 grounding screw to a torque of 1.0–1.2 N·m.



7.1.3 Size E 200 V

	Pin No.	Symbol	Name	Description	
XA	5	L1	Main power supply input terminal	200 V	3-phase 200–240 V, -15% to +10%, 50/60 Hz
	4	L2			
	3	L3			
	2	L1C	Control power supply input terminal	200 V	Single-phase 200–240 V, -15% to +10%, 50/60 Hz
	1	L2C			
XC	4	P	Regenerative resistor connection terminal	<ul style="list-style-type: none">• Normally, short circuit between RB and B.• When using an external regenerative resistor (customer-supplied), open between RB and B and connect the external regenerative resistor between P and B. In addition, parameters must be used for regenerative resistor settings. For details, refer to “Technical Reference - Functional Specification”. <ul style="list-style-type: none">• Do not connect anything to the N terminal.	
	3	RB			
	2	B			
	1	N			
XB	3	U	Motor output terminal	<ul style="list-style-type: none">• Connect each phase of the motor winding. U: U phase, V: V phase, W: W phase• Connect the following when using the voice coil motor. U: U-phase, W: W-phase Do not connect anything for V-phase. For details, refer to “Technical Reference - Functional Specification”.	
	2	V			
	1	W			
			Ground terminal	<ul style="list-style-type: none">• Connect with the motor E terminal to ground to earth.	

* Tighten the M4 grounding screw to a torque of 1.0–1.2 N·m.

7.1.4 Size F 200 V



Use terminal blocks.

	Terminal block No. (Upper to lower)	Symbol	Name	Description
Terminal block	1	L1	Main power supply input terminal	3-phase 200–240 V, -15% to +10%, 50/60 Hz
	2	L2		
	3	L3		
	4	L1C	Control power supply input terminal	Single-phase 200–240 V, -15% to +10%, 50/60 Hz
	5	L2C		
	6	P	Regenerative resistor connection terminal	<ul style="list-style-type: none"> Normally, short circuit between RB and B. When using an external regenerative resistor (customer-supplied), open between RB and B and connect the external regenerative resistor between P and B. <p>In addition, parameters must be used for regenerative resistor settings.</p> <p>For details, refer to “Technical Reference - Functional Specification”.</p> <ul style="list-style-type: none"> Do not connect anything to the N terminal.
	7	RB		
	8	B		
	9	N	Motor output terminal	<ul style="list-style-type: none"> Connect each phase of the motor winding. U: U phase, V: V phase, W: W phase Connect the following when using the voice coil motor. U: U-phase, W: W-phase <p>Do not connect anything for V-phase.</p> <p>For details, refer to “Technical Reference - Functional Specification”.</p>
	10	U		
	11	V		
	12	W		
			Ground terminal	<ul style="list-style-type: none"> Connect with the motor E terminal to ground to earth.

- * Tighten the M5 grounding screw to a torque of 1.8–2.0 N·m.
- * Tighten the M5 terminal block screw to a torque of 1.8–2.0 N·m.
- * Tighten the M3 screw for securing the terminal block cover to a torque of 0.19–0.21 N·m.
- * Exceeding the maximum tightening torque may cause damage.

7.1.5 Size G 200 V

Use terminal blocks.

	Terminal block No. (Upper to lower)	Symbol	Name	Description
Upper	1	L1C	Control power supply input terminal	Single-phase 200–240 V, -15% to +10%, 50/60 Hz
	2	L2C		
Lower	1	L1	Main power supply input terminal	3-phase 200–240 V, -15% to +10%, 50/60 Hz
	2	L2		
	3	L3		
	4	P	Regenerative resistor connection terminal	<ul style="list-style-type: none"> When using an external regenerative resistor (customer-supplied), connect the external regenerative resistor between P and B. In addition, parameters must be used for regenerative resistor settings. For details, refer to “Technical Reference - Functional Specification”. Do not connect anything to the N terminal.
	5	B		
	6	N		
	7	U	Motor output terminal	<ul style="list-style-type: none"> Connect each phase of the motor winding. U: U phase, V: V phase, W: W phase Connect the following when using the voice coil motor. U: U-phase, W: W-phase. Do not connect anything for V-phase. For details, refer to “Technical Reference - Functional Specification”.
	8	V		
	9	W		
			Ground terminal	<ul style="list-style-type: none"> Connect with the motor E terminal to ground to earth.



Connector

	Pin No.	Symbol	Name	Description
XE	1	DB1	External dynamic brake control terminal	<ul style="list-style-type: none"> This terminal is used to control electromagnetic contactor MC for the external dynamic brake resistor (customer-supplied). Connect if necessary. The applied voltage between DB1 and DB2 should be less than AC 300 V and DC 100 V.
	2	DB2		

- * Tighten the M5 grounding screw to a torque of 1.8–2.0 N·m.
- * Tighten the M3 terminal block (control power supply) screw to a torque of 0.4–0.6 N·m.
Exceeding the maximum tightening torque may damage the terminal block.
- * Tighten the M5 terminal block (main power supply, regenerative resistor, motor) screw to a torque of 2.0–2.4 N·m.
Exceeding the maximum tightening torque may damage the terminal block.
- * Tighten the M3 screw for securing the terminal block cover to a torque of 0.19–0.21 N·m.
Exceeding the maximum tightening torque may cause damage.



7.1.6 Size H 200 V

Use terminal blocks.

	Terminal block No. (From the left)	Symbol	Name	Description
Upper	1	L1C	Control power supply input terminal	Single-phase 200–240 V, -15% to +10%, 50/60 Hz
	2	L2C		
	3	DB1	Dynamic brake resistor connection terminal	<ul style="list-style-type: none"> This terminal is used to control electromagnetic contactor MC for the external dynamic brake resistor (customer-supplied). Connect if necessary. The applied voltage between DB1 and DB2 should be less than AC 300 V and DC 100 V.
	4	DB2		
Lower	1	L1	Main power supply input terminal	3-phase 200–240 V, -15% to +10%, 50/60 Hz
	2	L2		
	3	L3		
	4	P	Regenerative resistor connection terminal	<ul style="list-style-type: none"> When using an external regenerative resistor (customer-supplied), connect the external regenerative resistor between P and B. In addition, parameters must be used for regenerative resistor settings. For details, refer to “Technical Reference - Functional Specification”. Do not connect anything to the N terminal.
	5	B		
	6	N		
	7	U	Motor connection terminal	<ul style="list-style-type: none"> Connect each phase of the motor winding. U: U phase, V: V phase, W: W phase Connect the following when using the voice coil motor. U: U-phase, W: W-phase. Do not connect anything for V-phase. For details, refer to “Technical Reference - Functional Specification”.
	8	V		
	9	W		
			Ground terminal	<ul style="list-style-type: none"> Connect with the motor E terminal to ground to earth.

- * Tighten the M6 grounding screw to a torque of 2.4–2.6 N·m.
- * Tighten the M4 terminal block (upper: control power supply, dynamic brake) screw to a torque of 0.7–1.0 N·m. Exceeding the maximum tightening torque may damage the terminal block.
- * Tighten the M6 terminal block (lower: main power supply, regenerative resistor, motor) screw to a torque of 2.2–2.5 N·m. Exceeding the maximum tightening torque may damage the terminal block.
- * Tighten the M3 screw for securing terminal block cover 1 (transparent) to a torque of 0.19–0.21 N·m.
- * Tighten the M5 screw for securing terminal block cover 2 (black) to a torque of 2.0–2.5 N·m.



7.1.7 Size D, E 400 V

	Pin No.	Symbol	Name	Description
XD	1	24V	Control power supply input terminal	DC 24 V, $\pm 15\%$
	2	0V		
XA	3	L1	Main power supply input terminal	3-phase 380Y/220-480Y/277 V, -15% to +10%, 50/60 Hz TN (ground the neutral point to earth)
	2	L2		
	1	L3		
XC	4	P	Regenerative resistor connection terminal	<ul style="list-style-type: none"> Normally, short circuit between RB and B. When using an external regenerative resistor (customer-supplied), open between RB and B and connect the external regenerative resistor between P and B. <p>In addition, parameters must be used for regenerative resistor settings.</p> <p>For details, refer to "Technical Reference - Functional Specification".</p> <ul style="list-style-type: none"> Do not connect anything to the N terminal.
	3	RB		
	2	B		
	1	N		
XB	3	U	Motor output terminal	<ul style="list-style-type: none"> Connect each phase of the motor winding. U: U phase, V: V phase, W: W phase Connect the following when using the voice coil motor. U: U-phase, W: W-phase <p>Do not connect anything for V-phase.</p> <p>For details, refer to "Technical Reference - Functional Specification".</p>
	2	V		
	1	W		
			Ground terminal	<ul style="list-style-type: none"> Connect with the motor E terminal to ground to earth.

* Tighten the M4 grounding screw to a torque of 1.0–1.2 N·m.

7.1.8 Size F 400 V

Use terminal blocks.

	Terminal block No. (Upper to lower)	Symbol	Name	Description
Terminal block	1	—	Free terminals	
	2	—		
	3	L1	Main power supply input terminal	3-phase 380Y/220-480Y/277 V, -15% to +10%, 50/60 Hz TN (ground the neutral point to earth)
	4	L2		
	5	L3		
	6	P	Regenerative resistor connection terminal	<ul style="list-style-type: none"> Normally, short circuit between RB and B. When using an external regenerative resistor (customer-supplied), open between RB and B and connect the external regenerative resistor between P and B. In addition, parameters must be used for regenerative resistor settings. For details, refer to "Technical Reference - Functional Specification".
	7	RB		
	8	B		
	9	N	Motor output terminal	<ul style="list-style-type: none"> Do not connect anything to the N terminal.
	10	U		
	11	V		
	12	W		
			Ground terminal	<ul style="list-style-type: none"> Connect with the motor E terminal to ground to earth.



Connector

	Pin No.	Symbol	Name	Description
XD	1	24V	Control power supply input terminal	DC 24 V, $\pm 15\%$
	2	0V		

- * Tighten the M5 grounding screw to a torque of 1.8–2.0 N·m.
- * Tighten the M5 terminal block screw to a torque of 1.8–2.0 N·m.
- * Tighten the M3 screw for securing the terminal block cover to a torque of 0.19–0.21 N·m.
- * Exceeding the maximum tightening torque may cause damage.

7.1.9 Size G 400 V

Use terminal blocks.

	Terminal block No. (Upper to lower)	Symbol	Name	Description
Upper	1	NC	Free terminals	
	2	NC		
Lower	1	L1	Main power supply input terminal	3-phase 380Y/220-480Y/277 V, -15%~+10%, 50/60 Hz TN (ground the neutral point to earth)
	2	L2		
	3	L3		
	4	P	Regenerative resistor connection terminal	<ul style="list-style-type: none"> When using an external regenerative resistor (customer-supplied), connect the external regenerative resistor between P and B. In addition, parameters must be used for regenerative resistor settings. For details, refer to "Technical Reference - Functional Specification". Do not connect anything to the N terminal.
	5	B		
	6	N		
	7	U	Motor output terminal	<ul style="list-style-type: none"> Connect each phase of the motor winding. U: U phase, V: V phase, W: W phase
	8	V		
	9	W		
			Ground terminal	<ul style="list-style-type: none"> Connect with the motor E terminal to ground to earth.



Connector

	Pin No.	Symbol	Name	Description
XD	1	24V	Control power supply Input connector	DC 24 V, $\pm 15\%$
	2	0V		
XE	1	DB1	External dynamic brake control terminal	<ul style="list-style-type: none"> This terminal is used to control electromagnetic contactor MC for the external dynamic brake resistor (customer-supplied). Connect if necessary. The applied voltage between DB1 and DB2 should be less than AC 300 V and DC 100 V.
	2	DB2		

- * Tighten the M5 grounding screw to a torque of 1.8–2.0 N·m.
- * Tighten the M3 terminal block (control power supply) screw to a torque of 0.4–0.6 N·m.
Exceeding the maximum tightening torque may damage the terminal block.
- * Tighten the M5 terminal block (main power supply, regenerative resistor, motor) screw to a torque of 2.0–2.4 N·m.
Exceeding the maximum tightening torque may damage the terminal block.
- * Tighten the M3 screw for securing the terminal block cover to a torque of 0.19–0.21 N·m.
Exceeding the maximum tightening torque may cause damage.

7.1.10 Size H 400 V

Use terminal blocks.

	Terminal block No. (Upper to lower)	Symbol	Name	Description
Upper	1	24V	Control power supply input terminal	DC 24 V, $\pm 15\%$
	2	0V		
	3	DB1	Dynamic brake resistor connection terminal	<ul style="list-style-type: none"> This terminal is used to control electromagnetic contactor MC for the external dynamic brake resistor (customer-supplied). Connect if necessary. The applied voltage between DB1 and DB2 should be less than AC 300 V and DC 100 V.
	4	DB2		
Lower	1	L1	Main power supply input terminal	3-phase 380Y/220-480Y/277 V, $-15\% \sim +10\%$, 50/60 Hz TN (ground the neutral point to earth)
	2	L2		
	3	L3		
	4	P	Regenerative resistor connection terminal	<ul style="list-style-type: none"> When using an external regenerative resistor (customer-supplied), connect the external regenerative resistor between P and B. In addition, parameters must be used for regenerative resistor settings. For details, refer to "Technical Reference - Functional Specification". Do not connect anything to the N terminal.
	5	B		
	6	N		
	7	U	Motor connection terminal	<ul style="list-style-type: none"> Connect each phase of the motor winding. U: U phase, V: V phase, W: W phase
	8	V		
	9	W		
			Ground terminal	<ul style="list-style-type: none"> Connect with the motor E terminal to ground to earth.

- * Tighten the M6 grounding screw to a torque of 2.4–2.6 N·m.
- * Tighten the M4 terminal block (upper: control power supply, dynamic brake) screw to a torque of 0.7–1.0 N·m. Exceeding the maximum tightening torque may damage the terminal block.
- * Tighten the M6 terminal block (lower: main power supply, regenerative resistor, motor) screw to a torque of 2.2–2.5 N·m. Exceeding the maximum tightening torque may damage the terminal block.
- * Tighten the M3 screw for securing terminal block cover 1 (transparent) to a torque of 0.19–0.21 N·m.
- * Tighten the M5 screw for securing terminal block cover 2 (black) to a torque of 2.0–2.5 N·m.

7.2 USB Connector X1

By connecting to computer or NC controller via the USB interface, it is possible to set/change parameters, monitor control status, view error status/history, save/load parameters, etc.

Name	Symbol	Pin No.	Description
USB signal connector	VBUS	1	<ul style="list-style-type: none"> Used for communication with computers or NC controllers.
	D-	2	
	D+	3	
For manufacturer use	—	4	<ul style="list-style-type: none"> Do not connect anything
Signal ground	GND	5	<ul style="list-style-type: none"> Signal ground

The connector type on the servo driver side is USB mini-B.

7.3 RTEX Connector X2A, X2B

This is an RJ45 connector for use with RTEX.

[X2A] RX connector

Name	Symbol	Pin No.	Description
Not used	—	1	<ul style="list-style-type: none"> Connect to pin 1 of the TX connector of the transmitting node
Not used	—	2	<ul style="list-style-type: none"> Connect to pin 2 of the TX connector of the transmitting node
Network input +	RX+	3	<ul style="list-style-type: none"> Connect to pin 3 of the TX connector of the transmitting node
Not used	—	4	<ul style="list-style-type: none"> Connect to pin 4 of the TX connector of the transmitting node
Not used	—	5	<ul style="list-style-type: none"> Connect to pin 5 of the TX connector of the transmitting node
Network input -	RX-	6	<ul style="list-style-type: none"> Connect to pin 6 of the TX connector of the transmitting node
Not used	—	7	<ul style="list-style-type: none"> Connect to pin 7 of the TX connector of the transmitting node
Not used	—	8	<ul style="list-style-type: none"> Connect to pin 8 of the TX connector of the transmitting node
Frame ground	FG	Shell	<ul style="list-style-type: none"> Connect to the cable shield

[X2B] TX connector

Name	Symbol	Pin No.	Description
Not used	—	1	<ul style="list-style-type: none"> Connect to pin 1 of the RX connector of the receiving node
Not used	—	2	<ul style="list-style-type: none"> Connect to pin 2 of the RX connector of the receiving node
Network output +	TX+	3	<ul style="list-style-type: none"> Connect to pin 3 of the RX connector of the receiving node
Not used	—	4	<ul style="list-style-type: none"> Connect to pin 4 of the RX connector of the receiving node
Not used	—	5	<ul style="list-style-type: none"> Connect to pin 5 of the RX connector of the receiving node
Network output -	TX-	6	<ul style="list-style-type: none"> Connect to pin 6 of the RX connector of the receiving node
Not used	—	7	<ul style="list-style-type: none"> Connect to pin 7 of the RX connector of the receiving node
Not used	—	8	<ul style="list-style-type: none"> Connect to pin 8 of the RX connector of the receiving node
Frame ground	FG	Shell	<ul style="list-style-type: none"> Connect to the cable shield

- Make sure to use shielded twisted pair (STP) cables of Category 5e or higher in the TIA/EIA-568 standard.

7.4 Safety Function Connector X3

This is a connector for functional safety.

This connector is only compatible with the multifunction type.

Name	Symbol	Pin No.	Description	I/O signal interface
Reserved	—	1	• Do not connect anything	—
	—	2		—
Safety input 1	SF1-	3	• Two independent circuits turn off the drive signal to the power module and cut off the motor current.	i-1
	SF1+	4		
Safety input 2	SF2-	5		
	SF2+	6		
EDM output	EDM-	7	• Monitor output for monitoring safety function faults.	o-1
	EDM+	8		
Frame ground	FG	Shell	• Connected to the ground terminal inside the servo driver.	—

In order to set the safety levels to SIL 3, PL e, DCavg Medium, diagnosis via EDM output is required (max. 3-month diagnostic interval).

Safety levels are SIL 2, PL d, DCavg Low when diagnosis by EDM output is not performed.

7.5 Parallel I/O connector X4

7.5.1 Input signal

Name	Symbol	Pin No.	Description	I/O signal interface
General input common	SI-COM	6	<ul style="list-style-type: none"> Connect the positive or negative poles of the external DC power supply (12–24 V). Use a power supply of 12 V\pm5% – 24 V\pm5%. This must be isolated from the primary power supply. Do not connect it to the same power supply. Primary power supply: Power supply for motor brake	—
General input 1	SI1	5	<ul style="list-style-type: none"> Functions are assigned using parameters. For details, refer to “Technical Reference - Functional Specification”. Be aware that there are restrictions on the assignment of functions. For example, in the case of external latch inputs, EXT1 can only be assigned to SI5, EXT2 to SI6, and EXT3 to SI7. 	i-1
General input 2	SI2	7		
General input 3	SI3	8		
General input 4	SI4	9		
General input 5	SI5	10		
General input 6	SI6	11		
General input 7	SI7	12		
General input 8	SI8	13		

7.5.2 Output signal

Name	Symbol	Pin No.	Description	I/O signal interface
General output 1	SO1+ SO1-	1 2	<ul style="list-style-type: none"> Functions are assigned using parameters. For details, refer to “Technical Reference - Functional Specification”. 	o-1
General output 2	SO2+ SO2-	25 26		
General output 4	SO3+ SO3-	3 4		

7.5.3 feedback output signal/position compare output signal

Name	Symbol	Pin No.	Description	I/O signal interface
A-phase output/ position compare output 1	OA+/ OCMP1+	17	<ul style="list-style-type: none"> Differential output of divided feedback scale signal (A/B phase). (RS422 compatible) The division ratio can be set by the parameters. The ground of the line driver for the output circuit is connected to the signal ground (GND), and kept non-insulated. Maximum output frequency is 4 Mpps (after being multiplied by 4). It can be used as position compare output by setting parameters. For details, refer to "Technical Reference - Functional Specification". This differential signal should be received by a line receiver (AM26C32 or equivalent), and a terminating resistor (approx. 330 Ω) should be connected between the line receiver inputs. Use shielded twisted-pair cables for wiring, and connect the shielded wires to the connector shell. 	Do-1
	OA-/ OCMP1-	18		
B-phase output/ position compare output 2	OB+/ OCMP2+	20		
	OB-/ OCMP2-	19		
Position compare output 3	OCMP3+	21		
	OCMP3-	22		
Signal ground	GND	16	<ul style="list-style-type: none"> Signal ground. Always connect the line receiver ground to this terminal. 	—

7.5.4 Other

Name	Symbol	Pin No.	Description	I/O signal interface
Reserved	—	14 15 23 24	<ul style="list-style-type: none"> Do not connect anything. 	—
Frame ground	FG	Shell	<ul style="list-style-type: none"> Connected to the ground terminal inside the servo driver. 	—

7.6 Feedback scale connector X5

Name	Symbol	Pin No.	Description
Power supply output for feedback scale	EX5V	1	• Feedback scale power supply output (*1) (*2)
	EX0V	2	• Ground for feedback scale power supply output (*3)
Feedback scale signal input/output (serial signal)	EXPS	3	• Serial signal non-inverted I/O
	/EXPS	4	• Serial signal inverted I/O
Feedback scale signal input (A-/B-/Z-phase signal) (*4)	EXA	5	• A-phase signal non-inverted input
	/EXA	6	• A-phase signal inverted input
	EXB	7	• B-phase signal non-inverted input
	/EXB	8	• B-phase signal inverted input
	EXZ	9	• Z-phase signal non-inverted input
	/EXZ	10	• Z-phase signal inverted input
Frame ground	FG	Shell	• Connected to the ground terminal inside the servo driver.

*1 The EX5V is connected to the X6 connector pin 1 (E5V) inside the servo driver.

The EX5V and the X6 E5V are 5 V \pm 5% with a total maximum of 300 mA.

A customer-supplied external power supply is necessary if using a feedback scale with a consumption current higher than this.

Also, some feedback scales may take time to initialize when powering on. In that case, it is possible to adjust the power-on wait time, which is a function of the servo driver.

For details, refer to Technical Reference - Functional Specification -.

*2 If the feedback scale is powered by an external power supply, the EX5V pin should be open to prevent external voltage from being supplied to this pin.

*3 The EX0V of the feedback scale power supply output is connected to the control circuit ground connected to the connector X4 and pin 2 of X6 (E0V).

*4 Up to 4 Mpps can be received with A/B phase multiplied by 4. However, if the duty ratio of the scale input signal waveform is not 50%, it may not be able to read correctly.

7.7 CS Signal Connector X6

Name	Symbol	Pin No.	Description
Power supply output for CS signal	E5V	1	• Power supply output for CS signals (*1)
	E0V	2	• Ground for CS signal power supply output (*2)
Reserved	—	3	• Do not connect anything.
CS signal input	CS3	4	• CS3 signal input
	CS2	5	• CS2 signal input
	CS1	6	• CS1 signal input
Frame ground	FG	Shell	• Connected to the ground terminal inside the servo driver.

*1 The E5V is connected to the X5 connector pin 1 (EX5V) inside the servo driver.

The E5V and the X5 EX5V are $5\text{ V} \pm 5\%$ with a total maximum of 300 mA.


*2 The E0V of the CS signal power supply output is connected to pin 2 (EX0V) of connector X5 and to the control circuit ground connected to connector X4.

7.8 Analog Monitor Connector X7

Name	Symbol	Pin No.	Description	I/O signal interface
Analog monitor output 1	AM1	1	<ul style="list-style-type: none"> Outputs analog signals for the monitor. The meaning of the output signal changes depending on parameter settings. 	Ao-1
Analog monitor output 2	AM2	2		
Signal ground	GND	3	• Signal ground	—
Reserved	—	4,5	• Do not connect anything	—


7.9 I/O Signal Interface

i-1



S: [Pins] (X3) 3, 5 / (X4) 5, 7, 8, 9, 10, 11, 12, 13
P: [Pins] (X3) 4, 6 / (X4) 6

o-1




[Pins] +: (X3) 8 / (X4) 1, 3, 25

[Pins] -: (X3) 7 / (X4) 2, 4, 26

* If the relay is to be driven directly, install a diode in parallel with the relay in the direction shown above.

Ao-1




[Pins] S: (X7) 1, 2

[Pins] G: (X7) 3

* The output signal amplitude is ± 10 V.

Do-1



[Pins] +: (X4) 17, 20, 21

[Pins] -: (X4) 18, 19, 22

[Pins] G: (X4) 16


* Connect a terminating resistor (approx. 330 Ω) between the line receiver inputs.

7.9.1 CS Signal Interface


The linear motor CS signal is connected to X6.

The relationship between the CS signal and the movement direction of the linear motor is shown in the figure below.



■ when not using CS signal part twisted-pair cable



- when using CS signal part twisted-pair cable





CS signal direction

	Negative Direction (Counting Down)	Positive Direction (Counting Up)
Magnetic pole detection signal	 <p>CS1 advances 120° from CS2 CS2 advances 120° from CS3</p>	 <p>CS3 advances 120° from CS2 CS2 advances 120° from CS1</p>

8 Wiring and System Configuration

8.1 Cables Used and Maximum Cable Lengths

Name	Symbol	Maximum wiring length (*1)	Cable(s) used
Main power supply input	L1, L2, L3	—	See “15 Model Specifications”
Control power supply input	L1C, L2C (100 V / 200 V)	—	See “15 Model Specifications”
	24V, 0V (400 V)	—	See “15 Model Specifications”
Motor output	U, V, W, 	20 m	See “15 Model Specifications”
Ground cable		—	See “15 Model Specifications”
CS signal connection	X6	20 m	Common shielded twisted-pair wire Core cable: 0.18 mm ² or more
Feedback scale connection (*3)	X5	20 m	
Parallel I/O connection	X4	3 m	
Safety connection (*3)	X3	3 m	Core cable: 0.18 mm ² or more
RTEX connection	X2A, X2B	100 m (*2)	TIA/EIA-568 CAT5e STP

*1 The above wiring lengths are the maximum lengths used in Panasonic's evaluation environment. They do not guarantee operation in working environments of customers.

*2 For details, refer to “8.3.4 Wiring to Connectors X2A, X2B”

*3 Only compatible with the multifunction type.

8.2 Cable Side Connectors

Connector symbol	Product Name	Product number	Manufacturer
X3	Connector	2013595-1	TE Connectivity
X4	Solder plug (soldered type)	DF02P026F22A1	Japan Aviation Electronics Industry, Ltd. (JAE)
	Plug hood	DF02D026B22A	
X5	Connector	MUF-PK10K-X	J.S.T. Mfg. Co., Ltd.
X6	Receptacle	3E206-0100 KV	3M Japan
	Shell kit	3E306-3200-008	
X7	Connector	510210500	Molex Japan
	Terminal	500588020	
XE (*1)	Connector	5557-04R-210	Molex Japan
	Terminal	5556PBTB	


*1 Only size G is supported.

* Use the connectors above or an equivalent.

8.3 Precautions for Wiring

8.3.1 Wiring to Power Connectors and Terminal Blocks

8.3.1.1 Size A, B 100 V/200 V




Regenerative resistor connection

Size	Short cable (accessory)	Built-in regenerative resistor	Connection of connector XB	
			When using an external regenerative resistor	When not using an external regenerative resistor
Size A Side B	None	None	Between P and B: Connect the external regenerative resistor.	Between P and B: Keep open.

- * Connectors X1–X7 are secondary-side circuits. (See “5 Appearance and Part Names”)
The primary-side power supply (power supply for the motor brake) must be isolated.
Do not connect it to the same power supply.
- * For details, refer to the table in “7.1.1 Size A, B 100 V/200 V”.

8.3.1.2 Size C, D 100 V/200 V




Regenerative resistor connection

Size	Short cable (accessory)	Built-in regenerative resistor	Connection of connector XB	
			When using an external regenerative resistor	When not using an external regenerative resistor
Size C Side D	Provided	Provided	Between the RB and B: Disconnect the short cable. Between P and B: Connect the external regenerative resistor.	Between RB and B: Short circuit with the short cable.

- * Connectors X1–X7 are secondary-side circuits. (See “5 Appearance and Part Names”)
- The primary-side power supply (power supply for the motor brake) must be isolated.
Do not connect it to the same power supply.
- * For details, refer to the table in “7.1.2 Size C, D 100 V/200 V” .

8.3.1.3 Size E 200 V




Regenerative resistor connection

Size	Short cable (accessory)	Built-in regenerative resistor	Connection of connector XC	
			When using an external regenerative resistor	When not using an external regenerative resistor
Side E	Provided	Provided	Between the RB and B: Disconnect the short cable. Between P and B: Connect the external regenerative resistor.	Between RB and B: Short circuit with the short cable.

- * Connectors X1–X7 are secondary-side circuits. (See “5 Appearance and Part Names”)
The primary-side power supply (power supply for the motor brake) must be isolated.
Do not connect it to the same power supply.
- * For details, refer to the table in “7.1.3 Size E 200 V” .

8.3.1.4 Size F 200 V




Regenerative resistor connection

Size	Short bar (accessory)	Built-in regener- ative resistor	Terminal block connection	
			When using an external regenerative resistor	When not using an external regenera- tive resistor
Side F	Provided	Provided	Between RB and B: Disconnect the short bar. Between P and B: Connect the exter- nal regenerative resistor.	Between RB and B: Short circuit with the short bar.

- * Connectors X1–X7 are secondary-side circuits. (See “5 Appearance and Part Names”)
The primary-side power supply (power supply for the motor brake) must be isolated.
Do not connect it to the same power supply.
- * The capability of the built-in dynamic brake resistor is roughly the maximum allowable inertia when stopped three times consecutively from the rated speed. Failure to do so may cause the resistor to disconnect or the dynamic brake to no longer be operable.
- * For details, refer to the table in “7.1.4 Size F 200 V”.

8.3.1.5 Size G 200 V



Regenerative resistor connection


Size	Built-in regenerative resistor	Terminal block connection	
		When using an external regenerative resistor	When not using an external regenerative resistor
Side G	None	Between P and B: Connect the external regenerative resistor.	Between P and B: Keep open.

- * Connectors X1–X7 are secondary-side circuits. (See “5 Appearance and Part Names”)
The primary-side power supply (power supply for the motor brake) must be isolated.
Do not connect it to the same power supply.
- * Size G has a built-in dynamic brake. If using the built-in dynamic brake, set switch XS to “1”. (It is set to the “1” side by default.)
- * The capability of the built-in dynamic brake resistor is roughly the maximum allowable inertia when stopped three times consecutively from the rated speed. Failure to do so may cause the resistor to disconnect or the dynamic brake to no longer be operable.
- * If the capability of the built-in dynamic brake resistor is exceeded, set switch XS to “2” to use the external dynamic brake resistor.

See external dynamic brake connection examples for connections.


* For details, refer to the table in "7.1.5 Size G 200 V".

Connection example for Size G 200 V external dynamic brake resistor



- *1 If using the external dynamic brake resistor, set switch XS to "2".
- *2 The electromagnetic contactor (MC2) must be the same as the electromagnetic contactor (MC1) of the main circuit.
- *3 If an auxiliary contact is established and the main contact is welded together, configure protection so that the servo is not turned on using an external sequence.
- *4 Use three dynamic brake resistors of 1.2 Ω 400 W.
Install the dynamic brake resistor to nonflammable materials such as metal.
- *5 Install a thermal protector on the dynamic brake resistor and monitor it with the controller side I/O. Configure the protection so that the servo does not turn on in sequence when the thermal protector is operated.
- *6 If the thermal protector cannot be monitored by the controller side I/O, input the thermal protector output between L2C and DB2 so that the dynamic brake does not operate when temperature protector operates.
- *7 Use the external dynamic brake resistor when the capability of the built-in dynamic brake resistor is exceeded.
- *8 Do not use the built-in dynamic brake and external dynamic brake at the same time.
- *9 For details, refer to the table in "7.1.5 Size G 200 V".

8.3.1.6 Size H 200 V




- *1 The pin number of the connector on the motor side is listed. Only in the case of the 22-kW specification is the connection destination indicated in parentheses.
- *2 The electromagnetic contactor (MC2) must be the same as the electromagnetic contactor (MC1) of the main circuit.
- *3 If an auxiliary contact is established and the main contact is welded together, configure protection so that the servo is not turned on using an external sequence.
- *4 Use three dynamic brake resistors of 1.2 Ω 400 W.
Install the dynamic brake resistor to nonflammable materials such as metal.
- *5 Install a thermal protector on the dynamic brake resistor and monitor it with the controller side I/O. Configure the protection so that the servo does not turn on in sequence when the thermal protector is operated.
- *6 If the thermal protector cannot be monitored by the controller side I/O, input the thermal protector output between L2C and DB2 so that the dynamic brake does not operate when temperature protector operates.
- *7 For details, refer to the table in “7.1.6 Size H 200 V”.

Regenerative resistor connection

Size	Built-in regenerative resistor	Terminal block connection	
		When using an external regenerative resistor	When not using an external regenerative resistor
Side H	None	Between P and B: Connect the external regenerative resistor.	Between P and B: Keep open.

- * Connectors X1–X7 are secondary-side circuits. (See “5 Appearance and Part Names”)
The primary-side power supply (power supply for the motor brake) must be isolated.
Do not connect it to the same power supply.
- * Because the dynamic brake is not built in, it is in a free-run state when a motor emergency stop occurs.
Use the external dynamic brake resistor if this could cause a mechanical collision.
- * The capability of the external dynamic brake resistor is roughly the maximum allowable inertia when stopped three times consecutively from the rated speed. Failure to do so may cause the resistor to disconnect or the dynamic brake to no longer be operable.

8.3.1.7 Size D, E 400 V




Regenerative resistor connection

Size	Short cable (accessory)	Built-in regenerative resistor	Connection of connector XC	
			When using an external regenerative resistor	When not using an external regenerative resistor
Size D Size E	Provided	Provided	Between the RB and B: Disconnect the short cable. Between P and B: Connect the external regenerative resistor.	Between RB and B: Short circuit with the short cable.

- * Connectors X1–X7 are secondary-side circuits. (See “5 Appearance and Part Names”)
- The primary-side power supply (power supply for the motor brake) must be isolated.
Do not connect it to the same power supply.
- * For details, refer to the table in “7.1.7 Size D, E 400 V”.

8.3.1.8 Size F 400 V




Regenerative resistor connection

Size	Short bar (accessory)	Built-in regener- ative resistor	Terminal block connection	
			When using an external regenerative resistor	When not using an external regenera- tive resistor
Size F	Provided	Provided	Between RB and B: Disconnect the short bar. Between P and B: Connect the exter- nal regenerative resistor.	Between RB and B: Short circuit with the short bar.

- * Connectors X1–X7 are secondary-side circuits. (See “5 Appearance and Part Names”)
The primary-side power supply (power supply for the motor brake) must be isolated.
Do not connect it to the same power supply.
- * The capability of the built-in dynamic brake resistor is roughly the maximum allowable inertia when stopped three times consecutively from the rated speed. Failure to do so may cause the resistor to disconnect or the dynamic brake to no longer be operable.
- * For details, refer to the table in “7.1.8 Size F 400 V”.

8.3.1.9 Size G 400 V



Regenerative resistor connection


Size	Built-in regenerative resistor	Terminal block connection	
		When using an external regenerative resistor	When not using an external regenerative resistor
Size G	None	Between P and B: Connect the external regenerative resistor.	Between P and B: Keep open.

- * Connectors X1–X7 are secondary-side circuits. (See “5 Appearance and Part Names”)
The primary-side power supply (power supply for the motor brake) must be isolated.
Do not connect it to the same power supply.
- * Size G has a built-in dynamic brake. If using the built-in dynamic brake, set switch XS to “1”. (It is set to the “1” side by default.)
- * The capability of the built-in dynamic brake resistor is roughly the maximum allowable inertia when stopped three times consecutively from the rated speed. Failure to do so may cause the resistor to disconnect or the dynamic brake to no longer be operable.
- * If the capability of the built-in dynamic brake resistor is exceeded, set switch XS to “2” to use the external dynamic brake resistor.

See external dynamic brake connection examples for connections.


* For details, refer to the table in "7.1.9 Size G 400 V".

Connection example for Size G 400 V external dynamic brake resistor



- *1 If using the external dynamic brake resistor, set switch XS to "2".
- *2 The electromagnetic contactor (MC2) must be the same as the electromagnetic contactor (MC1) of the main circuit.
- *3 If an auxiliary contact is established and the main contact is welded together, configure protection so that the servo is not turned on using an external sequence.
- *4 Use three dynamic brake resistors of 4.8 Ω 400 W.
Install the dynamic brake resistor to nonflammable materials such as metal.
- *5 Install a thermal protector on the dynamic brake resistor and monitor it with the controller side I/O. Configure the protection so that the servo does not turn on in sequence when the thermal protector is operated.
- *6 If the thermal protector cannot be monitored by the controller side I/O, input the thermal protector output between L2C and DB2 so that the dynamic brake does not operate when temperature protector operates.
- *7 Use the external dynamic brake resistor when the capability of the built-in dynamic brake resistor is exceeded.
- *8 Do not use the built-in dynamic brake and external dynamic brake at the same time.
- *9 For details, refer to the table in "7.1.9 Size G 400 V".

8.3.1.10 Size H 400 V



- *1 The pin number of the connector on the motor side is listed. Only in the case of the 22-kW specification is the connection destination indicated in parentheses.
- *2 The electromagnetic contactor (MC2) must be the same as the electromagnetic contactor (MC1) of the main circuit.
- *3 If an auxiliary contact is established and the main contact is welded together, configure protection so that the servo is not turned on using an external sequence.
- *4 Use three dynamic brake resistors of 4.8 Ω 400 W.
Install the dynamic brake resistor to nonflammable materials such as metal.
- *5 Install a thermal protector on the dynamic brake resistor and monitor it with the controller side I/O. Configure the protection so that the servo does not turn on in sequence when the thermal protector is operated.
- *6 If the thermal protector cannot be monitored by the controller side I/O, input the thermal protector output between L2C and DB2 so that the dynamic brake does not operate when temperature protector operates.
- *7 For details, refer to the table in "7.1.10 Size H 400 V".

Regenerative resistor connection

Size	Built-in regenerative resistor	Terminal block connection	
		When using an external regenerative resistor	When not using an external regenerative resistor
Size H	None	Between P and B: Connect the external regenerative resistor.	Between P and B: Keep open.

- * Connectors X1–X7 are secondary-side circuits. (See “5 Appearance and Part Names”)
The primary-side power supply (power supply for the motor brake) must be isolated.
Do not connect it to the same power supply.
- * Because the dynamic brake is not built in, it is in a free-run state when a motor emergency stop occurs.
Use the external dynamic brake resistor if this could cause a mechanical collision.
- * The capability of the external dynamic brake resistor is roughly the maximum allowable inertia when stopped three times consecutively from the rated speed. Failure to do so may cause the resistor to disconnect or the dynamic brake to no longer be operable.

8.3.1.11 Precautions

- 1 When the servo driver uses a single-phase power supply for sizes A–D, connect the servo driver to main power supply input terminals L1 and L3. Do not connect anything to the terminal L2.
- 2 Insert the connector securely until it is locked.
- 3 Make sure to use an insulation coated crimp terminal when connecting to each terminal on the terminal block. (size F,G,H)
- 4 For models with terminal block covers, the terminal block cover is screwed on.
When wiring to the terminal block, unscrew these screws to open the cover.
Tighten the cover fixing screw to 0.19–0.21 N·m.
Only tighten the terminal block cover 2 (black) of size H to less than 2.0–2.5 N·m of torque.
- 5 Apply the power supply of the voltage indicated on the nameplate.
- 6 Do not reverse-connect the power supply input terminals (L1, L2, and L3) and the motor output terminals (U, V, and W).
- 7 Do not connect the motor output terminals (U, V, and W) to ground or short circuit them.
- 8 Power connectors XA, XB, XC, XD, and the terminal block are supplied with voltage, so do not touch them.
There is a danger of electric shock.
- 9 The short-circuit current of the power supply used should be capable of not more than 5,000 Arms symmetrical amperes, below the maximum input voltage of the product.
If the short-circuit current of the power supply exceeds this, limit the short-circuit current by using a currentlimiting device (such as a current-limiting fuse, current-limiting breaker, transformer).
- 10 Make sure to match the motor output terminals (U, V, and W) of the servo driver with the input terminals of the motor.
- 11 Make sure to connect the grounding terminal of the motor to the grounding terminal of the servo driver and ground it together with the ground terminal of the noise filter. Also ground the machine body. Use a D model ground (grounding resistance: 100 Ω or less). Tighten the servo driver's ground screw with the appropriate torque specified for each size.
Use a ground cable with a wire diameter equal to or larger than the wire diameter specified in “Model Specifications”.
Also, avoid direct contact between aluminum and copper to avoid the effects of electrolytic corrosion.
- 12 Insert surge absorbing circuits for preventing noise to electromagnetic contactors placed around the servo driver, to coils between relay contact points, and to the brake windings of motors with a brake.
- 13 Install a molded case circuit breaker (MCCB) and make sure to shut off the power supply from outside the servo driver in case of an emergency.
When using a residual current device, use one with countermeasures for high frequencies.
- 14 Install a noise filter to reduce terminal noise voltage.
- 15 The power supply for the brake of motors with a brake must be supplied by the customer.
- 16 Ensure that voltage is applied to the power supply only after wiring has been completed.
- 17 Regarding external regenerative resistors:
 - Sizes A, B, G and H do not have built-in regenerative resistors.
 - Sizes C, D, E, and F have built-in regenerative resistors which are activated by shorting between RB and B.
 - If tripping occurs due to a regenerative overload protection error (Err18.0), an external regenerative resistor must be installed. For external regenerative resistors, remove the short cable or short bar between RB and B and connect it between the P and B terminals. In addition, parameters must be used for regenerative resistor settings.
For details, refer to “Technical Reference - Functional Specification”.

- The following resistors are recommended as external regenerative resistors:

Size	Input power supply voltage		
	Single-phase 100 V	Single-phase 200 V/3-phase 200 V	3-phase 400 V
A	DV0P4280	DV0P4281 (100 W or less) DV0P4283 (200 W)	—
B	DV0P4283	DV0P4283	
C	DV0P4282	DV0P4283	
D	—	DV0P4284	DV0PM20048
E		Two DV0P4284 in parallel or one DV0P4285	DV0PM20049
F		Two DV0P4285 in parallel	Two DV0PM20049 in parallel
G	—	Three DV0P4285 in parallel	Three DV0PM20049 in parallel
H	—	Six DV0P4285 in parallel	Six DV0PM20049 in parallel

* Manufacturer: Iwaki Musen Kenkyusho

Panasonic product number	Manufacturer product number	Specifications			Built-in thermal protector (*2) Operating temperature
		Resistance value	Rated power (reference) (*1)		
			Free air	Fan used	
			Ω	[W]	
DV0P4280	RF70M	50	10	25	140 ± 5 °C B contact Open/close capacity (resistive load) 1 A, AC 125 V, 6,000 cycles 0.5 A, AC 250 V, 10,000 cycles
DV0P4281	RF70M	100	10	25	
DV0P4282	RF180B	25	17	50	
DV0P4283	RF180B	50	17	50	
DV0P4284	RF240	30	40	100	
DV0P4285	RH450F	20	52	130	
DV0PM20048	RF240TF	120	35	80	
DV0PM20049	RH450FTF	80	65	190	

*1 Available power without running the built-in thermal protector

*2 Each regenerative resistor has built-in thermal fuse and thermal protector for safety.

- When using a thermal protector, configure the circuit to turn off the power supply.

(See *“8 Wiring and System Configuration”*)

- The built-in thermal fuse may break due to heat dissipation conditions, operating temperature range, power supply voltage, or load fluctuation.


When operating in conditions where the regenerative resistor is likely to generate heat (e.g., when the power supply voltage is high, when load inertia is large, when deceleration times are short), incorporate it into the device to ensure that the surface temperature of the regenerative resistor remains at 100°C or less and confirm the operation thereof.

- Install the regenerative resistor to nonflammable materials such as metal.
- Install the regenerative resistor so that it cannot be touched directly, such as by covering it with non-combustible material.
- Sections which can be touched directly should be kept to less than 70°C.

8.3.1.12 How to wire to the power connector


Follow the procedure below to wire to connectors XA, XB, XC and XD .

- 1 Strip the wires to be used. Refer to the figure below for the stripping length.



Size	Connector	L [mm]
Sizes A - C, Size D 200 V	XA, XB	10 mm
Size D 400 V, Size E	XA, XB, XC	11 mm
Sizes D - F 400 V	XD	8 mm

- 2 Insert the wire into the connector.



- (1) Push down the spring by pushing the control lever attached to the upper operating slot with your fingers.
- (2) Insert the wire while pressing the control lever.
- * Ensure that all strands are inserted into the spring opening.
- (3) Wire it by releasing the control lever. Pull the wire lightly to make sure that the wire is securely connected.

Precautions

- Be careful not to damage or cut the core cable when stripping the wire.
- Because the stripping length of the electric wire will depend on the size and type of electric wire, decide the optimal stripping length based on processing conditions.
- When wiring, disconnect the connector from the servo driver main body.
- Insert one wire into one wire insertion slot of the connector.
- Push down the control lever to remove the wire.

8.3.2 Wiring to Connector X4


- 1 The customer is required to prepare provide a DC 12 - 24 V control signal power supply for external control to be connected to SI-COM.

It must be isolated from the primary power supply (motor brake power supply).

Do not connect it to the same power supply.

- 2 Install peripheral devices as close to the servo driver as possible to minimize the wiring length (within 3 m).
- 3 Keep the cables as far away from the wiring of the power lines (L1, L2, L3, L1C, L2C, U, V, W, \ominus) as possible (at least 30 cm). Do not put them in the same duct or bind them together.

8.3.2.1 Control input




The functions of SI1 to SI8 are assigned using parameters.

For details, refer to “Technical Reference - Functional Specification”.

8.3.2.2 Control output

- 1 Be aware of the polarity of the power supply for control signals. Polarity connections contrary to the figure shown above can damage the servo driver.
- 2 If the relay is to be driven directly by the output signal, install a diode in parallel with the relay in the direction shown below. Failure to install a diode or installing it in the opposite direction will damage the servo driver.
- 3 When each output signal is received by a logic circuit such as a gate, ensure that it is not affected by noise.
- 4 The current to be passed through each output must not exceed a rated current of 40 mA, a maximum current of 50 mA, or an inrush current of 90 mA.
- 5 The output circuit is equipped with a limiting resistor (10 Ω).


Also, because the output transistor is a Darlington connection, voltage $V_{CE(SAT)}$ is approx. 1 V between the collector and emitter when the transistor is on, meaning that direct connections are not possible due to the fact that V_{IL} cannot be satisfied with a normal TTL IC.



The functions of SO1 to SO3 are assigned using parameters.


For details, refer to “Technical Reference - Functional Specification”.

8.3.2.3 Feedback Output Signal/Position Compare Output Signal




- 1 Use a line receiver (AM26C32 or equivalent) to receive output pulse. Ensure that an appropriate terminating resistor (approx. 330 Ω) is installed between the line receiver inputs.
- 2 Use at a maximum output frequency of 4 Mpps (after being multiplied by 4) or less.

8.3.3 Wiring to Connector X5, X6


- 1 Use a cable for the feedback scale whose strands are common shielded twist-pair wires with a core of 0.18 mm² or more.
- 2 The cable for the CS signal must be common shielded (twisted pair is preferable), with a core of 0.18 mm² or greater.
- 3 The maximum cable length is 20 m. For long wiring lengths, double wiring is recommended for the 5 V power supply to reduce the effects of voltage drops.
- 4 See "7.9.1 CS Signal Interface" for the CS signal connection interface.
- 5 Connect the CS signal ground to E0V.
- 6 Connect the outer sheath of the shielded wire on the motor side to the shield of the shielded wire from the feedback scale and the CS signal. Make sure to connect the sheath of the shielded wire on the servo driver side to the X5 and X6 shells (FG).
- 7 Keep the cables as far away from the wiring of the power lines (L1, L2, L3, L1C, L2C, U, V, W, ) as possible (at least 30 cm).
Do not put them in the same duct as power lines or bind them together.
- 8 Do not connect anything to the empty terminals of X5 or X6.
- 9 The maximum power supply that can be supplied from X5 or X6 is 5 V \pm 5% with a total maximum of 300 mA.
A customer-supplied external power supply is necessary if using a scale with a consumption current higher than this. Also, some scales may take time to initialize when powering on.
Create a design that achieves the desired operation timing after power is turned on.
- 10 X6 wiring is not required when using the magnetic pole position estimation function without using a CS signal.

8.3.3.1 Wiring example for A/B phase, home position signal differential input type

■ When not using CS signal part twisted-pair cable




■ When using CS signal part twisted-pair cable




8.3.3.2 Serial communication type wiring example

■ When not using CS signal part twisted-pair cable




■ When using CS signal part twisted-pair cable




8.3.3.3 Wiring example with an external power supply

- * The following wiring example is for A/B phase, home position signal differential input type.
- * Connect the external power supply ground and sensor ground to EX0V, and use the same potential as the control ground inside the servo driver.
- * The EX5V pin should be open to prevent external voltage from being supplied to this pin.

■ When not using CS signal part twisted-pair cable



■ When using CS signal part twisted-pair cable




8.3.4 Wiring to Connectors X2A, X2B

- 1 Use shielded twisted pair (STP) cables of Category 5e or higher.
- 2 If both ends of the shield are not grounded, EMC properties will degrade.
When attaching the connector plug to each end of the cable, ensure that the shielded wire of the cable is connected to the metal shell of the plug.
- 3 The lead wire color and connector terminal must be in accordance with TIA/EIA-568B (see figure below).
The pair created by pins 3 and 6 is the signal wire. Make sure to wire the 3 pairs of pins that are not in use (1-2, 4-5, 7-8) to the connector.
- 4 If using a 2-pair wire instead of a 4-pair wire, connect it to pin pairs 1-2 and 3-6 on the connector while leaving pin pairs 4-5 and 7-8 unconnected.
- 5 The wiring length of the communication cable must be within a range that meets the following conditions.
Please contact us if the condition b is to be exceeded.
 - a. The length between each node must not exceed 100 m.
 - b. The total length of cable between nodes for all communication loops must not exceed 200 m.
- 6 Cable specifications, such as bending properties, temperature ranges, covering materials, will vary by manufacturer.
Select a cable that meets the usage conditions at your company.
Also select a movable cable that meets the usage conditions at your company.


Communication cable for evaluations at Panasonic

- Manufacturer: SANWA SUPPLY INC.
- Product number: KB-STP-**LBN
- Specification: Category 5e, STP


8.3.4.1 Connection of X2A



8.3.4.2 Connection of X2B



8.3.4.3 RJ45 plug pin configuration



8.4 Dynamic Brake

The servo driver (sizes A–G) feature a built-in dynamic brake for emergency stopping.

The size H servo driver does not have a built-in dynamic brake.

The dynamic brake can be activated when the:

- 1 main power supply is off;
- 2 servo is off;
- 3 protection function is activated;
- 4 over-travel inhibit inputs (POT, NOT) of connector X4 are operated.

Under conditions (1) to (4) above, dynamic brake operation or free running can be selected using parameters during deceleration or after stopping.

However, when the control power supply input is off, the dynamic brake continues operating for servo driver sizes A–F, while the dynamic brake stops operating for servo driver sizes G and H.

Because the dynamic brake is rated for short time periods and is only to be used for emergency stopping, please adhere to the following:

- 1 Do not start or stop the device by turning the servo-on signal (SRV-ON) on or off.
This may damage the dynamic braking circuit incorporated into the servo drive.
- 2 Do not run the motor using an external power source.
If the motor is run externally, it will start acting as an electricity generator. This may cause it to short-circuit during operation of the dynamic brake, resulting in smoke or fire.
Doing so may also cause the dynamic brake to become disconnected, preventing it from functioning.
- 3 If the dynamic brake is applied when the device is operating at a high speed, allow a stop time of approximately 10 minutes.
Failure to do so may cause the dynamic brake to disconnect or the brake to no longer be operable.

A dynamic brake circuit (electromagnetic contactor for driving and resistor) can be externally attached to size G and H servo drivers.

In the case of the size G servo driver, external attachment is recommended when the capacity of the built-in dynamic brake is insufficient.

Wiring according to *“8.3.1 Wiring to Power Connectors and Terminal Blocks”* shown above and the wiring diagrams for *“8.3.1.5 Size G 200 V”* and *“8.3.1.6 Size H 200 V”*

8.5 Mounting Direction and Spacing

- The servo driver is a vertically mounted type. Ensure that it is mounted vertically.
- Servo driver sizes A–D and H come standard as base-mounted types (rear-mounted).
- If changing the mounting surface of servo driver sizes A–D, use a separately sold mounting bracket.
- Select a tightening torque for the mounting screws used to secure your product by considering screw strength and the material to which it will be mounted.


Example: Mounting to steel with steel screws

Sizes A–G: M5 2.7–3.3 N·m; H: M6 4.7–5.7 N·m

- To ensure effective cooling, ensure surrounding space for airflow.
- Install a fan to achieve a uniform temperature within the control panel.
- Sizes D–F frames are equipped with a cooling fan on the bottom, while sizes G and H are equipped with cooling fans on the bottom and top.
- Observe the environmental conditions for the control panel as described in chapter *“9.3.1 Installation Environment”*.
- The servo driver must be secured to a grounded conductive frame.

- If the area where the servo driver is to be mounted is painted, removing the paint before installation will help to prevent noise.
- If using custom brackets, the bracket surface must have a conductive plating.
- Measure the ambient temperature of the servo driver at a location that is 50 mm from the side or bottom of the servo driver.

If measuring from a distance of 50 mm is not possible, instead measure at the midpoint of the gap between the obstacle preventing measurement and the servo driver.



9 Compliance with International Standards

9.1 List of Compliance Standards for Servo Drivers

		Standard No.
EU/UK Standards	EMC	EN55011:2016/A11:2020 (Group 1, Class A) EN61000-6-2 EN61000-6-4 EN61800-3:2004/A1:2012 (Category C3, Second environment)
	Low voltage	EN61800-5-1
	Machinery (Functional Safety)	ISO13849-1 EN61508 EN62061 EN61800-5-2 IEC61326-3-1 IEC60204-1
UL standards		UL61800-5-1 (File No. E164620)
CSA standards		C22.2 No.274
KC		KN11 KN61000-4-2, 3, 4, 5, 6, 8, 11

IEC: International Electrotechnical Commission

EN: Europaischen Norman

EMC: Electromagnetic Compatibility

UL: Under writers Laboratories

CSA: Canadian Standards Association

KC: Radio Waves Act (South Korea)

Safety parameters

	With EDM diagnostic	Without EDM diagnostic
Safety integrity level	EN61508 (SIL3) EN62061 (SILCL3)	EN61508 (SIL2) EN62061 (SILCL2)
Performance level	ISO13849-1 PL e (Cat.3)	ISO13849-1 PL d (Cat.3)
Safety function	EN61800-5-2 (SIL 3, STO)	EN61800-5-2 (SIL 2, STO)
Probability of dangerous failure per unit of time	<For size A, B, C, D, E, F> PFH = 1.34×10^{-8} (%SIL3=13.4%) <For size G and H> PFH = 1.78×10^{-8} (%SIL3=17.8%)	<For size A, B, C, D, E, F> PFH = 1.40×10^{-8} (%SIL2=1.40%) <For size G and H> PFH = 1.85×10^{-8} (%SIL2=1.85%)
Mean time to dangerous failure	MTTFd: High (100 years)	MTTFd: High (100 years)
Average self-diagnostic coverage	DC: Medium	DC: Low
Mission time	15 years	15 years

9.2 EU directives and UK regulations

Our products comply with standards associated with the EU low voltage directive/UK low voltage regulation in order to facilitate compliance of embedded equipment and devices with the EU directives/UK regulations.

9.2.1 Compliance with the EU EMC directive/UK EMC regulation

EN 55011

Warning: Class A equipment is intended for use in an industrial environment. Conductive and radioactive interference can make it difficult to ensure electromagnetic compatibility in other environments.

Caution: This equipment is not intended for use in residential environments and may not provide adequate protection to radio reception in such environments.

EN 61800-3

Servo drivers and servo motors are not intended for general household use or for connection to low-voltage public communication lines. Radio frequency interference may occur when connected to such circuits.

To comply with the EU EMC directive/UK EMC regulation, use a noise filter, a surge absorber, and a ferrite core.

The compliance of machinery and equipment with the EU EMC directive/UK EMC regulation must be confirmed on machinery and equipment in its final state incorporating servo drivers and servo motors.

9.2.2 Compliance with EN 61800-5-1:2007/A11:2021

1 Earth fault protection

This product does not have an earth fault protection function. Install a circuit breaker for wiring or an earth leakage breaker according to the grounding system.

Earth fault protection conditions for earth fault circuit breakers are shown below. The requirements of EN 60364-4-41 are met under these conditions.

Obey the laws and regulations of the country or region where you use the TT system. The rated sensitivity current and loop impedance of the earth leakage breaker are specified in some cases. You may also need a type B earth fault circuit breaker.

For TN system

Model	MCCB			Voltage to earth [V]	Acceptable maximum fault loop impedance [Ω]
	Rated current [A]	Type name	Manufacturer		
MADL*01**	10	BW50RAGU	Fuji Electric	100	0.43
MADL*11**	10	BW50RAGU	Fuji Electric	100	0.44
MBDL*21**	10	BW50RAGU	Fuji Electric	100	0.45
MCDL*31**	15	BW50RAGU	Fuji Electric	100	0.34
MADL*05**	10	BW50RAGU	Fuji Electric	115	0.53
MADL*15**	10	BW50RAGU	Fuji Electric	115	0.54
MBDL*25**	10	BW50RAGU	Fuji Electric	115	0.55
MCDL*35**	15	BW50RAGU	Fuji Electric	115	0.42
MDDL*45**	20	BW50RAGU	Fuji Electric	115	0.28
MDDL*55**	20	BW50RAGU	Fuji Electric	115	0.28
MEDL*83**	30	BW50RAGU	Fuji Electric	115	0.16
MEDL*93**	30	BW50RAGU	Fuji Electric	115	0.16
MFDL*A3**	50	BW50RAGU	Fuji Electric	115	0.17
MFDL*B3**	50	BW50RAGU	Fuji Electric	115	0.17

Model	MCCB			Voltage to earth [V]	Acceptable maximum fault loop impedance [Ω]
	Rated current [A]	Type name	Manufacturer		
MGDL*C3**	60	BW100EAGU	Fuji Electric	115	0.12
MHDL*E3**	125	BW125JAGU	Fuji Electric	115	0.06
MHDL*F3**	175	BW50RAGU	Fuji Electric	115	0.03
MDDL*44**	10	BW50RAGU	Fuji Electric	219	1.08
MDDL*54**	10	BW50RAGU	Fuji Electric	219	1.09
MDDL*64**	10	BW50RAGU	Fuji Electric	219	1.10
MEDL*84**	15	BW50RAGU	Fuji Electric	219	0.90
MFDL*A4**	30	BW50RAGU	Fuji Electric	219	0.44
MFDL*B4**	30	BW50RAGU	Fuji Electric	219	0.44
MGDL*C4**	30	BW50RAGU	Fuji Electric	219	0.54
MHDL*E4**	60	BW100EAGU	Fuji Electric	219	0.22
MHDL*F4**	100	BW100EAGU	Fuji Electric	219	0.22

For TT system

Model	ELCB				Voltage to earth [V]	Acceptable maximum fault loop impedance [Ω]
	Rated current [A]	rated sensitivity current [mA]	Type name	Manufacturer		
MADL*01**	10	30	EW50RAGU	Fuji Electric	100	360
MADL*11**	10	30	EW50RAGU	Fuji Electric	100	360
MBDL*21**	10	30	EW50RAGU	Fuji Electric	100	360
MCDL*31**	15	30	EW50RAGU	Fuji Electric	100	360
MADL*05**	10	100	EW50RAGU	Fuji Electric	115	207
MADL*15**	10	100	EW50RAGU	Fuji Electric	115	207
MBDL*25**	10	100	EW50RAGU	Fuji Electric	115	207
MCDL*35**	15	100	EW50RAGU	Fuji Electric	115	207
MDDL*45**	20	100	EW50RAGU	Fuji Electric	115	207
MDDL*55**	20	100	EW50RAGU	Fuji Electric	115	207
MEDL*83**	30	100	EW50RAGU	Fuji Electric	115	207
MEDL*93**	30	100	EW50RAGU	Fuji Electric	115	207
MFDL*A3**	50	100	EW50RAGU	Fuji Electric	115	207
MFDL*B3**	50	100	EW50RAGU	Fuji Electric	115	207
MGDL*C3**	60	100	EW100EAGU	Fuji Electric	115	207
MHDL*E3**	125	100	EW125JAGU	Fuji Electric	115	172
MHDL*F3**	175	100	EW250JAGU	Fuji Electric	115	166
MDDL*44**	10	100	EW50RAGU	Fuji Electric	219	394
MDDL*54**	10	100	EW50RAGU	Fuji Electric	219	394
MDDL*64**	10	100	EW50RAGU	Fuji Electric	219	394
MEDL*84**	15	100	EW50RAGU	Fuji Electric	219	394
MFDL*A4**	30	100	EW50RAGU	Fuji Electric	219	394
MFDL*B4**	30	100	EW50RAGU	Fuji Electric	219	394
MGDL*C4**	30	100	EW50RAGU	Fuji Electric	219	394

Model	ELCB				Voltage to earth [V]	Acceptable maximum fault loop impedance [Ω]
	Rated current [A]	rated sensitivity current [mA]	Type name	Manufacturer		
MHDL*E4**	60	100	EW100EAGU	Fuji Electric	219	394
MHDL*F4**	100	100	EW100EAGU	Fuji Electric	219	394

2 Over heat protection/Over load protection

The servo amplifier has a built-in servo motor overload protection function, but the servo motor does not have an overheat protection function. If it becomes necessary to meet NEC standards, take measures to protect the servo motor from overheating. (Refer to “9.5 Compliance with UL Standards” “4” Load Protection and overheating protection)

9.3 Configuration of Peripheral Devices

9.3.1 Installation Environment


Use in an environment with a pollution degree 2 as stipulated in IEC60664-1.

(Example: Install in an IP54 metal control panel.)


Make sure to connect a molded case circuit breaker (MCCB) or fuse that is compliant with IEC standards or that is UL-approved to the main power supply.

The power supply for parallel I/O should be a DC 24 V power supply with double or reinforced insulation.

100 V/200 V type specification



400 V type specification



Ferrite core installation status during EMC certification test

Symbol	Location	Applicable size	Option product number	Manufacturer product number	Manufacturer	Quantity
NF1	Power supply cable	(100 V) C (200 V) C, D, F	—	—	—	None
		(100 V) A, B (200 V) A, B, E (400 V) D, E, F	DV0P1460	ZCAT3035-1330	TDK Corporation	1 (*1)
		(200 V) G, H (400 V) G, H	DV0P1460	ZCAT3035-1330	TDK Corporation	3 (*2)
			Recommended parts	RJ8095	Konno Kogyosho Co., Ltd.	1 (*3)
NF2	Motor cable	(100 V) A, B, C (200 V) A, B, C, D, E (400 V) D, E, F	DV0P1460	ZCAT3035-1330	TDK Corporation	1 (*1)
		(200 V) F	DV0P1460	ZCAT3035-1330	TDK Corporation	2 (*4)
		(200V) G, H (400 V) G, H	DV0P1460	ZCAT3035-1330	TDK Corporation	3 (*2)
			Recommended parts	T400-61D	MICROMETALS	1 (*3)


- *1 Power supply cables (L1, L2, L3) should be wound together for one circle. Motor cables (U, V, W) should also be wound together for one circle. One circle (bypass one line).
- *2 Power supply cables (L1, L2, L3) should be wound individually for one circle. Motor cables (U, V, W) should also be wound individually for one circle. One circle (bypass one line).
- *3 Power supply cables (L1, L2, L3) should be wound together for four circles. Motor cables (U, V, W) should also be wound together for four circles. If four turns is difficult, use two identical ferrite cores and make two turns for each.
- *4 Combine motor wires (U, V, W) and attach two ferrite cores in series. One circle (bypass one line).

9.3.2 Power Supply

100 V (Sizes A–C)	: Single-phase 100–120 V	+10 % -15 %	50/60 Hz
200 V (Sizes A–D)	: Single-phase/3-phase 200 V–240 V	+10 % -15 %	50/60 Hz
200 V (Sizes E–H)	: 3-phase 200–240 V	+10 % -15 %	50/60 Hz
400 V (Sizes D–H) Main power supply	: 3-phase 380 Y/220–480 Y/277 V TN (ground the neutral point to earth)	+10 % -15 %	50/60 Hz
400 V (Sizes D–H) Controlled power supply	: DC24 V	±15 %	

- 1 Use in an OVC III environment as stipulated in IEC60664-1.
- 2 Use an insulated DC 12 to 24 V parallel I/O power supply that is in compliance with the CE marking or the EN standard (EN60950).

9.3.3 Molded Case Circuit Breaker (MCCB)

Make sure to connect a molded case circuit breaker (MCCB) that is compliant with IEC standards or that is UL-approved (listed, with ) between the power supply and noise filter.

The product's short-circuit protection circuit is not intended to protect the branch circuit.

Select branch circuit protection in accordance with the NEC standard and local standards.

9.3.4 Noise Filter

If using multiple servo drivers and installing one noise filter for all to the power supply, consult with the manufacturer of the noise filter.

9.3.5 Surge Absorber

Install the surge absorber to the primary side of the noise filter.



Caution

- Always remove the surge absorber before pressure testing machinery and equipment.
Failure to do so may result in damage to the surge absorber.

9.3.6 Ferrite Core

Install ferrite cores on the power supply input line and motor output line.

9.3.7 Grounding

- 1 To prevent electric shock, make sure to connect the protective ground terminal () of the servo driver with the protective ground (PE) of the control panel.
- 2 Do not tighten the connection to the protective ground terminal (). There are two protective ground terminals.

9.4 List of Peripheral Devices Applicable to the Servo Driver

Servo driver	Voltage specification	Power supply capacity (At rated load)	Electromagnetic contactor (Rated energizing current/ Open heat current)	MCCB Rated current	Noise filter	Surge absorber	Ferrite core		
							Power supply cable	Motor cable	
MADL□01□□	Single-phase 100 V	Approx. 0.4 kVA	20 A	10 A	DV0P4170 (for single-phase) / DV0PM20042	DV0P4190 (for single-phase) / DV0P1450 (for 3-phase)	DV0P1460	DV0P1460	
MADL□11□□									
MADL□05□□	Single-phase/ 3-phase 200 V	Approx. 0.5 kVA							
MADL□15□□									
MBDL□21□□	Single-phase 100 V	Approx. 0.5 kVA							
MBDL□25□□	Single-phase/ 3-phase 200 V	Approx. 0.9 kVA							
MCDL□31□□	Single-phase 100 V	Approx. 0.9 kVA		15 A	DV0PM20042				
MCDL□35□□	Single-phase/ 3-phase 200 V	Approx. 1.8 kVA							
MDDL□45□□	Single-phase/ 3-phase 200 V	Approx. 2.4 kVA	30 A	20 A	DV0P4220				
MDDL□55□□		Approx. 2.9 kVA							
MEDL□83□□	3-phase 200 V	Approx. 3.8 kVA	60 A	30 A	DV0PM20043	DV0P1450			
MEDL□93□□		Approx. 4.5 kVA							
MFDL□A3□□		Approx. 5.2 kVA	100 A	50 A	DV0P3410				
MFDL□B3□□		Approx. 7.8 kVA							
MGDL□C3□□		Approx. 11 kVA	100 A	60 A	HF3080C-SZA				
MHDL□E3□□		Approx. 20 kVA	150 A	125 A	HF3100C-SZA		DV0P1460 RJ8095	DV0P1460 T400-61D	
MHDL□F3□□	Approx. 28 kVA	175 A							
MDDL□44□□	3-phase 400 V	Approx. 1.8 kVA	20 A	10 A	FN3258-16-44	LT-C34G801WS	DV0P1460	DV0P1460	
MDDL□54□□		Approx. 2.4 kVA							
MDDL□64□□		Approx. 2.9 kVA							
MEDL□84□□		Approx. 3.8 kVA	30 A	15 A					
MFDL□A4□□		Approx. 5.2 kVA	60 A	30 A	FN3258-30-33				
MFDL□B4□□		Approx. 7.8 kVA							
MGDL□C4□□		Approx. 11 kVA				HF3040C-SZC			
MHDL□E4□□		Approx. 20 kVA	100 A	60 A	HF3080C-SZA	DV0PM20050	DV0P1460 RJ8095	DV0P1460 T400-61D	
MHDL□F4□□		Approx. 28 kVA		100 A					

* For both single-phase/3-phase 200 V specifications, select the peripherals according to the power supply used.

Notes

- Select a molded case circuit breaker (MCCB) and noise filter with a capacity that matches the power supply capacity (considering load conditions).
- Use copper conductor wires with a temperature rating of 75°C or higher when wiring terminal blocks and ground terminals.

The protective ground terminal is M4 for sizes A–E, M5 for sizes F and G, and M6 for size H.

If the tightening torque of the screws exceeds the maximum value (see the terminal block description page), the terminal block may be damaged.

- The wire diameter of the ground cable must be 2.0 mm² (AWG 14) or more for outputs between 50 W–2.5 kW, 3.5 mm² (AWG 12) or more for outputs between 3.0 kW–5.0 kW, 22 mm² (AWG 4) or more for an output of 15.0 kW, and 38 mm² (AWG 2) or more for an output of 22.0 kW.
- For sizes A–E, use the included dedicated connectors.
- The tightening torque of the screw used for connecting connector (X4) to the host controller should be between 0.2 ± 0.05 N·m.

If the tightening torque of the screws exceeds the maximum value, the connector on the servo driver side may be damaged.

	Option product number	Manufacturer product number	Manufacturer
Surge absorber	DV0P1450	R·A·V-781BXZ-4	Okaya Electric Industries
	DV0P4190	R·A·V-781BWZ-4	
	DV0PM20050	R·A·V-801BXZ-4	
	—	LT-C34G801WS	Soshin Electric
Ferrite core	DV0P1460	ZCAT3035-1330	TDK Corporation
	—	RJ8095	Konno Kogyosho Co., Ltd.
	—	T400-61D	MICROMETALS
Noise filter	DV0P4170	SUP-EK5-ER-6	Okaya Electric Industries
	DV0P4220	3SUP-HU30-ER-6	
	DV0P3410	3SUP-HL50-ER-6B	
	DV0PM20042	3SUP-HU10-ER-6	
	DV0PM20043	3SUP-HU50-ER-6	
	—	HF3080C-SZA	Soshin Electric
	—	HF3100C-SZA	
	—	HF3040C-SZC	
	—	FN3258-16-44	Schaffner EMC
	—	FN3258-30-33	

9.5 Compliance with UL Standards

1 Installation environment

Install in an environment with a pollution degree 2 as stipulated in IEC60664-1.

Make sure to connect a molded case circuit breaker (MCCB) or fuse that is UL-approved to the main power supply.

Use copper conductor wires with a temperature rating of 75°C or higher when wiring.

2 Short circuit current rating (SCCR)

This servo driver is compatible with power supplies whose voltage is less than the maximum input voltage and which have a symmetrical current of 5000 Arms or less.

3 Branch circuit protection

Protect the branch circuit in accordance with the NEC (National Electrical Code) and local standards.

4 Load protection and overheating protection

The servo driver has a built-in servo motor overload protection function.

The overload protection function operates based on specified time limit characteristics when current has reached 115% or more of the rating.

For overload protection time characteristics, please refer to "Technical Reference Document - Basic Function Specifications - 7. Protective function/Alarm function".

The servo motor does not have an overheating protection function. If NEC compliance is required, implement overheating protection measures for the servo motor.

The servo driver has the thermal memory (shut down) function specified in EN61800-5-1 / UL61800-5-1, but does not have thermal memory (loss of power) or speed sensitivity functions.

9.6 Radio Waves Act (South Korea)

Under South Korea's Radio Waves Act, this servo driver is classified as a Class A commercial electromagnetic radio wave generator that is not designed for household use.

The user and distributor should be aware of this fact.

A 급 기기 (업무용 방송통신기자재)

이 기기는 업무용(A 급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

(대상기종 : **Servo Driver**)

[Reference translation]

Class A device (broadcast communication device for business use)

This product is an electromagnetic wave generating device for business use (Class A), which is intended non-household use.

The user and distributor should be aware of this fact.

(Applicable model: Servo Driver)

9.7 Compliance with the SEMI F47 Standard

- The SEMI F47 standard includes requirements for voltage drops in semiconductor manufacturing equipment.
- The control power supply for the servo driver complies with the SEMI F47 standard.

The main circuit power supply complies with the SEMI F47 standard at no-load and light loads.

Precautions

- This does not apply to single-phase 100 V servo drivers whose control power supply input is DC 24 V.
- Make sure to perform evaluations and confirmation for compatibility with the SEMI F47 standard using the actual equipment.

9.8 Harmonic Suppression Measures

- Harmonic suppression measures vary by country. Install in accordance with local regulations.
- Servo drivers for Japan whose input current exceeds 20 A are applicable to the “Guidelines for harmonic suppression measures for users who receive high-voltage or extra-high voltage power”. Calculate the equivalent capacity and harmonic outflow current based on the guidelines. If the harmonic current is found to exceed the limit value predetermined for the contract demand, appropriate measures must be taken. Furthermore, when calculating the equivalent capacity, assume that the conversion factor of the servo driver is $K_{31}=3.4$. (Refer to JEM-TR210 and JEM-TR225*.)

* These are technical documents issued by JEMA (Japan Electrical Manufacturers' Association).

10 SAFETY PRECAUTIONS

This section explains precautions that must be taken to prevent harm to people and damage to property.



SAFETY PRECAUTIONS

The following symbols represent the extent of the harm or damage that may occur through improper use.

DANGER	This indicates "a significant risk of death or serious injury".
CAUTION	This indicates "a risk of minor injury or damage to property".

The following symbols indicate how to comply with safety precautions.

	Something that you must not do.
	Something you must do.



DANGER



- 1 Ensure that the product is used in an environment of pollution degree 2 (places free from dust, metal powders, oil mists, and other foreign objects, as well as liquids such as water, oil, or grinding fluids). Do not store or use near combustible materials or in an environment containing corrosive gases (H₂S, SO₂, NO₂, Cl₂, etc.), flammable gases, helium gases, or other gases with low molecular weight.
- 2 Do not place flammable materials near the motor, servo driver, or regenerative resistor.
- 3 Do not run the motor using an external power source. If the motor is run externally, it will start acting as an electricity generator. This may cause it to short-circuit during operation of the dynamic brake, which is integrated into the servo driver, resulting in smoke and dust being emitted. Doing so may also cause the dynamic brake to become disconnected, preventing it from functioning.
- 4 Do not damage the cable, apply undue stress to it, place heavy objects on it, or pinch it.
- 5 Do not use with the cable submerged in oil or water.
- 6 Do not install the product next to heating elements such as heaters or large winding resistors. (Protection such as heat shields should be used to protect the product from heating elements.)
- 7 Do not connect a commercial power supply directly to the motor.
- 8 Do not use in places susceptible to strong vibrations or impacts. If installing a servo driver near a source of vibration, attach a vibration dampening device to the servo driver mounting surface.
- 9 Do not touch the rotating parts of the motor during operation.
- 10 Do not touch the keyway of the motor output shaft with bare hands.
- 11 Do not put hands inside the servo driver.
- 12 Do not touch the heat sink and peripheral devices of the motor or servo driver, as they can get very hot.
- 13 Do not performing wiring or operate the product with wet hands.

DANGER



- 14 Wiring work should be carried out by an electrical engineer.
- 15 Motors other than that specified do not include protective devices. Protect them using overcurrent protection devices, ground-fault circuit interrupters, overheating prevention devices, emergency stop devices, etc.
- 16 Before operating the servo driver following an earthquake, ensure that the servo driver and motor are properly installed and that the machine is safe.
- 17 After the power supply is switched off, the internal circuit will be charged at high voltage for a period of time. When relocating, wiring, or inspecting the driver, ensure that the power supply input is completely disconnected on the outside of the servo driver and wait at least 15 minutes before carrying out any work.
- 18 Install and set up the product so that it does not cause fire or personal injury in the event of an earthquake.
- 19 Install an external emergency stop circuit must be installed to enable the power supply to be immediately disconnected in the event of an emergency.
- 20 Install the motor, servo driver, and peripheral devices to nonflammable materials such as metal.
- 21 Ensure that the product is wired correctly and securely. Insecure or incorrect wiring may cause the motor to malfunction or lead to thermal damage. Also, do not allow any conductive materials such as wire debris to enter the servo driver during installation and wiring.
- 22 Ensure that the cables are securely connected and that energized parts are insulated.
- 23 Binding and inserting wires into a metal duct will cause the temperature to increase, which will result in reduced wire current capacity and possibly lead to thermal damage. Please consider the current reduction coefficient before deciding on how to wire the product.
- 24 Make sure to install a molded case circuit breaker (MCCB) to the power supply. Also, make sure to ground the ground terminal or ground wire.
- 25 Securely tighten the screws for connecting the terminal block, as well as the grounding screw, using the torque indicated in the specification sheet.
- 26 When constructing a system using safety features, make sure you understand and comply with the relevant safety standards as well as the information in our user manuals or technical reference documents.

CAUTION



- 27 When transporting the product, do not hold it by the cable or motor shaft.
- 28 When adjusting the parameters of the servo driver, do not set the gain too high or make extreme modifications to settings simultaneously, as doing so may result in unstable operation.
- 29 Following a power outage, do not get close to the machine once power is restored, as it may restart suddenly. Settings must be made to ensure personal safety even in event the machine restarts suddenly.
- 30 Do not approach the motor or the machine when it is running during power-up to ensure safety in the event of an unexpected malfunction.
- 31 Do not subject the motor shaft to strong shock.
- 32 Do not turn the servo driver main power supply on and off more frequently than necessary.
- 33 Do not use the electromagnetic contactor installed on the main power supply side to start or stop the motor.
- 34 If the motor has a built-in brake, it is for maintenance purposes and should not be used as a stopping (braking) device in order to ensure machine safety.
- 35 Do not drop or tip over the product during transportation or installation.
- 36 Do not climb on the motor or place heavy objects on it.
- 37 Do not cover the servo driver louver or allow any foreign objects to enter.
- 38 Do not expose the product to direct sunlight. When storing the product, keep it away direct sunlight and store at temperatures and humidity within the specified ranges.
- 39 Do not attempt to overhaul or modify the motor. Overhauls must be carried out by Panasonic or an authorized dealer.
- 40 Do not start or stop the device by turning the servo-on command (SRV-ON) on or off as this may damage the dynamic braking circuit incorporated into the servo drive.

CAUTION



- 41 Use the motor and servo driver in the combination specified by Panasonic. If combining the motor with a different servo driver, make sure to confirm its performance and safety.
- 42 Failure of the motor or the servo driver it is combined with may result in thermal damage to the motor and may cause smoke and dust to be emitted. Please consider these possibilities when using the device in cleanrooms, etc.
- 43 Make sure the device is mounted in a manner suitable for the power output and the weight of the unit.
- 44 Keep the ambient temperature and humidity of the servo driver and motor are within the permitted ambient temperature and humidity ranges.
- 45 Observe the specified mounting method and orientation.
- 46 Keep the required distance between the servo driver and the control panel interior or other equipment.
- 47 If an eyebolt is attached to the motor, it should only be used to transport the motor and not to transport any other equipment. The eyebolt should also not be used if a decelerator, face plate, etc., is attached.
- 48 Connect the brake control relay in series with the relay that disconnects in the event of an emergency stop.
- 49 To perform a test run, secure the motor and check its operation with it disconnected from the mechanical system, then mount it onto the machine.
- 50 Confirm that the input power supply voltage is in line with the servo driver specifications before turning it on and operating.
- 51 In the event of an alarm, eliminate the cause of the alarm and restart the device.
- 52 If the motor has a built-in brake, it may not last due to reasons such as its life span or mechanical structure. A stopping device must be installed on the machine side to ensure safety.
- 53 The motor and servo drive emit heat while the motor is in operation. Ambient temperature may rise abnormally if used in an enclosed area. Take care to ensure that the ambient temperatures of the motor and servo driver are within the operating range.
- 54 Maintenance and inspections should be performed by a specialist.
- 55 Make sure to turn off the power supply if the device will not be used for a long period of time.
- 56 If the dynamic brake built into the servo driver is applied when the device is operating at a high speed, allow a stop time of approximately 10 minutes. Failure to do so may cause the internal circuit to disconnect or the brake to no longer be operable.
- 57 Secure the cables so that they do not put stress on the connectors, terminal block, or other connections.


- The capacitance of the capacitors of the power supply rectifier circuit will drop over time. To avoid a secondary problem due to a failure, replacement is recommended approx. every five years. Replacement must be carried out by Panasonic or an authorized dealer.
- Be sure to read operating manual (safety guide) included with product before use.

■ Servo Driver Ambient Temperature

The life span of the servo driver is largely dependent on the ambient temperature.

Make sure that the ambient temperature within 50 mm of the servo driver does not exceed the operating temperature range.

If it is not possible to measure the temperature from a distance of 50 mm, instead measure at the midpoint of the gap between the obstacle preventing measurement and the servo driver.

Front view

Operating temperature range: 0–55 °C

11 Life span

(Life span is not guaranteed.)

11.1 Expected Life span of Servo Driver

When used continuously under the following conditions, the expected life span is 28,000 hours.

Definition of life span: "Life span" is defined as the time it takes for the electrolytic capacitor to decrease in capacity by 20% once shipped from the factory.

Condition Input power supply : Single-phase AC 100 V 50/60 Hz,
Single-phase/3-phase AC 200 V 50/60 Hz
3-phase AC 400 V 50/60 Hz

Ambient temperature : 55 °C

Height above sea level : 100 m or less

Output torque: : Rated torque constant

Speed : Rated speed constant

The life span varies greatly depending on the conditions of use.

11.2 Standard Life span

■ Inrush Current Prevention Circuit

The expected life span of the inrush current prevention circuit is approximately 20,000 cycles. Note that criteria may vary depending on environmental and working conditions.

■ Cooling Fan

The standard replacement time for the cooling fan is approximately 20,000 hours. Note that criteria may vary depending on environmental and working conditions.

12 Warranty

12.1 Warranty Period

The warranty period for the product is one year from the date of purchase or one year and six months from the date the product was manufactured.

However, the warranty will be void in any of the following cases, even within the warranty period:

- 1 If the issue is due to incorrect use or improper repair/modification
- 2 If the issue is due to the device being dropped after purchase or damaged during transit
- 3 If the issue is due to the device being used outside of its specifications
- 4 If the issue is due to a fire, earthquake, lightning strike, wind/water damage, salt damage, voltage abnormalities, other natural disasters, or natural damage
- 5 If the issue is due to ingress of water, oil, metal fragments, or other foreign objects
- 6 If parts with a stated standard life span have exceeded their respective life spans

12.2 Warranty Coverage

If the product fails during the warranty period for reason in which our company is at fault, we will only replace or repair the defective parts of the device that were provided by us. Please note that our above-stated responsibility is limited to the replacement and repair of the equipment provided by us and that we do not accept any responsibility for damage to your company or any third party that may occur in connection with the failure of the equipment provided by us.

We do not accept responsibility for any equipment failures or damage to your company or any third party in the case of any of the exclusions set forth in 12-1 above or in any of the following cases:

- 1 If the equipment has been incorporated or used in a way that does not conform to the instructions or precautions set forth in this specifications document
- 2 If the issue is due to a combination of products that incorporate different equipment
- 3 If you fail to comply with the requests made to your company in this specifications document
- 4 If the equipment failure is not caused by our company's actions

12.3 Warranty Service

If you require the warranty service (fault cause investigation, repair, etc.), please contact the retailer from which you purchased the product.

If you wish to send it directly to us with the permission of the retailer, please receive a repair/investigation request form from the place of purchase, fill out the necessary information, and send it to our motor service desk along with the product.

As a general rule, you will be responsible for shipping costs.

13 Network Security

As you will use this product connected to a network, your attention is called to the following security risks.

- 1 Leakage or theft of information through this product
- 2 Unauthorized operation of this product by a malicious third party.
- 3 Interference of this product by a malicious third party.

It is the customer's responsibility to ensure that sufficient network security measures are taken, including those listed below.

We are not responsible for any damage caused by insufficient network security.

Precautions

- This product is to be used in an environment where only a limited number of parties are permitted access to the product.
- This product is not to be installed in locations where the product and its accessories, such as cables, can be easily destroyed.
- This product is to be used on a network that is not connected to the Internet.
- If an external device, such as a computer or tablet, is connected to this product, there are concerns about the effects of computer viruses and unauthorized programs.

Take appropriate security measures with external devices, such as ensuring that they are checked for computer viruses and that regularly cleaning of such viruses is performed before connecting them.

- If the product is to be disposed of, transferred, repaired, or otherwise transferred to a third party, important information may also be recorded on the product.

At customer's risk, please handle it with care, such as erasing it.

14 Additional Precautions

- 1 Precautions to be taken when exporting the product or equipment incorporating the product
If the end user or end use of this product is related to the military or weaponry, etc., it may be subject to export restrictions as set forth in the Foreign Exchange and Foreign Trade Act. When exporting, please review and follow the necessary export procedures.
- 2 This product is designed for general industrial use. This product is not for use in devices critical to human wellbeing or in specialized environments, such as nuclear power control, aerospace equipment, transportation systems, medical equipment, various safety devices, or equipment that requires a high degree of cleanliness.
- 3 Please ensure that finished equipment complies with standards, laws, and regulations, and confirm that the structure, dimensions, life span, and characteristics of the product match those of your installed equipment and components.
- 4 Since it is possible, albeit unlikely, that your finished equipment will operate abnormally due to a malfunction of our product (such as due to signal disconnections, signal open phases, or operation performed outside the settings as a result of external noise or static electricity being applied), please put in place failsafes and ensure adequate safety within the operational range of your site.
- 5 Make sure to follow indications as overloading products can cause loads to collapse.
- 6 Ensure that the motor shaft is not operated without being electrically grounded, as this may lead to electrolytic corrosion of the motor bearing and increased bearing noise, depending on the machine and the installation environment.
- 7 A tightening torque appropriate for the product mounting screws should be chosen to avoid loosening or damage, taking into account the strength of the screws used and the material to which they are mounted.
- 8 Because noise immunity may be affected by wiring conditions (e.g., grounding methods, cable length, signal wire shielding), please confirm the noise immunity of your equipment.
- 9 When disposing of the servo driver or motor, treat them as industrial waste.
- 10 When disposing of batteries, insulate them with tape and dispose of them in accordance with local regulations.
- 11 In order to improve performance, etc., some components of the product might be changed within the acceptable range in the specifications document.
- 12 Changes to specifications shall be reflected in the specifications document or in a document specified by your company. If this affects the function or characteristics of the product, the specifications will be changed following a test with a prototype.
- 13 Changes in specifications may affect the price of the product.
- 14 If you require clarification on something that is not covered by this specifications document, please contact us in advance.
- 15 In the event of a problem, the two parties shall resolve the issue following consultations as set forth in this specifications document.
- 16 Depending on the nature of the failure of the product, an amount of smoke equivalent to one cigarette may be emitted.
Please consider these possibilities when using the device in cleanrooms, etc.
- 17 Do not use detergents containing benzene, thinner, alcohol, acid, or alkaline as this may cause discoloration or damage to the product's exterior.
- 18 It is the responsibility of the customer to match the linear motor with the driver, and to ensure their safe operation.
- 19 Do not reverse engineer, decompile, or disassemble this product.

■ Disclaimer on servo driver sales described in this specification

- The servo driver stated in this specification acknowledges that the Company sold it with the exchange of “Delivery Specifications”, and we will withhold the handling on the sales channel without the “Delivery Specification” interchange.
- Please understand that we can not accept any responsibility for the servo driver sold in the sales channel without the “Delivery Specifications” exchange.
- We recommend that the “Delivery Specifications” be based on the exchange with the motor manufacturer, and that the motor manufacturer should sell it in combination with our corresponding amp.
- When equipment makers purchase motors and servo drivers separately, we will exchange "Delivery Specifications" with equipment manufacturers.
- In exceptional cases, if it is difficult to exchange the above “Delivery Specifications”, we will exchange the “Delivery Specifications” with the agency and we will handle it under the responsibility of the agency.
- The servo driver described in this specification does not guarantee the operation of the motor to be driven. Also, since we can not confirm matching with the corresponding motor within our company, please confirm matching with the corresponding motor manufacturer, equipment manufacturer, agency.
- In case of occurrence of unexpected troubles in combination with the corresponding motor, we, distributor, motor manufacturer and equipment maker cooperate with each other and deal with each other.

15 Model Specifications

Product number	MADLN01NL MADLT01NM	MADLN11NL MADLT11NM	MADLN05NL MADLT05NM	MADLN15NL MADLT15NM
Power supply input	Single-phase 100 V	Single-phase 100 V	Single-phase/3-phase 200 V	Single-phase/3-phase 200 V
Maximum output current	6 A	8 A	6 A	8 A
Regenerative resistor	External	External	External	External
Auto-gain tuning function	Provided	Provided	Provided	Provided
Dynamic brake function	Provided	Provided	Provided	Provided
Operating ambient temperature	0-55 °C	0-55 °C	0-55 °C	0-55 °C
Control power supply cable	HVSF 0.75 mm ²	HVSF 0.75 mm ²	HVSF 0.75 mm ²	HVSF 0.75 mm ²
	AWG18	AWG18	AWG18	AWG18
Main power supply cable	HVSF 0.75-2.0 mm ²	HVSF 0.75-2.0 mm ²	HVSF 0.75-2.0 mm ²	HVSF 0.75-2.0 mm ²
	AWG14-18	AWG14-18	AWG14-18	AWG14-18
Ground cable	HVSF 2.0 mm ²	HVSF 2.0 mm ²	HVSF 2.0 mm ²	HVSF 2.0 mm ²
	AWG14	AWG14	AWG14	AWG14
Motor cable	HVSF 0.75-2.0 mm ²	HVSF 0.75-2.0 mm ²	HVSF 0.75-2.0 mm ²	HVSF 0.75-2.0 mm ²
	AWG14-18	AWG14-18	AWG14-18	AWG14-18
Inrush current (main power supply) (*1)	Max. 7 A	Max. 7 A	Max. 14 A	Max. 14 A
Inrush current (control power supply) (*1)	Max. 7 A	Max. 7 A	Max. 14 A	Max. 14 A
Product weight	Approx. 0.8 kg	Approx. 0.8 kg	Approx. 0.8 kg	Approx. 0.8 kg
External size	Size A	Size A	Size A	Size A

*1 When the product power supply input voltage is the 100 V specification, the current is the value calculated with the voltage as 100 V. Likewise, the current is the value calculated with the voltage as 200 V when the product power input voltage is the 200 V specification.

Product number	MBDLN21NL MBDLT21NM	MBDLN25NL MBDLT25NM	MCDLN31NL MCDLT31NM	MCDLN35NL MCDLT35NM
Power supply input	Single-phase 100 V	Single-phase/3-phase 200 V	Single-phase 100 V	Single-phase/3-phase 200 V
Maximum output current	12 A	12 A	22 A	22 A
Regenerative resistor	External	External	Built-in	Built-in
Auto-gain tuning function	Provided	Provided	Provided	Provided
Dynamic brake function	Provided	Provided	Provided	Provided
Operating ambient temperature	0-55 °C	0-55 °C	0-55 °C	0-55 °C
Control power supply cable	HVSF 0.75 mm ²	HVSF 0.75 mm ²	HVSF 0.75 mm ²	HVSF 0.75 mm ²
	AWG18	AWG18	AWG18	AWG18
Main power supply cable	HVSF 0.75-2.0 mm ²	HVSF 0.75-2.0 mm ²	HVSF 0.75-2.0 mm ²	HVSF 0.75-2.0 mm ²
	AWG14-18	AWG14-18	AWG14-18	AWG14-18
Ground cable	HVSF 2.0 mm ²	HVSF 2.0 mm ²	HVSF 2.0 mm ²	HVSF 2.0 mm ²
	AWG14	AWG14	AWG14	AWG14
Motor cable	HVSF 0.75-2.0 mm ²	HVSF 0.75-2.0 mm ²	HVSF 0.75-2.0 mm ²	HVSF 0.75-2.0 mm ²
	AWG14-18	AWG14-18	AWG14-18	AWG14-18
Inrush current (main power supply) (*1)	Max. 7 A	Max. 14 A	Max. 15 A	Max. 29 A
Inrush current (control power supply) (*1)	Max. 7 A	Max. 14 A	Max. 7 A	Max. 14 A
Product weight	Approx. 1.0 kg	Approx. 1.0 kg	Approx. 1.6 kg	Approx. 1.6 kg
External size	Size B	Size B	Size C	Size C

*1 When the product power supply input voltage is the 100 V specification, the current is the value calculated with the voltage as 100 V. Likewise, the current is the value calculated with the voltage as 200 V when the product power input voltage is the 200 V specification.

Product number	MDDL45NL MDDLT45NM	MDDL55NL MDDLT55NM	MEDLN83NL MEDLT83NM	MEDLN93NL MEDLT93NM
Power supply input	Single-phase/3-phase 200 V	Single-phase/3-phase 200 V	3-phase 200 V	3-phase 200 V
Maximum output current	24 A	40 A	60 A	80 A
Regenerative resistor	Built-in	Built-in	Built-in	Built-in
Auto-gain tuning function	Provided	Provided	Provided	Provided
Dynamic brake function	Provided	Provided	Provided	Provided
Operating ambient temperature	0-55 °C	0-55 °C	0-55 °C	0-55 °C
Control power supply cable	HVSF 0.75 mm ²	HVSF 0.75 mm ²	HVSF 0.75 mm ²	HVSF 0.75 mm ²
	AWG18	AWG18	AWG18	AWG18
Main power supply cable	HVSF 2.0 mm ²	HVSF 2.0 mm ²	HVSF 2.0 mm ²	HVSF 2.0 mm ²
	AWG14	AWG14	AWG14	AWG14
Ground cable	HVSF 2.0 mm ²	HVSF 2.0 mm ²	HVSF 2.0 mm ²	HVSF 2.0 mm ²
	AWG14	AWG14	AWG14	AWG14
Motor cable	HVSF 2.0mm ²	HVSF 2.0 mm ²	HVSF 2.0 mm ²	HVSF 3.5 mm ²
	AWG14	AWG14	AWG14	AWG12
Inrush current (main power supply) (*1)	Max. 29 A	Max. 29 A	Max. 29 A	Max. 29 A
Inrush current (control power supply) (*1)	Max. 14 A	Max. 14 A	Max. 14 A	Max. 14 A
Product weight	Approx. 2.1 kg	Approx. 2.1 kg	Approx. 2.7 kg	Approx. 2.7 kg
External size	Size D	Size D	Size E	Size E

*1 When the product power supply input voltage is the 100 V specification, the current is the value calculated with the voltage as 100 V. Likewise, the current is the value calculated with the voltage as 200 V when the product power input voltage is the 200 V specification.

Product number	MFDLNA3NL MFDLTA3NM	MFDLNB3NL MFDLTB3NM
Power supply input	3-phase 200 V	3-phase 200 V
Maximum output current	100 A	120 A
Regenerative resistor	Built-in	Built-in
Auto-gain tuning function	Provided	Provided
Dynamic brake function	Provided	Provided
Operating ambient temperature	0-55 °C	0-55 °C
Control power supply cable	HVSF 0.75 mm ²	HVSF 0.75 mm ²
	AWG18	AWG18
Main power supply cable	HVSF 3.5 mm ²	HVSF 3.5 mm ²
	AWG12	AWG12
Ground cable	HVSF 3.5 mm ²	HVSF 3.5 mm ²
	AWG12	AWG12
Motor cable	HVSF 3.5 mm ²	HVSF 3.5 mm ²
	AWG12	AWG12
Inrush current (main power supply) (*1)	Max. 22 A	Max. 22 A
Inrush current (control power supply) (*1)	Max. 14 A	Max. 14 A
Product weight	Approx. 5.2 kg	Approx. 5.2 kg
External size	Size F	Size F

*1 When the product power supply input voltage is the 100 V specification, the current is the value calculated with the voltage as 100 V. Likewise, the current is the value calculated with the voltage as 200 V when the product power input voltage is the 200 V specification.

Product number	MGDLTC3NM	MHDLTE3NM	MHDLTF3NM
Power supply input	3-phase 200 V	3-phase 200 V	3-phase 200 V
Maximum output current	165 A	240 A	360 A
Regenerative resistor	External	External	External
Auto-gain tuning function	Provided	Provided	Provided
Dynamic brake function	Provided	None	None
Operating ambient temperature	0-55 °C	0-55 °C	0-55 °C
Control power supply cable	HVSF 0.75 mm ²	HVSF 0.75 mm ²	HVSF 0.75 mm ²
	AWG18	AWG18	AWG18
Main power supply cable	HVSF 8.0 mm ²	HVSF 22 mm ²	HVSF 38 mm ²
	AWG8	AWG4	AWG2
Ground cable	HVSF 8.0 mm ²	HVSF 22 mm ²	HVSF 38 mm ²
	AWG8	AWG4	AWG2
Motor cable	HVSF 14 mm ²	HVSF 22 mm ²	HVSF 38 mm ²
	AWG6	AWG4	AWG2
Inrush current (main power supply) (*1)	Max. 66 A	Max. 66 A	Max. 66 A
Inrush current (control power supply) (*1)	Max. 15 A	Max. 15 A	Max. 15 A
Product weight	Approx. 8.2 kg	Approx. 14.2 kg	Approx. 15.2 kg
External size	Size G	Size H	Size H

*1 When the product power supply input voltage is the 100 V specification, the current is the value calculated with the voltage as 100 V. Likewise, the current is the value calculated with the voltage as 200 V when the product power input voltage is the 200 V specification.

Product number	MDDLT44NM	MDDLT54NM	MDDLT64NM	MEDLT84NM
Power supply input	3-phase 400 V	3-phase 400 V	3-phase 400 V	3-phase 400 V
Maximum output current	6.5 A	13 A	20 A	28 A
Regenerative resistor	Built-in	Built-in	Built-in	Built-in
Auto-gain tuning function	Provided	Provided	Provided	Provided
Dynamic brake function	Provided	Provided	Provided	Provided
Operating ambient temperature	0-55 °C	0-55 °C	0-55 °C	0-55 °C
Control power supply cable	HVSF 0.52 mm ²	HVSF 0.52 mm ²	HVSF 0.52 mm ²	HVSF 0.52 mm ²
	AWG20	AWG20	AWG20	AWG20
Main power supply cable	HVSF 2.0 mm ²	HVSF 2.0 mm ²	HVSF 2.0 mm ²	HVSF 2.0 mm ²
	AWG14	AWG14	AWG14	AWG14
Ground cable	HVSF 2.0 mm ²	HVSF 2.0 mm ²	HVSF 2.0 mm ²	HVSF 2.0 mm ²
	AWG14	AWG14	AWG14	AWG14
Motor cable	HVSF 2.0mm ²	HVSF 2.0mm ²	HVSF 2.0 mm ²	HVSF 2.0 mm ²
	AWG14	AWG14	AWG14	AWG14
Inrush current (main power supply) (*1)	Max. 30 A	Max. 30 A	Max. 30 A	Max. 30 A
Inrush current (control power supply) (*1)	Max. 48 A	Max. 48 A	Max. 48 A	Max. 48 A
Product weight	Approx. 2.1 kg	Approx. 2.1 kg	Approx. 2.1 kg	Approx. 2.7 kg
External size	Size D	Size D	Size D	Size E

*1 When the product power input voltage is the 400 V specification, the current is the value calculated with the voltage as 400 V (control power supply: DC 24 V).

Product number	MFDLTA4NM	MFDLTB4NM
Power supply input	3-phase 400 V	3-phase 400 V
Maximum output current	40 A	60 A
Regenerative resistor	Built-in	Built-in
Auto-gain tuning function	Provided	Provided
Dynamic brake function	Provided	Provided
Operating ambient temperature	0-55 °C	0-55 °C
Control power supply cable	HVSF 0.52 mm ²	HVSF 0.52 mm ²
	AWG20	AWG20
Main power supply cable	HVSF 3.5 mm ²	HVSF 3.5 mm ²
	AWG12	AWG12
Ground cable	HVSF 3.5 mm ²	HVSF 3.5 mm ²
	AWG12	AWG12
Motor cable	HVSF 3.5 mm ²	HVSF 3.5 mm ²
	AWG12	AWG12
Inrush current (main power supply) (*1)	Max. 30 A	Max. 30 A
Inrush current (control power supply) (*1)	Max. 48 A	Max. 48 A
Product weight	Approx. 5.2 kg	Approx. 5.2 kg
External size	Size F	Size F

*1 When the product power input voltage is the 400 V specification, the current is the value calculated with the voltage as 400 V (control power supply: DC 24 V).

Product number	MGDLTC4NM	MHDLTE4NM	MHDLTF4NM
Power supply input	3-phase 400 V	3-phase 400 V	3-phase 400 V
Maximum output current	83 A	120 A	160 A
Regenerative resistor	External	External	External
Auto-gain tuning function	Provided	Provided	Provided
Dynamic brake function	Provided	None	None
Operating ambient temperature	0-55 °C	0-55 °C	0-55 °C
Control power supply cable	HVSF 0.75 mm ²	HVSF 0.75 mm ²	HVSF 0.75 mm ²
	AWG18	AWG18	AWG18
Main power supply cable	HVSF 5.5 mm ²	HVSF 14 mm ²	HVSF 22 mm ²
	AWG10	AWG6	AWG4
Ground cable	HVSF 5.5 mm ²	HVSF 14 mm ²	HVSF 22 mm ²
	AWG10	AWG6	AWG4
Motor cable	HVSF 5.5 mm ²	HVSF 14 mm ²	HVSF 22 mm ²
	AWG10	AWG6	AWG4
Inrush current (main power supply) (*1)	Max. 32 A	Max. 32 A	Max. 32 A
Inrush current (control power supply) (*1)	Max. 48 A	Max. 48 A	Max. 48 A
Product weight	Approx. 8.2 kg	Approx. 14.2 kg	Approx. 15.2 kg
External size	Size G	Size H	Size H

*1 When the product power input voltage is the 400 V specification, the current is the value calculated with the voltage as 400 V (control power supply: DC 24 V).

Appendix List of Default Parameters

The following pages show default parameters set when the servo driver is shipped from the factory.
Operation must be confirmed for each customer machine before use and the optimal parameters set.

MODEL	MINAS-A6N (NL/NM) series common
-------	---------------------------------

* Parameter names in the table correspond to the DD motor (rotary type). For parameter names and setting values corresponding to linear motors, refer to the technical document.

* Parameter names in the table correspond to the DD motor (rotary type). For parameter names and setting values corresponding to linear motors, refer to the technical document.

PARAMETER

MODEL MINAS-A6N (NL/NM) series common

Cate	Pr.	Parameter	Default value
1	0	1st gain of position loop	Size A-C 48.0 Size D-H 32.0
	1	1st gain of velocity loop	Size A-C 27.0 Size D-H 18.0
	2	1st time constant of velocity loop integration	Size A-C 21.0 Size D-H 31.0
	3	1st filter of velocity detection	0
	4	1st time constant of torque filter	Size A-C 0.84 Size D-H 1.26
	5	2nd gain of position loop	Size A-C 48.0 Size D-H 32.0
	6	2nd gain of velocity loop	Size A-C 27.0 Size D-H 18.0
	7	2nd time constant of velocity loop integration	Size A-C 21.0 Size D-H 31.0
	8	2nd filter of velocity detection	0
	9	2nd time constant of torque filter	Size A-C 0.84 Size D-H 1.26
	10	Velocity feed forward gain	100.0
	11	Velocity feed forward filter	0
	12	Torque feed forward gain	100.0
	13	Torque feed forward filter	0
	14	2nd gain setup	1
	15	Mode of position control switching	0
	16	Delay time of position control switching	1.0
	17	Level of position control switching	0
	18	Hysteresis at position control switching	0
	19	Position gain switching time	1.0
	20	Mode of velocity control switching	0
	21	Delay time of velocity control switching	0.0
	22	Level of velocity control switching	0
	23	Hysteresis at velocity control switching	0
	24	Mode of torque control switching	0
	25	Delay time of torque control switching	0
	26	Level of torque control switching	0
	27	Hysteresis at torque control switching	0
	28	For Manufacturer use	0
	29	For Manufacturer use	0
	30	For Manufacturer use	0

Cate	Pr.	Parameter	Default value
1	31	For Manufacturer use	0
	32	For Manufacturer use	0
	33	For Manufacturer use	0
	34	For Manufacturer use	0
	35	For Manufacturer use	0
	36	For Manufacturer use	0
	37	For Manufacturer use	0
	38	For Manufacturer use	0
	39	For Manufacturer use	0
	40	For Manufacturer use	0
	41	For Manufacturer use	0
	42	For Manufacturer use	0
	43	For Manufacturer use	0
	44	For Manufacturer use	0
	45	For Manufacturer use	0
	46	For Manufacturer use	0
	47	For Manufacturer use	0
	48	For Manufacturer use	0
	49	For Manufacturer use	0
	50	For Manufacturer use	0
	51	For Manufacturer use	0
	52	For Manufacturer use	0
	53	For Manufacturer use	0
	54	For Manufacturer use	0
	55	For Manufacturer use	0
	56	For Manufacturer use	0
	57	For Manufacturer use	0
	58	For Manufacturer use	0
	59	For Manufacturer use	0
	60	For Manufacturer use	0
	61	For Manufacturer use	0

Cate	Pr.	Parameter	Default value
1	62	For Manufacturer use	0
	63	For Manufacturer use	0
	64	For Manufacturer use	0
	65	For Manufacturer use	0
	66	For Manufacturer use	0
	67	For Manufacturer use	0
	68	For Manufacturer use	0
	69	For Manufacturer use	0
	70	For Manufacturer use	0
	71	For Manufacturer use	0
	72	For Manufacturer use	0
	73	For Manufacturer use	0
	74	For Manufacturer use	0
	75	For Manufacturer use	0
	76	For Manufacturer use	0
	77	For Manufacturer use	0
	78	For Manufacturer use	0

Cate	Pr.	Parameter	Default value

Cate	Pr.	Parameter	Default value

*1 When checking directly value of parameter-file with a text data etc., it does not show the decimal point. Ex) Pr6.24 Load change compensation filter・・・Value of Panaterm : 0.53 / Value of parameter-file : 53
* Parameter names in the table correspond to the DD motor (rotary type). For parameter names and setting values corresponding to linear motors, refer to the technical document.

MODEL	MINAS-A6N (NL/NM) series common
-------	---------------------------------

[illegible]

* Parameter names in the table correspond to the DD motor (rotary type). For parameter names and setting values corresponding to linear motors, refer to the technical document.

PARAMETER

MODEL MINAS-A6N (NL/NM) series common

Cate	Pr.	Parameter	Default value	Cate	Pr.	Parameter	Default value	Cate	Pr.	Parameter	Default value	Cate	Pr.	Parameter	Default value
3	0	No use	-	3	31	No use	-								
	1	No use	-		32	For Manufacturer use	0								
	2	No use	-												
	3	No use	-												
	4	For Manufacturer use	0												
	5	For Manufacturer use	0												
	6	No use	-												
	7	No use	-												
	8	No use	-												
	9	No use	-												
	10	No use	-												
	11	No use	-												
	12	Acceleration time setup	0												
	13	Deceleration time setup	0												
	14	Sigmoid acceleration/ deceleration time setup	0												
	15	No use	-												
	16	No use	-												
	17	Selection of speed limit	0												
	18	No use	-												
	19	No use	-												
	20	No use	-												
	21	Speed limit value 1	0												
	22	Speed limit value 2	0												
	23	External scale selection	0												
	24	For Manufacturer use	0												
	25	For Manufacturer use	1												
	26	Reversal of direction of feedback scale	0												
	27	Feedback scale Z phase disconnection detection disable	0												
	28	For Manufacturer use	1												
	29	For Manufacturer use	0												
	30	No use	-												

*1 When checking directly value of parameter-file with a text data etc., it does not show the decimal point. Ex) Pr6.24 Load change compensation filter ... Value of Panaterm : 0.53 / Value of parameter-file : 53
* Parameter names in the table correspond to the DD motor (rotary type). For parameter names and setting values corresponding to linear motors, refer to the technical document.

MODEL	MINAS-A6N (NL/NM) series common
-------	---------------------------------

[illegible]

* Parameter names in the table correspond to the DD motor (rotary type). For parameter names and setting values corresponding to linear motors, refer to the technical document.

PARAMETER				MODEL		MINAS-A6N (NL/NM) series common									
Cate	Pr.	Parameter	Default value	Cate	Pr.	Parameter	Default value	Cate	Pr.	Parameter	Default value	Cate	Pr.	Parameter	Default value
5	0	No use	-	5	31	USB axis address	1	5	62	No use	-	5	93	No use	-
	1	No use	-		32	No use	-		63	No use	-		94	No use	-
	2	No use	-		33	Pulse regenerative output limit setup	0		64	No use	-		95	No use	-
	3	Denominator of pulse output division	0		34	For Manufacturer use	4		65	No use	-		96	For Manufacturer use	0
	4	Over-travel inhibit input setup	1		35	No use	-		66	Deterioration diagnosis convergence judgment time	0		97	For Manufacturer use	0
	5	Sequence at over-travel inhibit	0		36	For Manufacturer use	0		67	Deterioration diagnosis inertia ratio upper limit	0		98	No use	-
	6	Sequence at Servo-off	0		37	No use	-		68	Deterioration diagnosis inertia ratio lower limit	0		99	No use	-
	7	Sequence at main power off	0		38	No use	-		69	Deterioration diagnosis unbalanced load upper limit	0		100	No use	-
	8	LV trip selection at main power off	1		39	No use	-		70	Deterioration diagnosis unbalanced load lower limit	0		101	No use	-
	9	Detection time of main power off	70		40	No use	-		71	Deterioration diagnosis dynamic friction upper limit	0		102	For Manufacturer use	0
	10	Sequence at alarm	0		41	No use	-		72	Deterioration diagnosis dynamic friction lower limit	0				
	11	Torque setup for emergency stop	0		42	No use	-		73	Deterioration diagnosis viscous friction upper limit	0				
	12	Over-load level setup	0		43	No use	-		74	Deterioration diagnosis viscous friction lower limit	0				
	13	Over-speed level setup	0		44	No use	-		75	Deterioration diagnosis velocity setting	0				
	14*1	Motor working range setup	1.0		45	Quadrant glitch positive-direction compensation value	0		76	Deterioration diagnosis torque average time	0				
	15	Control input signal reading setup	0		46	Quadrant glitch negative-direction compensation value	0		77	Deterioration diagnosis torque upper limit	0				
	16	No use	-		47	Quadrant glitch compensation delay time	0		78	Deterioration diagnosis torque lower limit	0				
	17	No use	-		48	Quadrant glitch compensation filter setting L	0.00		79	No use	-				
	18	No use	-		49	Quadrant glitch compensation filter setting H	0		80	No use	-				
	19	No use	-		50	For Manufacturer use	0		81	No use	-				
	20	Position setup unit select	0		51	For Manufacturer use	0		82	No use	-				
	21	Selection of torque limit	1		52	For Manufacturer use	0		83	No use	-				
	22*2	2nd torque limit	500		53	For Manufacturer use	0		84	No use	-				
	23	Torque limit switching setup 1	0		54	For Manufacturer use	0		85	No use	-				
	24	Torque limit switching setup 2	0		55	For Manufacturer use	0		86	No use	-				
	25*2	Positive direction torque limit	500		56	Slow stop deceleration time setting	0		87	No use	-				
	26*2	Negative direction torque limit	500		57	Slow stop S-shape acceleration and deceleration setting	0		88	No use	-				
	27	No use	-		58	No use	-		89	No use	-				
	28	No use	-		59	No use	-		90	No use	-				
	29	For Manufacturer use	2		60	No use	-		91	No use	-				
	30	No use	-		61	No use	-		92	No use	-				

*1 When checking directly value of parameter-file with a text data etc., it does not show the decimal point. Ex) Pr6.24 Load change compensation filter ... Value of Panaterm : 0.53 / Value of parameter-file : 53
* Parameter names in the table correspond to the DD motor (rotary type). For parameter names and setting values corresponding to linear motors, refer to the technical document.

PARAMETER				MODEL		MINAS-A6N (NL/NM) series common									
Cate	Pr.	Parameter	Default value	Cate	Pr.	Parameter	Default value	Cate	Pr.	Parameter	Default value	Cate	Pr.	Parameter	Default value
6	0	No use	-	6	31	Real time auto tuning estimation speed	1	6	62	1st resonance attenuation ratio	0	6	93	No use	-
	1	No use	-		32	Real time auto tuning custom setup	0		63*1	1st anti-resonance frequency	0		94	No use	-
	2	Velocity deviation excess setup	0		33	No use	-		64	1st anti-resonance attenuation ratio	0		95	No use	-
	3	For Manufacturer use	0		34*1	For Manufacturer use	0		65*1	1st response frequency	0		96	No use	-
	4	No use	-		35*1	For Manufacturer use	0.10		66*1	2nd resonance frequency	0		97	Function expansion setup 3	0
	5*1	Position 3rd gain valid time	0		36	Dynamic brake operation input setup	0		67	2nd resonance attenuation ratio	0		98	Function expansion setup 4	0
	6	Position 3rd gain scale factor	100		37*1	Oscillation detecting level	0		68*1	2nd anti-resonance frequency	0		99	No use	-
	7	Torque command additional value	0		38	Warning mask setup	4		69	2nd anti-resonance attenuation ratio	0		100	No use	-
	8	Positive direction torque compensation value	0		39	Warning mask setup2	0		70*1	2nd response frequency	0		101	No use	-
	9	Negative direction torque compensation value	0		40	No use	-		71	3rd damping depth	0		102	No use	-
	10	Function expansion setup	16		41	1st damping depth	0		72	4th damping depth	0		103	No use	-
	11	For Manufacturer use	100		42*1	Two-stage torque filter time constant	0		73*1	Load estimation filter	0		104	No use	-
	12	No use	-		43	Two-stage torque filter attenuation term	0		74*1	Torque compensation frequency 1	0		105	Excessive position deviation warning setting	0
	13	No use	-		44	No use	-		75*1	Torque compensation frequency 2	0				
	14	Emergency stop time at alarm	200		45	No use	-		76	Load estimation count	0				
	15	2nd over-speed level setup	0		46	No use	-		77	No use	-				
	16	No use	-		47	Function expansion settings 2	1		78	No use	-				
	17	No use	-		48*1	Adjust filter	A:1.1 B-C:1.2 D-H:1.7		79	No use	-				
	18*1	Power-up wait time	0		49	Adjust/Torque command attenuation term	15		80	No use	-				
	19	For Manufacturer use	0		50*1	Viscous friction compensation gain	0		81	No use	-				
	20	For Manufacturer use	0		51	Immediate cessation completion wait time	0		82	No use	-				
	21	For Manufacturer use	0		52	For Manufacturer use	0		83	No use	-				
	22	A, B phase feedback scale pulse output method selection	0		53	For Manufacturer use	0		84	No use	-				
	23	Load change compensation gain	0		54	For Manufacturer use	0		85	Condition setting for escape operation	0				
	24*1	Load change compensation filter	0.53		55	No use	-		86	Alarm setting for escape operation	0				
	25	For Manufacturer use	Size A-G 0 Size H 500		56	No use	-		87	For Manufacturer use	0				
	26	For Manufacturer use	2		57	Torque saturation anomaly detection time	0		88	For Manufacturer use	0				
	27	Warning latch state setup	0		58	For Manufacturer use	0		89	No use	-				
	28	No use	-		59	For Manufacturer use	0		90	No use	-				
	29	No use	-		60	2nd damping depth	0		91	No use	-				
	30	For Manufacturer use	0		61*1	1st resonance frequency	0		92	No use	-				

*1 When checking directly value of parameter-file with a text data etc., it does not show the decimal point. Ex) Pr6.24 Load change compensation filter ... Value of Panaterm : 0.53 / Value of parameter-file : 53
* Parameter names in the table correspond to the DD motor (rotary type). For parameter names and setting values corresponding to linear motors, refer to the technical document.

MODEL	MINAS-A6N (NL/NM) series common
-------	---------------------------------

[illegible]

* Parameter names in the table correspond to the DD motor (rotary type). For parameter names and setting values corresponding to linear motors, refer to the technical document.

MODEL	MINAS-A6N (NL/NM) series common
-------	---------------------------------

*1 When checking directly value of parameter-file with a text data etc., it does not show the decimal point. Ex) Pr6.24 Load change compensation filter ... Value of Panatorm : 0.53 / Value of parameter-file : 53

* Parameter names in the table correspond to the DD motor (rotary type). For parameter names and setting values corresponding to linear motors, refer to the technical document.

* Parameter names in the table correspond to the DD motor (rotary type). For parameter names and setting values corresponding to linear motors, refer to the technical document.

MODEL	MINAS-A6N (NL/NM) series common
-------	---------------------------------

[illegible]

* Parameter names in the table correspond to the DD motor (rotary type). For parameter names and setting values corresponding to linear motors, refer to the technical document.

PARAMETER

MODEL MINAS-A6N (NL/NM) series common

Cate	Pr.	Parameter	Default value	Cate	Pr.	Parameter	Default value	Cate	Pr.	Parameter	Default value	Cate	Pr.	Parameter	Default value
15	0	For Manufacturer use	0	15	31	For Manufacturer use	5								
	1	No use	-		32	No use	-								
	2	No use	-		33	For Manufacturer use	0								
	3	No use	-		34	For Manufacturer use	0								
	4	No use	-		35	For Manufacturer use	1								
	5	No use	-												
	6	No use	-												
	7	No use	-												
	8	No use	-												
	9	No use	-												
	10	No use	-												
	11	No use	-												
	12	No use	-												
	13	No use	-												
	14	No use	-												
	15	No use	-												
	16	For Manufacturer use	2												
	17	For Manufacturer use	4												
	18	No use	-												
	19	No use	-												
	20	No use	-												
	21	No use	-												
	22	No use	-												
	23	No use	-												
	24	No use	-												
	25	No use	-												
	26	No use	-												
	27	No use	-												
	28	No use	-												
	29	No use	-												
	30	For Manufacturer use	0												

*1 When checking directly value of parameter-file with a text data etc., it does not show the decimal point. Ex) Pr6.24 Load change compensation filter ... Value of Panaterm : 0.53 / Value of parameter-file : 53
* Parameter names in the table correspond to the DD motor (rotary type). For parameter names and setting values corresponding to linear motors, refer to the technical document.