

Document No. : SX-DSV03068

Revision No. : 1.4

Date of Issue : Apr. 1, 2022

Classification : ☐ New ☒ Change

SPECIFICATIONS

Product Name : AC servo driver
Product Series Name : MINAS-A5 series M Size
Product Model Number :

Motion Control Business Unit, Industrial Device Business Division
Panasonic Industry Co., Ltd.
7-1-1 Morofuku, Daito—City, Osaka 574-0044, Japan

If you have any questions, please contact the seller (Sales office or Distributor) of the product.

Panasonic

REVISIONS

[illegible]

Contents

1. Scope.....	1
2. Model Number.....	2
3. Applicable Motor.....	2
4. Basic Specifications.....	3
5. Dimensions.....	4
6. Appearance and Part Names	5
7. Connectors	6
7-1 Power Supply Connectors CN102 , CN103	6
7-2 Moter Connector CN101	6
7-3 Encoder Connector CN104	6
7-4 USB Connector CN7	7
7-5 RS232/RS485 Connector CN4	8
7-6 I/O Connector CN1	9
8. Wiring	13
8-1 Cables and Maximum Lengths	13
8-2 Cable Side Connectors	13
8-3 Precautions for Wiring	14
9. Safety Precautions.....	18
10. Life and Warranty	22
10-1 Life Expectancy of the Driver	22
10-2 Warranty Period	22
11. Others	23

[Appendix]

- Specification for Each Model
- I/O connector (CN1) default function allocation
- Differences of Specification
- Optional Parts
- Default value of the parameters
- The maximum value of Torque limit setup

1. Scope

The specifications are for AC servo driver MINAS-A5 Series M size model made by Motion Control Business Unit, Panasonic Industry Co., Ltd.

This product is for industrial equipment.
It cannot be used in the general household

<Software version>

This document applies to the servo drivers of the following software version:

Ver.3.10

For the software version, confirm it by the setup support software PANATERM or other function.

<Related documents>

SX-DSV03121: Technical document

<IMPORTANT>

- All rights reserved. No part of this publication may be reproduced or transmitted in any form without prior permission.
- Motion Control Business Unit, Panasonic Industry Co., Ltd. reserves the right to make modifications and improvements to its products and/or documentation, including specifications and software, without prior notice.


Operating Precautions

Pay a special attention to following items in order to prevent failure and degradation of the product.

- Implement the measure against static electricity and handle it with great caution.
- Do not touch a electronic components except the heat sink of the product when installing and carrying it.
- Do not touch edge and corner of the connector and printed-circuit board of the driver.
- When the equipment is energized, do not touch the driver.
- Install in a metal control box in order to prevent malfunction by noises, such as an electromagnetic interference (EMI).
- Prevent foreign matter from getting into the product.
- Do not give an impact shock to the product.
- Do not put a foreign matter into the servo driver.
- Do not add stress, such as a twist and bending, to the printed-circuit board of the product. Fix the cable so that stress is not added to the printed-circuit board and the connector of the product.

2. Model Number

The following shows how to interpret a Model number.



3. Applicable Motor

Driver			Applicable motor			
Model No.	Size	Power Supply	Model No.	Rated power	Rated speed [r/min]	Encoder specification
MMDKT2C09E	M	DC 24 V	MMMA1ACF**	10 W	3000	20 bit absolute encoder
			MMMA2ACF**	20 W	3000	20 bit absolute encoder
			MMMA3ACF**	30 W	3000	20 bit absolute encoder
			MNMA2ACF**	20 W	3000	20 bit absolute encoder
MMDKT2B09E	M	DC 48 V	MMMA1ABF**	10 W	3000	20 bit absolute encoder
			MMMA2ABF**	20 W	3000	20 bit absolute encoder
			MMMA3ABF**	30 W	3000	20 bit absolute encoder
			MNMA2ABF**	20 W	3000	20 bit absolute encoder

4. Basic Specifications

Item				Description	
Input power supply (Note 1)	DC24 V	Voltage permission ripple		DC24 V ±10 %	
		Capacity of power supply	Applicable motor	MMMA 10W	Rated current: 1.8 Arms Max current: 13 Ao-p
				MMMA 20W	Rated current: 3.1 Arms Max current: 11 Ao-p
				MMMA 30W	Rated current: 3.5 Arms Max current: 12 Ao-p
				MNMA 20W	Rated current: 3.1 Arms Max current: 14 Ao-p
	DC48 V	Voltage permission ripple		DC48 V ±10 %	
		Capacity of power supply	Applicable motor	MMMA 10W	Rated current: 0.9 Arms Max current: 6 Ao-p
				MMMA 20W	Rated current: 1.6 Arms Max current: 11 Ao-p
				MMMA 30W	Rated current: 1.9 Arms Max current: 11 Ao-p
				MNMA 20W	Rated current: 1.5 Arms Max current: 9 Ao-p
Conditions	Temperature		Operation temperature: 0-55 degrees C Storage temperature: -20-65 degrees C Guarantee the maximum temperature: 80 degrees C 72 hours No condensation. (Note 2)		
	Humidity		Operation and storage humidity 20-85 %RH or less No condensation. (Note 2)		
	Height above the sea		1,000 meters or less		
	Vibration		5. 88 m/s ² or less, 10-60 Hz Continuous operation at resonance point is not allowed.(Note 3)		
Protection rating				IP00 (Note 4)	

(Note 1) DC power using stabilized power supply (SELV) are provided with reinforced insulation.

Do not exceed the voltage including rippl of DC power is supply voltage range of the servo driver.

Capacity of power supply depends on a applicable motor and a load.

(Note 2) Easier condensation occurs when the temperature is reduced.


(Note 3) Do not install in a flexible region.

(Note 4) Protection rating of this servo driver is IP00 (No protection).

Make sure not to put the electric static discharge or the foreign matters such as dust when installing or handling the driver.


5. Dimensions

Size M



Unit : mm


6. Appearance and Part Names



7. Connectors

7-1 Power Supply Connectors CN102, CN103

Servo driver side: Molex 556902-A2210, Plating: TIN (or equivalent)

Pin No.	Symbol	Description	Pin location
1	P (+ Line)	<ul style="list-style-type: none"> • Input DC24 V, DC48 V. • DC power source using a stabilized power supply are provided with reinforced insulation. 	
2	N (- Line)		

* There is no anti-reverse connection function on the driver.

Reverse connection is caused of failure.


Pay enough attention to the power supply wiring.

* This servo driver has two power connectors, in order to install two or more daisy chain connection.

In that case, be sure not to exceed the maximum current (9 A) of these connectors.


7-2 Motor Connector CN101

Servo driver side: 2-1445054-4, Plating: TIN (or equivalent)

Pin No.	Symbol	Description	Pin location
1	U	Connect U phase of the motor winding	
2	V	Connect V phase of the motor winding	
3	W	Connect W phase of the motor winding	
4	FG	Connect ground wire of the motor	

7-3 Encoder Connector CN104

Servo driver side: Tyco Electronics 3-794678-6, Plating: GOLD (or equivalent)

Pin No.	Symbol	Description	Pin location
1	NC	NC (No connection)	
2	PS	Encoder signal input / output (serial signal)	
3	$\overline{\text{PS}}$		
4	E5V	Power supply output	
5	E0V		
6	FG	Frame ground	

7-4 USB Connector CN7

Servo driver side: J. S. T. Mfg. UB-M5BR-DMP14-4S, Plating: GOLD (or equivalent)

By connecting to the PC through USB interface, various operations such as setting / changing of parameters, monitoring of control state, referencing of error/history, and saving/loading of parameters can be performed.

Pin No.	Symbol	Description
1	VBUS	USB communication signal
2	D-	
3	D+	
4	-	NC (No connection)
5	GND	Signal ground

<About the USB cable>

Use a commercial-release USB cable with a ferrite core.

Connector of the servo driver side is a mini-B.

For the connector of a computer side, use it united with the specification of the computer to be used.


7-5 RS232/RS485 Connector CN4

Servo driver side: J. S. T. Mfg. CIF-HS08SS-072-TB equivalent, Plating: GOLD (or equivalent)

Pin No.	Symbol	Name	Description
1	GND	Signal ground	• Signal ground
2	-	NC	• Do not connect
3	TXD	RS232 signal	• Serial Bus transmission and reception data (RS232)
4	RXD		
5	485-	RS485 signal	• Serial Bus transmission and reception data (RS485)
7			
6	485+		
8			
Shell	FG	Frame ground	• Frame ground

7-6 I/O Connector **CN1**

Servo driver side: Tyco Electronics. 5-794678-0, Plating: GOLD (or equivalent)

**Input**

Pin No.	Name	Symbol	Description	I/O type
1	Power supply input	COM+	<ul style="list-style-type: none"> Connect to the + terminal of an external DC power supply (12 to 24 V) Use a 12 V (+/- 5 %) to 24 V (+/- 5 %) power supply 	-
2	Multi-function input 1	SI1	<ul style="list-style-type: none"> The function changes according to the parameter settings. See below. 	i-1
9	Multi-function input 4	SI4		
7	Multi-function input 7	SI7		
8	Multi-function input 10	SI10		

Functions allocatable to Multi-function inputs

Name	Symbol	Description
Servo ON	SRV-ON	<ul style="list-style-type: none"> When turned ON, the servo is turned on (power is supplied to the motor). When turned OFF, the servo is turned off and the motor power is turned off.
Control mode switch	C-MODE	<ul style="list-style-type: none"> Switches the control modes.
Positive overtravel limit	POT	<ul style="list-style-type: none"> Positive overtravel limit. Make sure to connect this so that the contact point will be opened when the movable module positively exceeded the movable range. When this input is OFF, a positive torque does not occur.
Negative overtravel limit	NOT	<ul style="list-style-type: none"> Negative overtravel limit. Make sure to wire this input to be activated as the work over travels the limit in the negative direction. When this input is OFF, a negative torque does not occur.
Deviation counter clear	CL	<ul style="list-style-type: none"> Clears the position deviation counter.
Command pulse inhibition	INH	<ul style="list-style-type: none"> Ignores the position command pulse.
Preset velocity 1	INTSPD1	<ul style="list-style-type: none"> Preset speed. Allows you to set up to 8 internal velocities by combining INTSPDs 1 - 3.
Preset velocity 2	INTSPD2	
Preset velocity 3	INTSPD3	
Speed zero clamp	ZEROSPD	<ul style="list-style-type: none"> Sets the speed command to zero.
Anti-vibration switch 1	VS-SEL1	<ul style="list-style-type: none"> Switches the applied frequencies for anti-vibration control.
Anti-vibration switch 2	VS-SEL2	
Gain switch	GAIN	<ul style="list-style-type: none"> Input to switch the gains.
Torque limit switch	TL-SEL	<ul style="list-style-type: none"> Switches the torque limits.
Alarm clear	A-CLR	<ul style="list-style-type: none"> Digital input to clear the alarm.
Command scaling switch	VC-SIGN	<ul style="list-style-type: none"> Specifies the sign of the speed command during the speed control.
Torque command sign	TC-SIGN	<ul style="list-style-type: none"> Do not use.
Command scaling switch 1	DIV1	<ul style="list-style-type: none"> Switches the scaling numerators of the command pulse. Allows you to switch up to 4 numerators by combining DIVs 1, 2.
Command scaling switch 2	DIV2	
Forced alarm input	E-STOP	<ul style="list-style-type: none"> Generates Err87. 0 "Abnormal forced alarm input."
Inertia ratio switch	J-SEL	<ul style="list-style-type: none"> Switches the inertia ratios.

“Deviation counter clear (CL)” can only be assigned to the SI7.

“Command pulse inhibition(INH)” can only be assigned to the SI10.

Input signals (command pulse train) and their functions

A suitable interface can be chosen from “A. Pulse train interface with line driver” .

A. Pulse train interface with line driver

Pin No.	Symbol	Name	Description	Circuit
3	PULSH1	Command pulse input 1	<ul style="list-style-type: none">• Input terminal for the position command pulse. It can be selected by setting corresponding parameters.• Disabled in such control modes as the speed control or the torque control, which does not require position commands.• The maximum allowable input frequency is 4 Mpps.	Di-2
4	PULSH2			
5	SIGNH1	Command direction input 1		
6	SIGNH2			

Output

Pin No.	Symbol	Name	Description	Circuit
11	SO1	Multi-function output 1	• The function changes according to the parameter settings. See below.	o-1
10	SO2	Multi-function output 2		
12	COM-	Power supply input	<ul style="list-style-type: none"> • Connect to the + terminal of an external DC power supply (12 to 24 V) • The power capacity varies depending on a composition of I/O circuit. 0.5 A or more is recommended. 	—

Functions allocatable to Multi-function outputs

Name	Symbol	Description
Servo Alarm	ALM	• Digital output to indicate the drive is in alarm status..
Servo ready	S-RDY	• Digital output to indicate the drive is ready to be enabled.
Motor holding break release	BRK-OFF	• Digital output to provide the timing signal to control the motor holding brake.
Zero speed	ZSP	• Outputs the zero speed detection signals.
Torque limited	TLC	• Outputs the torque limit signal.
In-position	INP	• Outputs the positioning completion signal.
Positioning completion 2	INP2	• Outputs the positioning completion signal 2.
At speed	AT-SPD	• Outputs the at-speed signal.
V-COIN	V-COIN	• Outputs the speed coincidence signal.
Warning output 1	WARN1	• Outputs the warning output signal configured in Pr4. 40 "Warning output selection 1".
Warning output 2	WARN2	• Outputs the warning output signal configured in Pr4. 41 "Warning output selection 2".
Position command ON/OFF	P-CMD	• Outputs meaning positional command applied.
Speed in –limit output	V-LIMIT	• Outputs meaning the speed is limited at torque control mode.
Alarm attribute output	ALM-ATB	• Outputs meaning occur an alarm that can be cleared.
Servo on status output	SRV-ST	• Turns on output transistor when servo is on.

Output signals (Pulse output) and its function


Pin No.	Symbol	Name	Description	Circuit
14	OA+	A phase output	<ul style="list-style-type: none">• Scaling processed encoder signal or external scale signal (A/B/Z-phase) is output in differential mode. (RS422 equivalent)• Scaling ratio can be set by parameters.• The ground pin of the line driver on the output circuit is not insulated and is connected to signal ground (GND).• The maximum output frequency is 4 Mpps (after quadrature).	Do-1
15	OA-			
16	OB+	B phase output		
17	OB-			
18	OZ+	Z phase output		
19	OZ-			

Other


Pin No.	Symbol	Name	Description	I/O type
13	GND	Signal ground	• Signal ground • Internally insulated from the control signal power supply (COM-).	-
20	FG	Frame ground	• Connected to the Frame ground inside the servo driver.	-

I/O type


i-1




o-1



Do-1



Di-1



8. Wiring

8-1 Cables and Maximum Lengths

Name	Symbol	Maximum cable length	Cable
Power connection	CN102 CN103	-	AWG 18
Motor connection	CN101	3 m	AWG 20
Encoder connection	CN104	3 m	Overall twisted shielded pair Core wire: 0.18 mm ² or larger
I/O connection	CN1	1 m	AWG 26-28

8-2 Cable Side Connectors

Symbol	Part name	Part number	Manufacturer
CN102 CN103	Connector	5557-02R	Molex
	Pin	5556TL	
CN101	Connector	1445022-4	Tyco Electronics
	Pin	794610-1	
	Connector	43645-0400	Molex
	Pin	43030-0001	
CN104	Connector	794617-6	Tyco Electronics
	Pin	1-794610-2	
	Connector	43025-0600	Molex
	Pin	43030-0002	
CN1	Connector	2-794617-0	Tyco Electronics
	Pin	1-794611-2	
CN4	Plug kit	2040008-1	Tyco Electronics

Use connectors listed above or equivalents.

8-3 Precautions for Wiring

(1) Wiring to power connector

- [1] Power connector of the servo driver is tin plated. In order to avoid a bad contact caused by dissimilar metals, connector pins for the connection, please use the tin plating.
- [2] The DC power supply might have a trip to protect its components from over-voltage that is caused by the regenerated energy from motor. In that case, it is necessary to install the diode for protecting from the feedback current and also to install the DC bus capacitor for storing the regenerated energy between the DC power supply and drivers.
- [3] So that the specified voltage at the input servo driver, consider the transient voltage drop due to the impedance wiring, select both the diameter of the power line and the length.
- [4] This servo driver does not mount the inrush current limit circuit. Inrush current is dependent on the characteristics and wiring impedance of the connection power, please check the actual machine.
- [5] Because this servo driver to assume a connection with a stabilized power supply is provided with reinforced insulation, protective ground terminal is not available. M4 screw on the heat-sink is functional earth (FG).

(2) Wiring to motor connector

- [1] Motor connector of the servo driver is tin plated. In order to avoid a bad contact caused by dissimilar metals, connector pins for the connection, please use the tin plating.
- [2] For a noise countermeasure, attach the ferrite core U, V, W as necessary.

(3) Wiring to encoder connector.


- [1] Encoder connector of the servo driver is gold plated. In order to avoid a bad contact caused by dissimilar metals, connector pins for the connection, please use the gold plating.
- [2] Encoder cable is a stranded wire of core wire, please use Collective shield twisted pair cable.
- [3] Maximum cable length is 3 m. In order to meet the mitigation of the voltage drop of 5 V power supply to the encoder to long wiring, select the appropriate wire diameter.
- [4] Cable should be located well away from power cable and motor cable with large current.

(4) Wiring to I/O connector

- [1] I/O connector of the servo driver is gold plated. In order to avoid a bad contact caused by dissimilar metals, connector pins for the connection, please use the gold plating.
- [2] Do not exceed the maximum voltage and current specification of the input and output.

(5) Wiring to connector **CN1**


- [1] The 12–24 VDC power supply for the external control signal connected to the I-COM should be prepared by the customer.
 - [2] Place the servo driver and its peripheral device as nearly as possible (up to 3 m) so as to shorten the wiring.
 - [3] Wire the wiring as far away as possible (30 cm or more) from the power lines (P, N, U, V, W).
- Do not put them in the same duct or bind them together.

Input

The functions of the pins SI1, SI4, SI7, SI10 are assigned by parameters. For factory default settings, refer to Appendix “Specification for Each Model”.

Output


- [4] Be aware of the polarity of the power supply for control signals. The servo driver is damaged by reverse connection of the polarity shown in the following figure.
- [5] To directly drive the relay with each output signal, make sure to attach a diode in parallel to the relay and in the direction as shown in the figure below. The servo driver can be damaged if the diode is not attached or the diode is attached in the reverse direction.
- [6] Apply 50 mA or less of current to output.



The functions of the pins SO1, SO2 are assigned by parameters. For factory default settings, refer to Appendix “Specification for Each Model”.

(6) Wiring to connector **CN104**

- [1] As for the encoder signal cable, use the batch shielded twisted wire pairs whose core is 0.18 mm² or more.
 - [2] The cable length should be up to 3 m. When the wiring is long, we recommend you to use the double wiring for the 5 V power supply in order to reduce the impact of voltage drop.
 - [3] Make sure to connect the shield to 6pin (FG) of **CN104**.
 - [4] Wire the wiring as far away as possible (30 cm or more) from the power lines (P, N, U, V, W).
- Do not put them in the same duct or bind them together.
- [5] Do not connect anything to the empty pins of **CN104**.

In case of 20bit absolute encoder



If you wish to use in absolute encoder system, the battery for absolute encoder, please directly connected between motor side BAT- and motor side BAT+.





SAFETY PRECAUTIONS

9. Safety Precautions

- Danger and damage caused when the safety precautions are ignored are described in the following categories and signs:

 DANGER	Description of this sign indicates “urgent danger that may cause death or serious injury.”
 CAUTION	Description of this sign indicates “danger that may cause injury or property damage.”

- Rules to keep are categorized and described with the following graphics.

	This graphic indicates “Prohibited” acts that are not permitted.
	This graphic indicates “Mandatory” acts that must be performed forcibly.



DANGER



- (1) Be sure not to store or use the equipment under conditions subjected to vibrations (5.88 m/s² or heavier) or an impact shock, foreign matters such as dust, metal particles oil mist, liquids such as water, oil and polishing liquid, near flammable objects, in an atmosphere of corrosive gas (such as H₂S, SO₂, NO₂, Cl₂), or in an atmosphere of flammable gas.
- (2) Do not place any flammable objects near a motor, a servo driver.
- (3) Do not drive the motor with an external force.
- (4) Do not damage or strain the cable, or do not apply excessive stress. Do not place a heavy item on the cable or do not pinch the cable.
- (5) Do not use the equipment with the cable soaked in oil or water.
- (6) Do not install the equipment near a heating object such as a heater or a large wire-wound resistor. (Install a thermal shield, etc. to avoid the influences of heating object.)
- (7) Do not connect the motor directly with a commercial power.
- (8) Do not use the equipment under conditions subject to strong vibrations or an impact shock.
- (9) Be sure not to touch a rotating part of a motor during operation.
- (10) Please do not touch with bare hands to motor key way.
- (11) Be sure not to touch inside a servo driver.
- (12) Motor, servo driver heat sink and peripheral device become very hot. Do not touch them.
- (13) Do not carry out wiring or do not operate the equipment with wet hands.
- (14) Wiring work is strictly allowed only for an engineer specializing electrical work.



SAFETY PRECAUTIONS



- (15) A motor other than specified is not provided with a protection device. Protect a motor with an overcurrent protection device, a ground-fault interrupter, overheating protection device, and emergency stop device, etc.
- (16) When operating the servo driver after an earthquake, inspect installation conditions of the servo driver and the motor and safety of the equipment to make sure that no fault exists.
- (17) After turning off the power, the inside circuit remains charged at a high voltage for a while. When moving, wiring or inspection the equipment, completely shut off the power supply input outside the servo driver and leave for 15 minutes or longer before working.
- (18) Install and mount the equipment securely to prevent personal injury caused by poor installation or mounting on an earthquake.
- (19) Install an external emergency shutoff circuit to stop operation and interrupt power immediately upon emergency.
Emission of smoke or dust may occur due to a fault of a motor or a servo driver used in combination.
- (20) Mount the motor, the servo driver and the peripheral devices on a noncombustible material such as metal.
- (21) In consideration of strength of the screw and the material of the mounting base, select appropriate fastening torque for the product mounting screws, so that the screws will not be loosened or damaged.
Example) To tighten a steel screw into a steel base : $M5\ 2.7 - 3.3\ N \cdot m$
- (22) Provide correct and secure wiring. Insecure wiring or incorrect wiring may cause runaway or burning of a motor. During wiring work, avoid entry of conductive dust such as wire chippings in a servo driver.
- (23) Connect cables securely and provide secure insulation on current-carrying parts using insulation material.
- (24) FG screw (M4) should be tighten to a torque of $1.0 - 1.2\ N \cdot m$.



CAUTION



- (25) Do not hold cables or motor shaft when carrying the equipment.
- (26) Do not adjust or change servo driver gains extremely, and do not make operations of the machine instable.
- (27) The equipment may suddenly restart after recovery from shutdown upon a power failure. Keep away from the equipment.
Specify settings of the equipment to secure safety for human against such restart operations.
- (28) When the equipment is energized, keep away from the motor and mechanism driven by the motor in case of malfunction.
- (29) Avoid a strong shock to the motor shaft.
- (30) Avoid a strong shock to the product.
- (31) Be sure not to use the electromagnetic contactor installed on the power supply to start or stop the motor.
- (32) Avoid frequent switching on and off the main power supply of the servo driver.
- (33) The built-in brake of the motor is used for holding only. Do not use the brake to stop (braking) for securing safety of the equipment.
- (34) Do not fall or topple over the equipment when carrying or installing.



SAFETY PRECAUTIONS



CAUTION



- (35) Do not climb the motor or do not place a heavy item on the motor.
- (36) Do not put a foreign matter into the servo driver.
- (37) Do not use the equipment under direct sunlight. When storing the equipment, avoid direct sunlight and store under conditions of operating temperatures and humidity.
- (38) Be sure not to disassemble or modify the equipment.
Disassembling and repair is allowed only for the manufacturer or sales agency authorized by the manufacturer.
- (39) Please use power are provided with reinforced insulation the stabilized power supply (SELV). Do not connect the positive side and the negative side and ground (FG) of the input power of servo driver.
- (40) This servo driver is Built-in type (degree of protection IP00). Please note that during the installation so without applying static electricity. Static electricity is applied to runaway or burning, destruction, and cause of failure.

- (41) Use a motor and a servo driver in combination specified by the manufacturer. A customer shall be responsible for verifying performances and safety of combination with other servo motor.
- (42) A failure of a motor or a combined servo driver may cause burning of motor, or emission of smoke and dust. Take this into consideration when the application of the machine is clean room related.
- (43) Install the equipment adequately in consideration of output and main unit weight.
- (44) Keep the ambient conditions of an installed motor within a range of allowable ambient temperatures and of allowable humidity.
- (45) Install the equipment by specified procedures and in specified orientation.
- (46) Install the devices by keeping specified distances between a servo driver and inside control panel or other devices.
- (47) For a test run, hold down a motor and disconnect from a mechanical system to verify operations before installing on the equipmen
- (48) Verify that an input power supply voltage satisfies the servo driver specifications before turning on the power and start operation. An input voltage higher than rated may cause ignition and smoking in the servo driver, which may cause runaway or burning of a motor in some cases.
- (49) When an alarm status occurs, remove a cause of the problem before restarting.
Careless restarting without removing a cause of problem may cause malfunction or burning of a motor.
- (50) The motor may not be able to hold due to expiring useful life or a mechanical structure. Install a braking device on the equipment to secure safety.
- (51) Pay attention to heat radiation. The servo driver generates heat by operating a motor. A servo driver used in a sealed control box may cause an extreme rise of temperature.
Consider cooling so that an ambient temperature around the servo driver satisfies an operating range.
- (52) Maintenance and inspection is allowed only for a specializing person.
- (53) Turn off the power when the equipment is not used for a long term.

- Capacitance of the capacitors of power supply rectifier circuit drops over time. To avoid a secondary problem due to a failure, replacement of capacitors is recommended at an interval of approximately 5 years. Commission the manufacturer or sales agency authorized by the manufacturer to replace the parts.
- Be sure to read the operating manual (safety book) before use.



SAFETY PRECAUTIONS

Servo driver's ambient temperature

The driver's service life significantly depends on the ambient temperature.

Do measures cooling such as fan installation.

Operating temperature range: 0 to 55 degrees C

We have made the best efforts to ensure quality of this product. However, application of external noise (include radiation) or static electricity, or a defect of the input power supply, wiring or components may cause the servo driver to operate beyond the preset conditions. Therefore, you should exercise thorough caution to ensure safety against an unexpected operation.

10. Life and Warranty

10-1 Life Expectancy of the Driver

The Servo driver has 28000 hours of life expectancy when used continuously under the following conditions.

Definition of the life Life end shall be defined as the capacitance of the electrolytic capacitor is reduced by 20 % from the ex-factory status.

Condition	{	Input power source: DC 24 V or DC 48 V Ambient temperature: 55 degree C Output torque: Rated constant value No. of revolutions: Rated constant No. of revolutions
-----------	---	--

Note that the life varies due to the working conditions.

10-2 Warranty Period

(1) Warranty period

For a period of 12 months from the date of delivery or 18 months from the manufacturing month, whichever is shorter.

This warranty shall be exempted in the following cases,

- [1] defects resulting from misuse and/or repair or modification by the customer
- [2] defects resulting from drop of the product or damage during transportation
- [3] defects resulting from improper usage of the product beyond the specifications
- [4] defects resulting from fire, earthquake, lightning, flood, damage from salt, abnormal voltage or other act of God, or other disaster.
- [5] defects resulting from the intrusion of foreign material to the product, such as water, oil or metallic particles.

This warranty shall be exempted when the life of component exceeds its rated standard life.

(2) Warranty scope

Panasonic warrants the replacement of the defected parts of the product or repair of them when the defects of the product occur during the warranty period, and when the defects are under Panasonic responsibility. This warranty only covers the product itself and does not cover any damage incurred by such defects.

11. Others

- Precautions for export of this product and the equipment incorporating this product If the end user or end purpose of this product relates to military affairs, armament and so on, this product may be subject to the export regulations prescribed in “Foreign Exchange and Foreign Trade Control Law”. To export this product, take thorough examination, and follow the required export procedure.
- We cannot warrant this product, if it is used beyond the specified operating conditions.
- Compliance with the relevant standards should be considered by the user.
- The final decision on the compatibility with the installations and components at the user’s site, in terms of structure, dimensions, characteristics and other conditions, should be made by the user.
- When using this product in your equipment, be careful about the compatibility with the servo motor and the servo driver to be used together.
- For performance improvement or other reasons, some components of this product may be modified in a range that satisfies the specifications given in this document.
- Any specification change shall be based on our authorized specifications or the documents presented by the user. If a specification change may affect the functions and characteristics of this product, we will produce a trial product, and conduct examination in advance. Note that the produce price may be changed with a change in its specifications.
- We have made the best efforts to ensure the product quality. However, complete equipment at customer’s site may malfunction due to a failure of this product. Therefore, take precautions by providing fail-safe design at customer’s site, and ensure safety within the operating range of the work place.
- Failure of this product depending on its content, may generate smoke of about one cigarette. Take this into consideration when the application of the machine is clean room related.
- When the equipment runs without connecting the servomotor’s shaft electrically to ground, electrolytic corrosion may occur on the motor bearing and the bearing noise may get louder depending on the equipment and installing environment. So, customer is responsible to check and verify it.
- A customer must verify and inspect the equipment. Please be careful when using in an environment with high concentrations of sulphur or sulphuric gases, as sulphuration can lead to disconnection from the chip resistor or a poor contact connection.
- Take care to avoid inputting a supply voltage which significantly exceeds the rated range to the power supply of this product. Failure to heed this caution may result in damage to the internal parts, causing smoking and/or a fire and other trouble.
- When discard batteries, provide insulation using a tape etc. and discard the batteries abiding by a municipal law.
- When discarding the equipment, process the item as an industrial waste.
- Confirmation of safety and matching of the servo amplifier and motor, execute the responsibility of your company.
- This production is designed for general industry applications, and is not designed for applications of nuclear plant, aerospace, transportation, medical, various safety equipment, highly clean equipment that involve human lives, or for usage under special environment.

【Exemption clause regarding with distribution of drive specified on this spec.】

- Product responsibility will be owned by the publisher of this specification regarding with the drive on this specification, when product had been supplied to the party which agreed to this specification.
- Product responsibility will not be owned by the publisher of this specification when product had gone through the channel or end user which had not conducted the specification agreement.
- Publisher recommends that the drive is to be supplied with the motor manufacture with its motor, based on this specification being agreed with the motor manufacture.
- Specification is to be agreed with the machine manufacture, when the machine manufacture intends to procure the drive and motor separately.
- When in case the agreement of this specification becomes difficult, then we will supply the drive based on the responsibility of the distributor who has agreed to this specification.
- This specification does not assure the operation of the motor matched to the drive specified by this specification. Publisher does not confirm the matching of the motor to drive, and therefore please take extra care in confirming the matching to the motor by equipment manufacture, distributor, or motor manufacture.
- When an unexpected trouble occurs at the matching of motor, distributor, motor manufacture, and machine manufacture is to correspond the trouble in good faith.

Specification for Each Model

● MINAS-A5 Series Size M

Model	MMDKT2C09E	MMDKT2B09E
Power supply input	DC24 V	DC48 V
Maximum instantaneous output current	15 A	15 A
Maximum continuous output current	9 A	9 A
Regenerative processing function	Unprovided	Unprovided
Auto gain tuning function	Provided	Provided
Dynamic brake function	Provided	Provided
Ambient temperature	0–55 degrees C	0–55 degrees C
Main power supply cable	HVSF 0.75–2.0 mm ²	HVSF 0.75–2.0 mm ²
	AWG 14–18	AWG 14–18
Ground cable	HVSF 2.0 mm ²	HVSF 2.0 mm ²
	AWG 14	AWG 14
Motor cable	HVSF 0.50 mm ²	HVSF 0.50 mm ²
	AWG 20 (5 A rated)	AWG 20 (5 A rated)
Inrush Current	No limit by driver	No limit by driver
Weight	Approx. 0.2 kg	Approx. 0.2 kg
Dimensions	Size M	Size M

I/O connector (CN1) default function allocation

CN1 connector		Default function			
Name	Pin number	Signal name	Default value (): in decimal	Symbol	Logic
SI1	2	Servo ON	00030303h (197379)	SRV-ON	NO contact
SI4	9	Alarm clear	00040404h (65793)	A-CLR	NO contact
SI7	7	Deviation counter clear	00000007h (7)	CL	NO contact
SI10	8	Gain switch	00060606h (394758)	GAIN	NO contact
SO1	11	In-position	00000004h (4)	INP	-
SO2	10	Servo alarm	00010101h (65793)	ALM	-

Differences of Specification

This servo driver differs in the following specification to SX-DSV03121 Technical document.

■Basic Specifications

Control mode		Selectable from the following 3 modes by parameter: [1]position control [2]internal velocity control [3]position/internal velocity control
Encoder feedback		20bit(resolution:1048576) 7-serial incremental encoder
External scale feedback		Not Available
Control signal	Input	Multi-function input x 4 Function of each multi-function input is assigned by the parameter.
	Output	Multi-function output x 2 Function of each multi-function output is assigned by the parameter.
Analogue signal	Input	Not Available
	Output	Not Available
Pulse signal	Input	1 inputs Line driver interface can be connected.
	Output	4 outputs Line driver output for Encoder pulses (A/B/Z signal).
Communication	USB	USB interface to connect to computers for parameter setting or status monitoring.
	RS232	1:1 communication *1
	RS485	1: n communication (max 31) *1
Safety Terminal		Not Available
Front Panel		Not Available
Regeneration		Not Available
Dynamic Brake		Built-in (short U-W)

*1 In the case of size M, A5E** series is equipped with a communication function.

■LED

In case of size M, A5 series does not have the LED panel.

Instead, size M is equipped with LED to check state.

SON

LED		Description
LED502 (Green)	Turn ON	Servo ON
	Turn OFF	Servo OFF

SO3

LED		Description
LED501 (Red)	Turn ON	Alarm
	Turn OFF	Normal

LED (SO3) is the possible to change function in the parameters.

LED (SO3) is set alarm at the default parameter.

This servo driver does not support the following protective and warning functions.


■ Protective functions

Error No.		Description
Main	Sub	
13	1	Main power supply under voltage protection
14	1	IPM error protection
18	0	Over-regeneration load protection
	1	Over-regeneration Tr error protection
25	0	Hybrid deviation excess error protection
28	0	Limit of pulse replay error protection
29	1	Deviation counter overflow protection 1
30	0	Safety detection
50	0	Feedback scale connection error protection
	1	Feedback scale communication error protection
51	0	Feedback scale status 0 error protection
	1	Feedback scale status 1 error protection
	2	Feedback scale status 2 error protection
	3	Feedback scale status 3 error protection
	4	Feedback scale status 4 error protection
	5	Feedback scale status 5 error protection
55	0	A-phase connection error protection
	1	B-phase connection error protection
	2	Z-phase connection error protection
92	1	Feedback scale data restoration.
93	2	Parameter setting error protection 2
	3	Feedback scale abnormal connection error protection

■ Warning functions

	Warning No. (Hex.)	Description
General warning	A1	Over-regeneration warning
	A3	Fan warning
	A8	External scale error alarm
	A9	External scale communication alarm
Extended warning	C3	Main power off warning

■ Time characteristics of overload protection



The above drawing describes time characteristics of driver of overload protection at using MMMA 10W motor, 20 W motor, 30 W motor and MNMA 20 W motor.

* Use the motor so that actual torque stays in the continuous running range shown in “S-T characteristic” of the motor.
For the S-T characteristics, see Specification of the motor..

Optional Parts

Please contact Panasonic or authorized retailer for optional parts below.

Part location	Part number	Part name	Description
Power Connector CN102 CN103	DV0PM24600	Power cable	A cable with connector 5557-02R[MOLEX] on one end. (Length : around 2M)
	DV0PM24603	Connector kit for power cable	<ul style="list-style-type: none"> • Connector 5557-02R[MOLEX] (1pc) • Connector pin 5556L[MOLEX](2pc) A connector set of the above item
I/O Connector CN1	DV0PM24601	I/O Cable	A cable with connector 2-794617-0[TE] on one end. (Length : around 1M)
	DV0PM24609	Connector Kit for I/O cable	<ul style="list-style-type: none"> • Connector 2-794617-0[TE](1pc) • Connector 1-794611-2(2pc) A connector set of the above item.
Serial Bus Connector CN4	DVP0M20024	RS232/485 Connector	Connector Kit 2040008-1[TE](1pc).
	DV0PM20102		Connector Kit CIF-PCNS08KK-072R[JST](1pc).
Motor Connector CN101	MFMCG0036EEF	Motor cable	A cable with connector 1445022-4[TE] on one end and connector 172159-1[TE] on the other end. (Length : around 3 m)
	DV0PM24605	Motor connector kit	<ul style="list-style-type: none"> • Connector 1445022-4[TE](1pc) • Connector pin 172159-1[TE](4pc) A connector set of the above item. ※For servo drive side only.
Encoder Connector CN104	MFECA0030EAH	Absolute encoder cable (With battery case)	A cable with connector 794617-6[TE] on one end and connector 172161-1[TE] on the other end. (Length : around 3 m) A Panasonic battery case come with the cable.
	MFECA0030EAG	Absolute encoder cable (Without battery case)	A cable with connector 794617-6[TE] on one end and connector 172161-1[TE] on the other end. (Length : around 3 m)
	DV0PM24604	Connector kit for encoder	<ul style="list-style-type: none"> • Connector 794617-6[TE](1pc) • Connector pin 1-794610-2[TE](6pc) A connector set of the above item. ※For servo drive side only.
Connector For Motor Side.	DV0PM24607	Connector kit for motor encoder connection.	<ul style="list-style-type: none"> • Connector 172159-1[TE](1pc) • Connector pin 170366-1[TE](4pc) • Connector 172161-1[TE](1pc) • Connector pin 170365-1[TE](9pc) A connector set of the above item. ※For motor side only.
Absolute Encoder	DV0P2990	Battery for absolute encoder	Lithium battery : 3.6 V 2000 mAh ※When shipment by air (commercial or cargo aircraft), there are situations where this item must be declared. When shipment by air please inquire with airlines.
Battery Case	DV0P4430	Battery case for absolute encoder	A case for absolute encoder battery to fit in to encoder cable.

※There are situations where connector will be replaced by a compatible one.

* TE: Tyco Electronics AMP

* JST: JST Group

PARAMETER				MODEL		MMDKT2C09E / MMDKT2B09E													
Cate gory	Pr.	Parameter	Default value	Cate gory	Pr.	Parameter	Default value	Cate gory	Pr.	Parameter	Default value	Cate gory	Pr.	Parameter	Default value				
0	0	Reference direction	1	1	13	Torque feed forward filter	0.00	2	16	Anti-vibration frequency 2	0.0	3	23 *2	External scale type selection	0	4	24 *2	Max analog input 1 (AI1)	0.0
	1	Control mode	0		14	Second gain enable	1		17	Anti-vibration filter configuration 2	0.0		24 *2	External scale scaling numerator	0		25 *2	Analog input 2 (AI2) offset	0
	2	RTAT mode	1		15	Gain switching mode for position	0		18	Anti-vibration frequency 3	0.0		25 *2	External scale scaling denominator	10000		26 *2	Analog input 2 (AI2) filter	0.00
	3	Mechanical stiffness for RTAT	13		16	Gain switching delay for position	5.0		19	Anti-vibration filter configuration 3	0.0		26 *2	External scale direction	0		27 *2	Max analog input 2 (AI2)	0.0
	4	Inertia ratio	250		17	Gain switching level for position	50		20	Anti-vibration frequency 4	0.0		27 *2	Disconnected wiring detection disable for external scale Z phase	0		28 *2	Analog input 3 (AI3) offset	0
	5	Command pulse mode	1		18	Gain switching hysteresis for position	33		21	Anti-vibration filter configuration 4	0.0		28 *2	Max hybrid deviation	16000		29 *2	Analog input 3 (AI3) filter	0.00
	6	Command pulse counting direction	0		19	Position loop gain switching time	3.3		22	First order filter time constant for position command	0.0		29 *2	Hybrid deviation clearing revolution	0		30 *2	Max analog input 3 (AI3)	0.0
	7	Command pulse input mode setting	1		20	Gain switching mode for velocity	0		23	FIR filter time constant for position command	0.0	4	0	SI1 input assignment	197379		31	In-position range	10
	8	Command pulse resolution	10000		21	Gain switching delay for velocity	0.0	3	0 *2	Velocity command type	1		1 *2	SI2 input assignment	0		32	In-position output configuration	0
	9	First command division/ multiplication numerator	0		22	Gain switching level for velocity	0		1	Velocity command direction source	0		2 *2	SI3 input assignment	0		33	INP hold time	0
	10	Command scaling denominator	10000		23	Gain switching hysteresis for velocity	0		2	Velocity command gain	500		3	SI4 input assignment	263172		34	Zero speed	50
	11	Number of output pulses per motor revolution	2500		24 *2	Gain switching mode for torque	0		3 *2	Velocity command polarity	1		4 *2	SI5 input assignment	0	35	Velocity coincidence width	50	
	12	Output pulse logic	0		25 *2	Gain switching delay for torque	0.0		4	1st speed	0		5 *2	SI6 input assignment	0	36	At-speed	1000	
	13	Torque limit 1	500 *1		26 *2	Gain switching level for torque	0		5	2nd speed	0	6	SI7 input assignment	7	37	Stop time mechanical brake operation setting	0		
	14	Max position deviation	100000		27 *2	Gain switching hysteresis for torque	0		6	3rd speed	0	7 *2	SI8 input assignment	0	38	Run time mechanical brake operation setting	0		
	1	15	Absolute encoder setting		1	2	0	Adaptive filter mode	0	7	4th speed	0	8 *2	SI9 input assignment	0	39	Brake clear speed setting	30	
		16 *2	Regen resistor configuration		3		1	1st notch frequency	5000	8	5th speed	0	9	SI10 input assignment	394758	40	Warning output selection 1	0	
17 *2		External regenerative resistor selection	0		2		Notch width 1	2	9	6th speed	0	10	SO1 output assignment	4	41	Warning output selection 2	0		
0		Position loop gain 1	48.0		3		Notch depth 1	0	10	7th speed	0	11	SO2 output assignment	65793	42	Positioning completion range 2	10		
1		Velocity loop proportional gain 1	27.0		4		2nd notch frequency	5000	11	8th speed	0	12	SO3 output assignment	65793	5	0	2nd command frequency division multiplication numerator	0	
2		Velocity loop integral time constant 1	21.0		5		Notch width 2	2	12	Acceleration time	0	13 *2	SO4 output assignment	0		1	3rd command frequency division multiplication numerator	0	
3		Velocity detection filter 1	0		6		Notch depth 2	0	13	Deceleration time	0	14 *2	SO5 output assignment	0		2	Command scaling numerator 4	0	
4		Torque filter 1	0.84		7		Third notch frequency	5000	14	S-curve accel/decel time	0	15 *2	SO6 output assignment	0		3	Output pulse scaling denominator	0	
5		Position loop gain 2	57.0	8	Notch width 3		2	15	Speed zero clamp select	0	16 *2	Analog monitor 1 type	0	4		Overtravel input configuration	1		
6		Velocity loop proportional gain 2	27.0	9	Notch depth 3		0	16	Speed zero clamp level	30	17 *2	Analog monitor 1 output gain	0	5		Overtravel action	0		
7		Velocity loop integral time constant 2	1000.0	10	Notch frequency 4		5000	17 *2	Torque command type	0	18 *2	Analog monitor 2 types	4	6		Servo off action	0		
8		Velocity detection filter 2	0	11	Notch width 4		2	18 *2	Torque command direction source	0	19 *2	Analog monitor 2 output gain	0	7 *2		Sequence at main power AC off	0		
9		Torque filter 2	0.84	12	Notch depth 4		0	19 *2	Torque command gain	3.0	20 *2	DOUT monitor type	0	8 *2		LV trip selection at main power AC off	1		
10	Velocity feed forward gain	30.0	13	Anti-vibration filter switching mode	0		20 *2	Torque command polarity	0	21 *2	Analog monitor output type	0	9 *2	Main power AC off detecting time		70			
11	Velocity feed forward filter	0.50	14	Anti-vibration frequency 1	0.0		21 *2	Speed limit 1	0	22 *2	Analog input 1 (AI1) offset	0	10	Alarm action		0			
12	Torque feed forward gain	0.0	15	Anti-vibration filter configuration 1	0.0		22 *2	Speed limit 2	0	23 *2	Analog input 1 (AI1) filter	0.00	11	Immediate stop torque limit	0				

*1 The maximum Torque limit value (Pr.0.13,Pr.5.22,Pr.5.25,Pr.5.26) varies by the applicable motor

*2 Invalid parameter in MMDKT2C09E,MMDKT2B09E.Please do not chenge from the default value.

*3 When communicating with your computer, please operate the parameter as A5 series. It will not be recognized as A5E series.

PARAMETER				MODEL		MMDKT2C09E / MMDKT2B09E														
Cate gory	Pr.	Parameter	Default value	Cate gory	Pr.	Parameter	Default value	Cate gory	Pr.	Parameter	Default value	Cate gory	Pr.	Parameter	Default value	Cate gory	Pr.	Parameter	Default value	
5	12	Overload level	0	6	7	Torque command addition	0	6	38	Warning mask setting	4									
	13	Overspeed level	0		8	Positive torque compensation	0		39 *2	For manufacturer use	0									
	14	Motor movable range	1.0		9	Negative torque compensation	0		40	For manufacturer use	0									
	15	Control input signal read setting	0		10	Function expansion settings 1	0		41	Anti-vibration depth 1	0									
	16	Alarm clear input (A-CLR) setting	0		11	Current response	100		42	Two-stage torque filter time constant	0.00									
	17	Counter clear input (CL) setting	3		12	For manufacturer use	0		43	Two-stage torque filter Attenuation term	0									
	18	Command pulse prohibition input (INH) disable setting	1		13	2nd inertia ratio	250		44	For manufacturer use	0									
	19	Command pulse prohibition input (INH) read setting	0		14	Immediate stop time for alarm	200		45	For manufacturer use	0									
	20	Position units	0		15	2nd overspeed level	0		46	For manufacturer use	0									
	21	Torque limit selection	1		16 *2	For manufacturer use	0		47	Function expansion settings 2	0									
	22	Torque limit 2	500 *1		17 *2	Front panel parameter write se	0		48	Adjust filter	0.0									
	23	Torque limit switch setup 1	0		18	Start-up wait	0.0		49	Adjust/Torque command Attenuation term	0									
	24	Torque limit switch setup 2	0		19	Encoder Z-phase setting	0		50	Viscous friction compensation gain	0.0									
	25	Positive torque limit for external input	500 *1		20 *2	External scale Z-phase expansion setting	0		51	Immediate cessation completion wait time	0									
	26	Negative torque limit for external input	500 *1		21 *2	Serial absolute external scale Z-phase setting	0		52	For manufacturer use	0									
	27 *2	Analog torque limit input gain	3.0		22 *2	AB-phase regeneration method selection for AB-phase output-type	0		53	For manufacturer use	0									
	28 *2	LED Initial display	1		23	Disturbance torque compensation gain	0		54	For manufacturer use	0									
	29 *3	Baud rate of RS232	2		24	Disturbance observer filter	0.53		55	For manufacturer use	0									
	30 *3	Baud rate of RS485	2		25	For manufacturer use	0		56	For manufacturer use	0									
	31	Axis number	1		26	For manufacturer use	0		57	Torque saturation anomaly detection time	0									
	32	Maximum command pulse input setting	4000		27	Warning latch time	5													
	33	Enable pulse regeneration output limit	0		28	For manufacturer use	0													
	34 *2	For manufacturer use	4		29	For manufacturer use	0													
	35 *2	Front panel lock	0		30	For manufacturer use	0													
	6	0 *2	Analog torque feed forward gain setting		0.0	31	Real time auto-gain tuning estimated speed		1											
		1	For manufacturer use		0	32	Real time auto-gain tuning customize		0											
		2	Excessive speed deviation		0	33 *2	For manufacturer use		1000											
		3	For manufacturer use		0	34 *2	Hybrid vibration suppressor gain		0.0											
		4	JOG speed		300	35 *2	Hybrid vibration suppressor filter		0.10											
		5	Position gain 3 valid time		0.0	36	For manufacturer use		0											
	6	Position gain 3 scaling factor	100		37	Oscillation detection threshold	0.0													

*1 The maximum Torque limit value (Pr.0.13,Pr.5.22,Pr.5.25,Pr.5.26) varies by the applicable motor

*2 Invalid parameter in MMDKT2C09E,MMDKT2B09E.Please do not chenge from the default value.

*3 When communicating with your computer, please operate the parameter as A5 series. It will not be recognized as A5E series.

[The maximum value of Torque limit setup]

Size	Mode	Applicable motor	The maximum value of Torque limit setup
M	MMDHT2C09ND1	MMMA1AC***	330
		MMMA2AC***	250
		MMMA3AC***	250
		MNMA2AC***	285
	MMDHT2B09ND1	MMMA1AB***	300
		MMMA2AB***	300
		MMMA3AB***	300
		MNMA2AB***	300