

Order number	Kind of motor	Rated output W	wer Supply	Motor code	Gear head code	Ratio	Name of dxf file
MB8G5BV+MBMU5AZAB	Worm Shaft	50	100V	MBMU5AZAB	[GH=MB8G5BV]	5	MB8G(5-20)BV+MBMU5AZAB_rev1.dxf
MB8G10BV+MBMU5AZAB	Worm Shaft	50	100V	MBMU5AZAB	[GH=MB8G10BV]	10	MB8G(5-20)BV+MBMU5AZAB_rev1.dxf
MB8G15BV+MBMU5AZAB	Worm Shaft	50	100V	MBMU5AZAB	[GH=MB8G15BV]	15	MB8G(5-20)BV+MBMU5AZAB_rev1.dxf
MB8G20BV+MBMU5AZAB	Worm Shaft	50	100V	MBMU5AZAB	[GH=MB8G20BV]	20	MB8G(5-20)BV+MBMU5AZAB_rev1.dxf
MB8G30BV+MBMU5AZAB	Worm Shaft	50	100V	MBMU5AZAB	[GH=MB8G30BV]	30	MB8G(30-50)BV+MBMU5AZAB_rev1.dxf
MB8G50BV+MBMU5AZAB	Worm Shaft	50	100V	MBMU5AZAB	[GH=MB8G50BV]	50	MB8G(30-50)BV+MBMU5AZAB_rev1.dxf
MB8G5BV+MBMU5AZAB	Worm Shaft	50	200V	MBMU5AZAB	[GH=MB8G5BV]	5	MB8G(5-20)BV+MBMU5AZAB_rev1.dxf
MB8G10BV+MBMU5AZAB	Worm Shaft	50	200V	MBMU5AZAB	[GH=MB8G10BV]	10	MB8G(5-20)BV+MBMU5AZAB_rev1.dxf
MB8G15BV+MBMU5AZAB	Worm Shaft	50	200V	MBMU5AZAB	[GH=MB8G15BV]	15	MB8G(5-20)BV+MBMU5AZAB_rev1.dxf
MB8G20BV+MBMU5AZAB	Worm Shaft	50	200V	MBMU5AZAB	[GH=MB8G20BV]	20	MB8G(5-20)BV+MBMU5AZAB_rev1.dxf
MB8G30BV+MBMU5AZAB	Worm Shaft	50	200V	MBMU5AZAB	[GH=MB8G30BV]	30	MB8G(30-50)BV+MBMU5AZAB_rev1.dxf
MB8G50BV+MBMU5AZAB	Worm Shaft	50	200V	MBMU5AZAB	[GH=MB8G50BV]	50	MB8G(30-50)BV+MBMU5AZAB_rev1.dxf
MB9G5BV+MBMU9A1AB	Worm Shaft	90	100V	MBMU9A1AB	[GH=MB9G5BV]	5	MB9G(5-20)BV+MBMU_AB.dxf
MB9G10BV+MBMU9A1AB	Worm Shaft	90	100V	MBMU9A1AB	[GH=MB9G10BV]	10	MB9G(5-20)BV+MBMU_AB.dxf
MB9G15BV+MBMU9A1AB	Worm Shaft	90	100V	MBMU9A1AB	[GH=MB9G15BV]	15	MB9G(5-20)BV+MBMU_AB.dxf
MB9G20BV+MBMU9A1AB	Worm Shaft	90	100V	MBMU9A1AB	[GH=MB9G20BV]	20	MB9G(5-20)BV+MBMU_AB.dxf
MB9G30BV+MBMU9A1AB	Worm Shaft	90	100V	MBMU9A1AB	[GH=MB9G30BV]	30	MB9G(30-50)BV+MBMU_AB.dxf
MB9G50BV+MBMU9A1AB	Worm Shaft	90	100V	MBMU9A1AB	[GH=MB9G50BV]	50	MB9G(30-50)BV+MBMU_AB.dxf
MB9G5BV+MBMU9A2AB	Worm Shaft	90	200V	MBMU9A2AB	[GH=MB9G5BV]	5	MB9G(5-20)BV+MBMU_AB.dxf
MB9G10BV+MBMU9A2AB	Worm Shaft	90	200V	MBMU9A2AB	[GH=MB9G10BV]	10	MB9G(5-20)BV+MBMU_AB.dxf
MB9G15BV+MBMU9A2AB	Worm Shaft	90	200V	MBMU9A2AB	[GH=MB9G15BV]	15	MB9G(5-20)BV+MBMU_AB.dxf
MB9G20BV+MBMU9A2AB	Worm Shaft	90	200V	MBMU9A2AB	[GH=MB9G20BV]	20	MB9G(5-20)BV+MBMU_AB.dxf
MB9G30BV+MBMU9A2AB	Worm Shaft	90	200V	MBMU9A2AB	[GH=MB9G30BV]	30	MB9G(30-50)BV+MBMU_AB.dxf
MB9G50BV+MBMU9A2AB	Worm Shaft	90	200V	MBMU9A2AB	[GH=MB9G50BV]	50	MB9G(30-50)BV+MBMU_AB.dxf
MB9G5BV+MBMU1E1AB	Worm Shaft	130	100V	MBMU1E1AB	[GH=MB9G5BV]	5	MB9G(5-20)BV+MBMU_AB.dxf
MB9G10BV+MBMU1E1AB	Worm Shaft	130	100V	MBMU1E1AB	[GH=MB9G10BV]	10	MB9G(5-20)BV+MBMU_AB.dxf
MB9G15BV+MBMU1E1AB	Worm Shaft	130	100V	MBMU1E1AB	[GH=MB9G15BV]	15	MB9G(5-20)BV+MBMU_AB.dxf
MB9G20BV+MBMU1E1AB	Worm Shaft	130	100V	MBMU1E1AB	[GH=MB9G20BV]	20	MB9G(5-20)BV+MBMU_AB.dxf
MB9G30BV+MBMU1E1AB	Worm Shaft	130	100V	MBMU1E1AB	[GH=MB9G30BV]	30	MB9G(30-50)BV+MBMU_AB.dxf
MB9G50BV+MBMU1E1AB	Worm Shaft	130	100V	MBMU1E1AB	[GH=MB9G50BV]	50	MB9G(30-50)BV+MBMU_AB.dxf
MB9G5BV+MBMU1E2AB	Worm Shaft	130	200V	MBMU1E2AB	[GH=MB9G5BV]	5	MB9G(5-20)BV+MBMU_AB.dxf
MB9G10BV+MBMU1E2AB	Worm Shaft	130	200V	MBMU1E2AB	[GH=MB9G10BV]	10	MB9G(5-20)BV+MBMU_AB.dxf
MB9G15BV+MBMU1E2AB	Worm Shaft	130	200V	MBMU1E2AB	[GH=MB9G15BV]	15	MB9G(5-20)BV+MBMU_AB.dxf
MB9G20BV+MBMU1E2AB	Worm Shaft	130	200V	MBMU1E2AB	[GH=MB9G20BV]	20	MB9G(5-20)BV+MBMU_AB.dxf
MB9G30BV+MBMU1E2AB	Worm Shaft	130	200V	MBMU1E2AB	[GH=MB9G30BV]	30	MB9G(30-50)BV+MBMU_AB.dxf
MB9G50BV+MBMU1E2AB	Worm Shaft	130	200V	MBMU1E2AB	[GH=MB9G50BV]	50	MB9G(30-50)BV+MBMU_AB.dxf
MBEG5A1BCP	Amp	50	100~120V	MBMU5AZA*			MBEG_BC_.dxf
MBEG5A5BCP	Amp	50	200~240V	MBMU5AZA*			MBEG_BC_.dxf
MBEG9A1BCP	Amp	90	100~120V	MBMU9A1A*			MBEG_BC_.dxf
MBEG9A5BCP	Amp	90	200~240V	MBMU9A2A*			MBEG_BC_.dxf
MBEG1E1BCP	Amp	130	100~120V	MBMU1E1A*			MBEG_BC_.dxf
MBEG1E5BCP	Amp	130	200~240V	MBMU1E2A*			MBEG_BC_.dxf