

## PANATERM Ver6.0

### Update information (Software ver.6.0.7.0 → 6.0.8.0)

● Version information

Item	Contents	Version
Setup	Installer	6.8.0
PANATERM	PANATERM main body	6.0.8.0
ParameterConverter	Parameter file conversion software	1.1.0
SimMotor	Software for simulation	2.1.0
Setup (USBDriver)	Installer 32 bit version for USB communication device driver	16.00.0000
	Installer 64 bit version for USB communication device driver	16.02.0000
USBDriver	Device driver for 32 bit version USB communication	1.1.0.0
	Device driver for 64 bit version USB communication	1.1.0.0
Operation manual	Set up support software PANATERM Ver. 6.0	3.16

● History of change point

No	Objects	Contents
1	Operation manual	Updated the operation manual
2	PANATERM	Supported MINAS-A6BU series Ver1.14 driver
3	PANATERM	Supported MINAS-A6B series, MINAS-A6BL series Ver1.14 driver
4	PANATERM	Improved "Block operation Editor v2"
5	PANATERM	Improved "Select connection with drivers"

● History of correction

No	Function	Symptoms
1	Wave form graphic	"Pressure control gain number" can be selected as a measurement item. (Target: MINAS-A6ST series)
2	Common	Fixed "PANATERM is forcibly shutdown when executing a screenshot".
3	Block operation Editor v2	Fixed "PANATERM is forcibly shutdown when starting and ending "Block operation Editor v2" repeatedly".