


Ultra-slim Body Picking Sensor NA1-PK5 SERIES NA1-5 SERIES



Ultra-slim Body Picking Sensor

NA1-PK5 SERIES NA1-5 SERIES









Make sure to use safety light curtains when using a sensing device for personnel protection.





Even a slim hand is detectable by the 25 mm 0.984 in pitch beam area sensor

10 mm 0.394 in thick: half the thickness of conventional models

Space saving is now possible. The ultra-thin design does not obstruct picking operation.

Clearly visible job indicators

Bright, easy-to-see job indicators, 55 mm 2.165 in in length, have been incorporated into both the emitter and the receiver.





Cable can be freely arranged in any position



BASIC PERFORMANCE

Long sensing range: 3 m 9.843 ft

NA1-5

Its long sensing range of 3 m 9.843 ft is sufficient for confirming access to a parts shelf.

FUNCTIONS


Two unit installation is possible

Sensor units can now be set to different light emission frequencies in order to prevent mutual interference. Two units can now be operated in a side-by-side configuration without interference, for problem-free detection over wider areas.



APPLICATIONS


Preventing wrong parts picking



FUNCTIONS

Lighting pattern selectable

The job indicator operation can be selected as either continuous lighting or blinking.



Selectable detection operation

Either of the two different detection operations may be selected in order to suit the particular application. Sensor units can be set to detect the interruption of 1 or more beam channels, or can be set to detect only the interruption of 2 or more beam channels.




All opaque bodies with ø35 mm ø1.378 in or greater will be detected.

The accidental passage of small objects through the beam axis will not trigger detection, yet the operator's hands will always be accurately detected.
This function is also useful when small objects regularly interrupt the beam axis.

ORDER GUIDE

Туре	Appearance	Sensing range (Note)	Model No.	Output
rd type	Sensing height 100 mm 3.937 in Beam pitch	0.1 to 1.2 m 0.328 to 3.937 ft		NPN open-collector transistor
		(0.05 to 0.5 m 0.164 to 1.640 ft) when set to SHORT.		PNP open-collector transistor
ensing type		0.2 to 3 m 0.656 to 9.843 ft	NA1-5	NPN open-collector transistor
Long s range t		(0.05 to 1 m 0.164 to 3.281 ft) when set to SHORT.	NA1-5-PN	PNP open-collector transistor

- Notes: 1) The sensing range is the possible setting distance between the emitter and the receiver.
 - 2) The model No. with "P" shown on the label affixed to the product is the emitter, "D" shown on the label is receiver.



ORDER GUIDE

5 m 16.404 ft cable length type


5~m 16.404~ft cable length type (standard: 2~m 6.562~ft) is also available. Model No.: NA1-5-C5

Pigtailed type

Pigtailed type is also available. When ordering this type, suffix "-J" to the model No. Please order the mating cable separately. (e.g.) Pigtailed type of NA1-PK5-PN is "NA1-PK5-PN-J".

• Mating cable (2 cables are required.)

Model No. Description		
CN-24-C2 4-core, cable length 2 m 6.562 ft		
CN-24-C5	CN-24-C5 4-core, cable length 5 m 16.404 ft	



S-LINK direct hook-up picking sensor

SL-N15 can be hooked up to the sensor & wire-saving link system **S-LINK**. Refer to our website for the sensor & wire-saving link system **S-LINK**.

Model No.	Description	
SL-N15	Sensing range: 0.2 to 3 m 0.656 to 9.843 ft (0.05 to 1 m 0.164 to 3.281 ft when the switch is set to SHORT) Beam pitch: 25 mm 0.984 in Sensing height: 100 mm 3.937 in Sensing object: ø35 mm ø1.378 in or more opaque object	It is a parts-taking verification sensor with five sensing beams and can be hooked up to the S-LINK cable without any interface. Both the emitter and the receiver are incorporated with bright orange LED job indicators that are easily visible to the operator.




OPTIONS


Designation	Model No.	Description	
Sensor	MS-NA1-1	Four bracket set Four M4 (length 15 mm 0.591 in) screws with washers, eight	
mounting bracket	MS-NA2-1	nuts, four hooks, four spacers and eight M4 (length 18 mm 0.709 in) screws with washers are attached. (Spacers are not attached with MS-NA1-1.)	
Sensor	MS-NA3	It protects the sensor body. Two silver bracket set Four M4 (length 15 mm 0.591 in) screws with washers, and four nuts are attached.	
protection bracket	MS-NA3-BK	It protects the sensor body. Two black bracket set [Four M4 (length 15 mm 0.591 in) screws with washers, and four nuts are attached.	
Slit mask	OS-NA1-5 10 pcs. per set	The slit mask restrains the amount of beam emitted or received. (Seal type)	
Y-shaped connector	SL-WY 5 pcs. per set	This connector is able to combine the cables of receiver and emitter into one.	

Sensor mounting bracket

• MS-NA1-1




• MS-NA2-1



Sensor protection bracket

- MS-NA3
- MS-NA3-BK



M4 screws with washers, and nuts are attached.

Slit mask

• OS-NA1-5




Since the slit mask is of seal type, it can be used by sticking to the detection surface.

Take care that the sensing range will be reduced when the slit mask is used.

Y-shaped connector

• SL-WY



SPECIFICATIONS

Sensin Sensin Beam p Numbe Sensin Supply Power	Type Model No. rking directive compliance ng height ng range (Note 2)	Standard type NA1-PK5	Long sensing range type	Standard type	Long sensing range type
CE mar Sensin Sensin Beam p Numbe Sensin Supply Power	rking directive compliance	NA1-PK5	NA4 E		
Sensin Sensin Beam p Numbe Sensin Supply Power	ng height		NA1-5	NA1-PK5-PN	NA1-5-PN
Sensin Beam p Numbe Sensin Supply Power	<u> </u>		EMC Directive,	RoHS Directive	
Beam p Numbe Sensin Supply Power	ng range (Note 2)	100 mm 3.937 in			
Number Sensin Supply Power	ig range (Note 2)	0.1 to 1.2 m 0.328 to 3.937 ft (0.05 to 0.5 m 0.164 to 1.640 ft when set to SHORT)	0.2 to 3 m 0.656 to 9.843 ft (0.05 to 1 m 0.164 to 3.281 ft when set to SHORT)	0.1 to 1.2 m 0.328 to 3.937 ft (0.05 to 0.5 m 0.164 to 1.640 ft when set to SHORT)	0.2 to 3 m 0.656 to 9.843 ft (0.05 to 1 m 0.164 to 3.281 ft when set to SHORT)
Sensin Supply Power Output	pitch		25 mm	0.984 in	
Supply Power Output	er of beam channels		5 beam	channels	
Power	ng object	ø35 mr	n ø1.378 in or more opaque obje	ect (completely beam interrupted	object)
Output	voltage	12 to 24 V DC ±10 % Ripple P-P 10 % or less			
	consumption (Note 3)	Emitter: 0.5 W or less, Receiver: 0.8 W or less Emitter: 0.6 W or less, Receiver: 0.9 W or less		Receiver: 0.9 W or less	
	t	 Residual voltage: 1 V or le 	r less (between output and 0 V)	PNP open-collector transistor • Maximum source current: 100 mA • Applied voltage: 30 V DC or less (between output and +V • Residual voltage: 1 V or less (at 100 mA source current) 0.4 V or less (at 16 mA source current)	
0	Jtilization category	DC-12 or DC-13			
0	Output operation	ON or OFF when one or more beam channels are interrupted / ON or OFF when two or more beam channels are interrupted, selectable by operation mode switch			
S	Short-circuit protection	Incorporated			
Respor	nse time	10 ms or less (when the interference prevention is used, in Light state: 30 ms or less, in Dark state: 13 ms or less)			
E	Emitter	Power indicator: Green LED (lights up when the power is ON) Job indicator: Orange LED (lights up or blinks when the job indicator input is Low, lighting pattern is selected by operation mode switch) Power indicator: Green LED (lights up when the power is O Job indicator: Orange LED (lights up or blinks when the job indicator input is High, lighting pattern is selected by operation mode switch)		its up or blinks when the job	
Indicators	Receiver	beam channels are stably received) Job indicator: Orange LED (lights up or blinks when the job indicator input is Low, lighting pattern is selected by operation		Operation indicator: Red LED (I beam channels are interrupted, channels or more are interrupted interruption mode) Stable incident beam indicator: beam channels are stably recei Job indicator: Orange LED (ligh indicator input is High, lighting mode switch)	but lights up when two beam d in the double-beam- Green LED (lights up when all ved) ts up or blinks when the job
Interfer	rence prevention function	Incorporated			
Р	Pollution degree	3 (Industrial environment)			
g P	Protection		IP62	(IEC)	
resistance	Ambient temperature	-10 to +55 °C +14 to +131 °F (No dew condensation or icing allowed), Storage: -20 to +70 °C -4 to +158 °F			
<u>s</u> A	Ambient humidity	35 to 85 % RH, Storage: 35 to 85 % RH			
Environmental	Ambient illuminance	Incandescent light: 3,000 & or less at the light-receiving face			
Ĕ V	oltage withstandability	1,000 V AC	for one min. between all supply	terminals connected together an	d enclosure
.E In	nsulation resistance	20 M Ω , or more, with 250 V DC megger between all supply terminals connected together and enclosure			
	/ibration resistance	10 to 150 Hz frequency, 0.75 mm 0.030 in double amplitude in X, Y and Z directions for two hours each			
Shock resistance		490 m/s² acceleration (50 G approx.) in X, Y and Z directions three times each			
Emitting element		Infrared LED (Peak emission wavelength: 950 nm 0.037 mil, synchronized scanning system)			
Material		Enclosure: Heat-resistant ABS, Lens cover: Acrylic, Indicator cover: Acrylic			
Cable		0.3 mm² 4-core (emitter: 3-core) oil resistant cabtyre cable, 2 m 6.562 ft long			
Cable extension		Extension up to total 100 m 328.084 ft is possible for both emitter and receiver with 0.3 mm², or more, cable.			mm ² , or more, cable.
Weight		Net weight: Emitter 80 g approx. Receiver 85 g approx. Gross weight: 270 g approx.	Net weight: Emitter 70 g approx. Receiver 80 g approx. Gross weight: 270 g approx.	Net weight: Emitter 80 g approx. Receiver 85 g approx. Gross weight: 270 g approx.	Net weight: Emitter 70 g approx. Receiver 80 g approx. Gross weight: 270 g approx.

Notes: 1) Where measurement conditions have not been specified precisely, the conditions used were an ambient temperature of +23 °C +73.4 °F.


2) The sensing range is the possible setting distance between the emitter and

- the receiver.
- 3) Obtain the current consumption by the following equation.

Current consumption = Power consumption ÷ Supply voltage

(e.g.) When the supply voltage is 12 V,

the current consumption of the emitter is: $0.5 \text{ W} \div 12 \text{ V} \approx 0.042 \text{ A} = 42 \text{ mA}$



I/O CIRCUIT AND WIRING DIAGRAMS

NA1-PK5 NA1-5 NPN output type

I/O circuit diagram

Color code / Connector pin No. of the pigtailed type (Brown / 1) +V (Black / 4) Load 12 to 24 V DC Output (Note 1) ±10 % 100 mA max. Sensor (Blue / 3) 0 V (Pink / 2) Job indicator input lighting / blinking circuit (Note 2) **(1**) → E Internal circuit -→ Users' circuit

Notes: 1) The emitter does not incorporate the output (black).

- 2) If a connection cable is connected to the relay connector type, then the lead wire color is "white".
- 3) Unused wire must be insulated to ensure that they do not come into contact with wires already in use.


Symbols ... D : Reverse supply polarity protection diode ZD: Surge absorption zener diode Tr : NPN output transistor E : Job indicator (IND.)

Non-contact voltage or NPN open-collector transistor

or

Job indicator input
Low (0 to 2 V): Lights up or Blinks
High (5 to 30 V, or open): Lights off


Wiring diagram



Notes: 1) The emitter does not incorporate the black lead wire.

- If a connection cable is connected to the relay connector type, then the lead wire color is "white".
- 3) Unused wires must be insulated to ensure that they do not come into contact with wires already in use.

Connector pin position (Pigtailed type)




Notes: 1) No connection is required for the emitter.

2) The pin arrangement of the **SL-WY** Y-shaped connector (optional) is identical to the receiver.

PNP output type

NA1-PK5-PN NA1-5-PN


I/O circuit diagram




Notes: 1) The emitter does not incorporate the output (black).

- If a connection cable is connected to the relay connector type, then the lead wire color is "white".
- Unused wire must be insulated to ensure that they do not come into contact with wires already in use.

Symbols ... D : Reverse supply polarity protection diode ZD: Surge absorption zener diode Tr : PNP output transistor E : Job indicator (IND.)




Wiring diagram



Notes: 1) The emitter does not incorporate the black lead wire.

- 2) If a connection cable is connected to the relay connector type, then the lead wire color is "white".
- 3) Unused wires must be insulated to ensure that they do not come into contact with wires already in use.

Connector pin position (Pigtailed type)



Notes: 1) No connection is required for the emitter.


 The pin arrangement of the SL-WY Y-shaped connector (optional) is identical to the receiver.

SENSING CHARACTERISTICS (TYPICAL)

NA1-PK5 NA1-PK5-PN

Parallel deviation


Vertical direction




Horizontal direction



Vertical direction



Horizontal direction




Angular deviation


Emitter angular deviation



· Setting on LONG



Setting on SHORT



Receiver angular deviation




NA1-5 NA1-5-PN

Parallel deviation


Vertical direction Receiver

Emitter


· Common for both horizontal and vertical directions




Angular deviation



• Setting on LONG



Setting on SHORT




Horizontal direction




Emitter Receiver angular deviation



PRECAUTIONS FOR PROPER USE






- If this product is used as a sensing device for personnel protection, death or serious body injury could result.
- For a product which meets safety standards, use the safety light curtain.

Mounting


 Use M4 screws with washers and M4 nuts. The tightening torque should be 0.5 N·m or less.



Purchase the screws and nuts separately.

Orientation


 The emitter and the receiver must face each other correctly. If they are set upside down, the sensor does not work.




Interference prevention function

 By setting different emission frequencies, two units of the sensor can be mounted close together, as shown in the figure below.

The switches must be set with the power supply off. The operation mode does not change if the switch setting is changed with the power supplied.





	Operation mode switch		
	Emitter	Receiver	
Sensor A (FREQ. A)	FREQ. A FREQ. B	FREQ. A FREQ. B	
Sensor B (FREQ. B)	FREQ. A FREQ. B	FREQ. A FREQ. B	

LONG / SHORT selection switch (incorporated on the emitter)

• Select the switch setting according to the setting distance between the emitter and the receiver as given below.

The switches must be set with the power supply off. The operation mode does not change if the switch setting is changed with the power supplied.

Setting distance	Operation mode switch
0.05 to 0.5 m 0.164 to 1.640 ft [NA1-PK5(-PN)] 0.05 to 1 m 0.164 to 3.281 ft [NA1-5(-PN)]	LONG
0.5 to 1.2 m 1.640 to 3.937 ft [NA1-PK5(-PN)] 1 to 3 m 3.281 to 9.843 ft [NA1-5(-PN)]	LONG

Selection of output operation

 The output operation mode is selected by the operation mode switch on the receiver.

The switches must be set with the power supply off. The operation mode does not change if the switch setting is changed with the power supplied.

Output operation	Operation mode switch
ON when one or more beam channels are interrupted (OFF when all beam channels are received).	SINGLE DOUBLE L/ON
OFF when one or more beam channels are interrupted (ON when all beam channels are received).	SINGLE DOUBLE L/ON
ON when any two or more beam channels are interrupted.	SINGLE DOUBLE L/ON
OFF when any two or more beam channels are interrupted.	SINGLE DOUBLE L/ON

Job indicator operation selection

• Lighting / Blinking is selected by the operation mode switch on the emitter and the receiver.

The switches must be set with the power supply off. The operation mode does not change if the switch setting is changed with the power supplied.

	Operation mode switch		
	Emitter	Receiver	
Lighting	LIGHT FLASH	LIGHT FLASH	
Blinking	LIGHT FLASH	LIGHT	

Others

• Do not use during the initial transient time (0.5 sec.) after the power supply is switched on.

DIMENSIONS (Unit: mm in)

Emitter

The CAD data can be downloaded from our website.

NA1-PK5(-PN) NA1-5(-PN) 2-ø4.5 ø0.177 2-ø4.6 ø0.181 2-ø4.5 ø0.177 mounting through holes with M4 nut seats, 3.3 0.130 deep supplementary mounting holes, 1.1 0.043 deep mounting through holes with supplementary mounting holes, 1.1 0.043 deep M4 nut seats, 3.3 0.130 deep (1.1 0.043 deep on back side) (1.1 0.043 deep on back side) (on both sides) (on both sides) 30 1.181 -18 0.709 30 1.181 18_ 5 0 15 0.59 15 0.591 Ъ_ \bigoplus Beam Channel 1 Beam Channel 1 Operation Operation mode switch Job indicator (Orange) Job indicator (Orange) mode switch Beam Beam Channel 2 Channel 2 Beam Channel 3 Stable incident Beam Channel 3 130 140 5.118 5.512 140 130 5.512 5.118 25 0.98 ▲ beam indicator (Green) 0.984 Beam Channel 4 Beam Channel 4 3 25 25 0.984 Beam Channel 5 Beam Channel 5 Operation indicator (Green) indicator (Red) 0

ø3.7 ø0.146 cable, 2 m 6.562 ft long

MS-NA1-1


Sensor mounting bracket (Optional)

Receiver

Assembly dimensions

ø3.7 ø0.146 cable, 2 m 6.562 ft long


Mounting drawing with the receiver



Material: Cold rolled carbon steel (SPCC) (Uni-chrome plated)

Four bracket set

Four M4 (length 15 mm 0.591 in) screws with washers, eight nuts, four hooks and eight M4 (length 18 mm 0.709 in) screws with washers are attached. [M4 (length 18 mm 0.709 in) screws with washers are not used for **NA1-PK5/5** series.]




DIMENSIONS (Unit: mm in)

The CAD data can be downloaded from our website.

MS-NA2-1

Sensor mounting bracket (Optional)




Material: Cold rolled carbon steel (SPCC) (Uni-chrome plated)

Four bracket set

Four M4 (length 15 mm 0.591 in) screws with washers, eight nuts, four hooks, four spacers and eight M4 (length 18 mm 0.709 in) screws with washers are attached.


Assembly dimensions

Mounting drawing with the receiver




MS-NA3 MS-NA3-BK

Sensor protection bracket (Optional)



SL-N15

S-LINK direct hook-up area sensor



Disclaimer

The applications described in the catalog are all intended for examples only. The purchase of our products described in the catalog shall not be regarded as granting of a license to use our products in the described applications. We do NOT warrant that we have obtained some intellectual properties, such as patent rights, with respect to such applications, or that the described applications may not infringe any intellectual property rights, such as patent rights, of a third party.



Panasonic Industry Co., Ltd.

Industrial Device Business Division 7-1-1, Morofuku, Daito-shi, Osaka 574-0044, Japan industrial.panasonic.com/ac/e/